

NHTSA Form 814

"Response to No. 8 Claim Denied Data"

e.	f.	g.				h.		i.			j.	k.	l.	m.	n.		
ClaimNbr	CustNbr	BodyNbr	Product	Yr/Mdl	CompNbr	FailNbr	DelOdom	RepOdom	M/K	WkstDate	ReprDate	RepBy	ReqAmt	ApprAmt	Type	OnRubber	Reason Denied
	48	L084432	BBCV	2005	45100115	1	1110	1231	M	07/30/04	07/07/04	1	\$90.00	\$0.00	W	05/14/04	Part number not provided
	48	L084432	BBCV	2005	45100115	1	1110	1231	M	07/30/04	08/24/04	1	\$171.00	\$0.00	W	05/14/04	Exceeded labor time allowed
	3258	L082855	BBCV	2005	45100115	1	538	2223	M	07/08/04	10/11/04	2	\$58.00	\$0.00	W	05/28/04	Parts not filed on claim
	2053	L084847	BBCV	2005	45100115	1	720	8868	M	07/09/04	04/14/05	1	\$182.00	\$0.00	W	08/11/04	Parts not returned
	2376	B103532	BBCV	2005	45100118	1	585	8884	M	07/08/04	06/13/05	1	\$181.00	\$0.00	W	02/27/04	Parts not returned
	4120	B110681	BBCV	2008	45100115	1	2018	1900	K	05/02/05	05/28/05	1	\$188.00	\$0.00	W	02/04/05	Claim cancelled
	2053	L084849	BBCV	2005	45100115	1	720	8708	M	07/09/04	08/01/05	1	\$182.00	\$0.00	W	08/11/04	Claim cancelled
	4771	L088450	BBCV	2008	45100115	1	2883	8823	M	08/01/05	08/27/05	1	\$212.00	\$0.00	W	02/04/05	Parts not returned
	1339	L089785	BBCV	2006	45100180	1	2890	9058	M	08/25/05	10/08/05	1	\$285.00	\$0.00	W	08/17/05	Claim cancelled
	2053	L084813	BBCV	2005	45100115	1	720	8834	M	07/02/04	10/17/05	1	\$162.00	\$0.00	W	08/04/04	Claim cancelled
	2053	L084807	BBCV	2005	45100115	1	720	14518	M	08/04/04	11/28/05	1	\$189.00	\$0.00	W	08/25/04	Exceeded mileage allowed
	5154	B111075	BBCV	2008	45100115	1	520	13097	M	08/15/05	03/21/06	1	\$199.00	\$0.00	W	04/29/05	Claim cancelled
	5154	B112201	BBCV	2008	45100180	1	620	12073	M	10/28/05	03/28/06	1	\$78.00	\$0.00	W	08/28/05	Work not complete
	2053	B105091	BBCV	2006	45100115	1	385	23833	M	08/07/04	04/07/05	1	\$182.00	\$0.00	W	03/28/04	Holding for parts
	39	L087205	BBCV	2008	45100115	1	1035	9275	M	08/17/05	04/24/06	3	\$184.00	\$0.00	W	08/17/05	Holding for parts

Repaired by:

- 1 Distributor
- 2 Other Repair Shop
- 3 Owner

Larry Sheffield

From: Larry Sheffield [lshaff@blue-bird.com]
Sent: Monday, May 23, 2006 11:03 AM
To: Aaron Carpenter (acarpenter@actia.com); triacy@blue-bird.com; wmlayfie@blue-bird.com; ewlee@blue-bird.com; wpcolems@blue-bird.com
Cc: mastrode@blue-bird.com; Rod Hooley (rhooley@actia.com)
Subject: Meeting with ACTIA at 1:00 pm Tuesday 5-24-06

Good Morning:

Meeting with ACTIA will be 1:00 P.M. Tuesday May 24, 2006 in the Conference room between Diane Squires and Joanne Knight. If you have any information for Aaron Carpenter or any questions that should be addressed on Tuesday, please call or email Aaron before 2:00 P.M. today. The three subjects that I am aware of are:

1. ACTIA Service Bulletin plan on speedometers and tachometers for A3FE and A3RE products for field and in house replacement plan by ACTIA plus action plan on BBCV (fix as fall?).
2. Failed speaker on speedometer for alarms (Mike Layfield).
3. Proposed replacement for VDO speedometers from an outside source.

If you have any questions or additional items for the meeting, please contact me.

Thanks,
Larry Sheffield

Speaker Fellows Sort By E & D[illegible]

Speaker Failure

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	
1		0	1	2	3	4	5	6	7	8	9	A	B	C	L	M
2		CLAIM	ACCT	BODY	PROD	YR	COMP	FL	IN SVC	REPAIR	M	IN SVC	REPAIR	BODY	CHAS	
3		NUM	NUM	NUM		MDL	CODE		ODOM	ODOM	K	DATE	DATE	START	START	
4																
5																
6																
7																
8																
9																
10																
11																
12																
13																
14																
15																
16																
17																
18																
19																
20																
21																
22																
23																
24																
25																
26																
27																
28																
29																
30																
31																
32																
33																
34																
35																
36																
37																
38																
39																
40																
41																
42																
43																
44																
45																
46																
47																
48																
49																
50																
51																
52																
53																
54																
55																
56																
57																
58																
59																
60																
61																
62																
63																
64																
65																
66																
67																

Speaker Features

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
66															
69															
70															
71															
72															
73															
74															
75															
76															
77															
78															
79															
80															
81															
82															
83															
84															
85															
86															
87															
88															
89															
90															
91															
92															
93															
94															
95															
96															
97															
98															
99															
100															
101															
102															
103															
104															
105															
106															
107															
108															
109															
110															
111															
112															
113															
114															

Larry Sheffield

From: Larry Sheffield [lshaff@blue-bird.com]
Sent: Monday, July 18, 2005 4:36 PM
To: Russell Parks (rparks@actia.com)
Cc: triacy@blue-bird.com; wmlayfie@blue-bird.com
Subject: Busses with alarm speaker failures for Russell Parks of ACTIA

Russell:

Attached is a spread sheet with body numbers, distributor, customers, chassis num, etc. This replaces the hard copy that I gave to you this afternoon.

Thanks,

Larry

5/4/2006

Buses with Acfa alarm speaker failure for 5-25-05 sheet Russel .xls

	A	B	C	D	E	F	G	H	I	J	K	L	M
1	BODY	PROD	SCHD	QTY	ENG	T	DISTRIBUTOR	CUSTOMER	BODY	DEL	STATE	CHAS	CHASSIS
2	NUM	TYPE							START	DATE		NUM	START
3													
4	F141547	A3FE	505	1	C7		CENTRAL STAT		11/2/2004	12/14/2004	42	229621	11/2/2004
5	F141790	A3FE	514	5	C7		WISCONSIN BU		1/7/2005	3/25/2005	49	230358	1/6/2005
6	F141801	A3FE	508	1	C7		MIDWEST TRAN		11/9/2004	12/5/2004	22	230374	11/8/2004
7	F142027	A3FE	516	2	C7		WISCONSIN BU		1/18/2005	3/12/2005	48	230838	1/17/2005
8	F142185	A3FE	507	4	C7		AMERICAN BUS		11/15/2004	12/10/2004	30	230958	11/15/2004
9	F142579	A3FE	508	4	C7		AZ BUS SALE		12/3/2004	1/8/2005	5	231886	12/1/2004
10	F142582	A3FE	510	1	C7		OBS, INC.		12/6/2004	12/18/2004	36	231875	12/2/2004
11	F142637	A3FE	518	28	C7		MIDWEST TRA		1/18/2005	3/24/2005	14	231869	1/17/2005
12	F142730	A3FE	515	1	C7		AZ BUS SALE		1/12/2005	2/8/2005	5	232008	1/11/2005
13	F141534	A3RE	509	1	ISC-3		WESTERN BUS		12/2/2004	2/17/2005	47	229482	12/2/2004
14	F142090	A3RE	508	50	ISC-3		FLORIDA TRAN		11/29/2004	12/28/2004	9	230884	11/28/2004
15	F142528	A3RE	514	8	C7		WESTERN BUS		1/4/2005	2/27/2005	47	231598	12/18/2004
16	F142541	A3RE	510	4	ISC-3		WESTERN BUS		12/7/2004	1/30/2005	47	231598	12/6/2004
17	F142583	A3RE	522	1	C7		AZ BUS SALE		3/3/2005	3/30/2005	5	232388	3/7/2005
18	F143102	A3RE	524	1	C7		ELDER EQUIPM		3/15/2005	4/8/2005	50	232818	3/15/2005
19	L061698	A3RE	410	1	ISC		WESTERN BUS		12/2/2003	2/8/2004	57	218945	10/30/2003
20	F066682	AAFC	8460	4	427A	A	UNITED TRUCK		10/15/1984	11/12/1984	23*		10/5/1984
21	B099706	BBCV	341	6	3128		O'CONNOR BUS		7/10/2003	8/19/2003	19	215825	6/19/2003
22	B102007	BBCV	344	2	3128		NORTH CENTRA		7/28/2003	8/10/2003	23	218157	6/6/2003
23	B103328	BBCV	424	1	C7		A GIRARDIN I		3/11/2004	3/31/2004	53	220317	3/2/2004
24	B106074	BBCV	427	8	C7		BBS - PITTS		3/30/2004	6/21/2004	38	221584	3/12/2004
25	B105090	BBCV	427	2	C7		BBS - PITTS		4/1/2004	6/28/2004	38	221580	3/19/2004
26	B106092	BBCV	427	2	C7		BBS - PITTS		3/31/2004	5/5/2004	38	221582	3/18/2004
27	B105098	BBCV	428	2	C7		BBS - PITTS		4/8/2004	6/18/2004	38	221586	3/23/2004
28	B105428	BBCV	427	2	C7		MIDWEST TRAN		3/30/2004	6/8/2004	13	222171	3/12/2004
29	B105498	BBCV	431	2	C7		ATLANTIC TRA		4/29/2004	6/23/2004	20	222470	4/13/2004
30	B105515	BBCV	421	2	C7		MIDWEST TRAN		2/18/2004	3/10/2004	13	222487	2/2/2004
31	B105537	BBCV	423	10	C7		RAMP TRANSP		3/3/2004	5/3/2004	32	222614	2/18/2004
32	B105542	BBCV	425	10	C7		RAMP TRANSP		3/18/2004	5/10/2004	32	222519	2/26/2004
33	B107307	BBCV	431	2	C7		COMMONWEALTH		4/23/2004	5/24/2004	46	225451	4/7/2004
34	B109914	BBCV	516	8	C7		A GIRARDIN I		1/28/2005	2/17/2005	53	231242	12/14/2004
35	L061718	BBCV	406	2	C7		CARDINAL BUS		11/5/2003	12/18/2003	35	218962	9/25/2003
36	L062184	BBCV	412	4	C7		OBS, INC.		12/18/2003	1/24/2004	35	219580	10/21/2003
37	L062196	BBCV	412	4	C7		OBS, INC.		12/17/2003	1/24/2004	35	219581	10/27/2003
38	L062384	BBCV	421	1	C7		OBS, INC.		2/18/2004	3/13/2004	35	219857	2/18/2004
39	L062452	BBCV	421	2	C7		OBS, INC.		2/18/2004	3/20/2004	35	219837	2/5/2004
40	L062453	BBCV	422	2	C7		OBS, INC.		2/27/2004	3/20/2004	35	219938	2/5/2004
41	L062485	BBCV	420	2	C7		SCHOOL BUS S		2/18/2004	3/18/2004	15	218977	10/29/2003
42	L062588	BBCV	434	1	C7		OBS, INC.		5/21/2004	5/17/2004	38	220418	5/12/2004
43	L062778	BBCV	437	2	C7		CENTRAL STAT		6/7/2004	7/14/2004	13	221024	5/28/2004
44	L062817	BBCV	438	2	C7		CENTRAL STAT		6/14/2004	7/24/2004	25	221062	6/3/2004
45	L062912	BBCV	422	1	C7		CAPITAL BUS		2/23/2004	3/16/2004	43	221157	2/2/2004
46	L062938	BBCV	422	3	C7		OBS, INC.		2/25/2004	4/17/2004	35	221222	2/13/2004
47	L062940	BBCV	423	3	C7		OBS, INC.		3/3/2004	4/17/2004	35	221223	2/20/2004
48	L062941	BBCV	423	3	C7		OBS, INC.		3/2/2004	4/17/2004	35	221224	2/17/2004
49	L062944	BBCV	423	1	C7		OBS, INC.		3/1/2004	4/18/2004	35	221227	2/18/2004
50	L063037	BBCV	422	8	C7		AUTO SAFETY		2/24/2004	4/14/2004	3	221459	2/4/2004
51	L063041	BBCV	422	2	C7		AUTO SAFETY		2/24/2004	3/20/2004	3	221463	2/3/2004
52	L063207	BBCV	434	1	C7		WESTERN BUS		5/17/2004	6/12/2004	37	221775	5/10/2004
53	L063382	BBCV	426	2	C7		CAPITAL BUS		3/23/2004	4/21/2004	43	222011	3/15/2004
54	L063391	BBCV	427	2	C7		CAPITAL BUS		4/1/2004	4/20/2004	43	222020	3/22/2004
55	L063382	BBCV	427	2	C7		CAPITAL BUS		4/1/2004	4/20/2004	43	222021	3/23/2004
56	L063723	BBCV	427	6	C7		KANSAS TRUCK		3/28/2004	5/18/2004	16	222512	3/19/2004
57	L063781	BBCV	420	1	C7		ZIA BUS SALE		2/10/2004	3/1/2004	31	222610	12/4/2003
58	L064088	BBCV	422	3	C7		FLORIDA TRAN		2/26/2004	3/25/2004	9	223538	2/4/2004
59	L064417	BBCV	425	2	C7		OBS, INC.		3/18/2004	4/18/2004	35	224372	3/11/2004
60	L064418	BBCV	426	3	C7		OBS, INC.		3/23/2004	4/24/2004	35	224374	3/16/2004
61	L064422	BBCV	426	4	C7		OBS, INC.		3/25/2004	4/18/2004	35	224377	3/18/2004
62	L064425	BBCV	426	4	C7		OBS, INC.		3/23/2004	4/18/2004	35	224380	3/16/2004

Buyers with Active alarm breaker failure for 5-25-05 about Russell.xls

	A	B	C	D	E	F	G	H	I	J	K	L	M
63	L084432	BBCV	435	2	C7		GRANDE AMERI		6/28/2004	6/29/2004	23	224395	5/12/2004
64	L084472	BBCV	434	2	C7		CENTRAL STAT		5/24/2004	6/18/2004	13	224535	5/12/2004
65	L084521	BBCV	428	2	C7		SCHOOL BUS S		3/23/2004	4/19/2004	15	224833	3/18/2004
66	L084523	BBCV	427	2	C7		OBS, INC.		4/1/2004	4/24/2004	38	224838	3/18/2004
67	L084824	BBCV	426	2	C7		OBS, INC.		3/24/2004	4/24/2004	35	224838	3/18/2004
68	L084547	BBCV	438	2	C7		CARDINAL BUS		6/23/2004	7/29/2004	35	224708	6/10/2004
69	L084710	BBCV	434	3	C7		CARDINAL BUS		5/18/2004	7/19/2004	35	225439	6/10/2004
70	L084712	BBCV	435	3	C7		CARDINAL BUS		5/25/2004	7/19/2004	35	225441	6/17/2004
71	L084714	BBCV	428	1	C7		WESTERN BUS		4/6/2004	7/10/2004	37	225445	3/18/2004
72	L084812	BBCV	440	15	C7		BBBS - PITTS		6/30/2004	7/21/2004	36	225588	6/21/2004
73	L084814	BBCV	438	5	C7		BBBS - PITTS		6/15/2004	6/28/2004	38	225588	6/4/2004
74	L084815	BBCV	438	6	C7		BBBS - PITTS		6/15/2004	6/28/2004	38	225589	6/4/2004
75	L084816	BBCV	438	6	C7		BBBS - PITTS		6/15/2004	6/28/2004	38	225590	6/4/2004
76	L084818	BBCV	438	1	C7		BBBS - PITTS		6/15/2004	7/14/2004	38	225593	6/10/2004
77	L084820	BBCV	438	1	C7		BBBS - PITTS		6/17/2004	7/1/2004	38	225594	6/10/2004
78	L084828	BBCV	439	7	C7		BBBS - PITTS		6/23/2004	6/8/2004	38	225602	6/16/2004
79	L084831	BBCV	439	8	C7		BBBS - PITTS		6/24/2004	7/15/2004	38	225605	6/15/2004
80	L084838	BBCV	438	18	C7		BBBS - PITTS		6/15/2004	6/28/2004	38	225610	6/3/2004
81	L084845	BBCV	438	18	C7		BBBS - PITTS		6/14/2004	7/5/2004	38	225619	6/7/2004
82	L084847	BBCV	438	18	C7		BBBS - PITTS		6/14/2004	7/5/2004	38	225621	6/7/2004
83	L084850	BBCV	439	18	C7		BBBS - PITTS		6/23/2004	7/10/2004	38	225624	6/15/2004
84	L084928	BBCV	428	1	C7		COMMONWEALTH		4/6/2004	5/20/2004	46	225788	3/28/2004
85	L084965	BBCV	436	15	C7		FLORIDA TRAN		6/2/2004	7/13/2004	9	225807	6/18/2004
86	L085044	BBCV	435	8	C7		O'CONNOR BUS		6/25/2004	6/25/2004	19	226110	6/13/2004
87	L085046	BBCV	436	8	C7		O'CONNOR BUS		6/28/2004	6/25/2004	19	226111	5/13/2004
88	L085178	BBCV	436	1	C7		O'CONNOR BUS		6/2/2004	6/25/2004	19	226341	6/26/2004
89	L085239	BBCV	442	2	C7		AMERICAN BUS		7/8/2004	8/8/2004	30	226519	6/30/2004
90	L086332	BBCV	438	2	C7		KANSAS TRUCK		6/14/2004	7/31/2004	18	226728	6/10/2004
91	L085333	BBCV	438	2	C7		KANSAS TRUCK		6/15/2004	7/31/2004	18	226728	6/8/2004
92	L086538	BBCV	441	2	C7		MIDWEST TRAN		7/8/2004	8/11/2004	13	227313	6/28/2004
93	L088440	BBCV	603	4	C7		KANSAS TRUCK		10/18/2004	11/8/2004	18	229077	10/9/2004
94	L087085	BBCV	507	48	C7		WESTERN BUS		11/15/2004	12/17/2004	37	229836	11/8/2004
95	L087086	BBCV	507	46	C7		WESTERN BUS		11/17/2004	12/18/2004	37	229841	11/8/2004
96	L087397	BBCV	516	3	C7		CARDINAL BUS		1/1/2005	2/7/2005	35	230396	12/15/2004
97	L087429	BBCV	517	3	C7		CARDINAL BUS		1/25/2005	2/28/2005	35	230443	1/18/2005
98	L087430	BBCV	517	3	C7		CARDINAL BUS		1/25/2005	2/27/2005	35	230444	1/19/2005
99	L088225	BBCV	515	1	C7		BLUE STAR BU		1/12/2005	2/22/2005	43	231802	1/10/2005
100	L088628	BBCV	521	2	C7		OBS, INC.		2/22/2005	3/19/2005	35	232615	2/22/2005
101	L088708	BBCV	522	1	C7		CARDINAL BUS		3/1/2005	3/23/2005	35	232786	2/28/2005
102													
103													
104	A3FE	8											
105	A3FE	7											
106	AAFC	1											
107	BBCV	81											
108		98											
109	TOTAL	98											

Larry Sheffield

From: Pete Runge [prunge@actia.com]
Sent: Tuesday, September 06, 2005 12:09 PM
To: tracy@blue-bird.com; mestrode@blue-bird.com
Cc: Steve Detwiler; Aaron Carpenter; Russell Parks; Dave Troup
Subject: Actia buzzer failures

Sammy,

I wanted to give you an update of our efforts on resolving the buzzer failures.

For short-term immediate action, as of 8/3/05, we are performing a 100% burn-in test on all master speedo gauges. The burn-in test is focused at having the buzzers sound constantly. Any failures found during this test will be analyzed for root cause failure. We have continuous on-going communication with the buzzer supplier as we provide detailed reports on the failures we are seeing and receive feedback from their engineering group. We are reviewing and comparing all collected data such as PWA and gauge build date, chassis type, and part number, narrowing the scope of the failures, and looking for trends. Long term, our engineering department has modified the drive level of the buzzers at the recommendation of the buzzer supplier. It will be a given time span before we receive the PWA's with the modification. We will advise of the implementation date of the reduced drive level once the data is available.

We appreciate your patience as we work to a resolution on the buzzer failures. Any and all information regarding failures and the quick return of all failures will greatly aid our efforts in resolving the failures.

Regards,

Pete Runge
 Quality Assurance Manager
 Actia Corp
 674-268-2858

5/8/2006

Larry Sheffield

From: Russell Parks [rparks@actia.com]
Sent: Wednesday, September 14, 2005 2:27 PM
To: Larry Sheffield; Aaron Carpenter
Cc: Pete Runge
Subject: RE: Request Update Speaker Failures on Actia Gauges

Larry,

Attached is the e-mail sent to Sammy Strobe and Tim Lacy on 9/6/05. As we determine more details and further corrective action plans we will let you know.

Thanks for your patience.

Russell

From: Larry Sheffield [mailto:disheff@blue-bird.com]
Sent: Tuesday, September 13, 2005 12:25 PM
To: Aaron Carpenter; Russell Parks
Cc: trlacy@blue-bird.com; wmlayfle@blue-bird.com
Subject: Request Update Speaker Failures on Actia Gauges

Aaron/ Russell:

What is the status of the speaker failures that we discussed early during the time we were working on LCD failures. Mike Layfield and I do not remember receiving an answer. If you provided an answer, please resend email to Mike Layfield and me to jog our memory. If you have not answered, please provide an update.

Thanks,
Larry Sheffield
Senior Service Engineer
Blue Bird Body Co.

Telephone: 478-822-2211
Email: disheff@blue-bird.com

5/8/2006

Larry Sheffield

From: Larry Sheffield [lshelli@blue-bird.com]
Sent: Wednesday, September 21, 2005 9:30 AM
To: ewlee@blue-bird.com; wmlayfie@blue-bird.com; mstrode@blue-bird.com; tracy@blue-bird.com;
omcathen@blue-bird.com
Co: Jim Moberg; Aaron Carpenter (acarpenter@actia.com)
Subject: ACTIA Conference Call Friday 10:00 on Speaker problems

We will have a conference call with ACTIA on Friday Morning at 10:00 in the conference room between Joannie Knight and Diane Squires. We have a joint agreement with ACTIA to have a weekly conference call until ACTIA completely resolves the speaker/buzzer problem with ACTIA gauges. You are invited and may invite others that I may have missed. If you have any questions, please contact me.

Thanks,
Larry

Larry Sheffield

From: Larry Sheffield [lshaff@blue-bird.com]
Sent: Wednesday, September 28, 2005 2:18 PM
To: ewles@blue-bird.com; wmlayfie@blue-bird.com; msstrode@blue-bird.com; triacy@blue-bird.com;
cmcelhen@blue-bird.com; Aaron Carpenter (acarpenter@actia.com)
Cc: Jim Moberg; dksquire@blue-bird.com
Subject: ACTIA Conference Call Friday 10:00

We will have our second conference call with ACTIA on Friday Morning at 10:00 in the conference room between Joannie Knight and Diane Squires. We have a joint agreement with ACTIA to have a weekly conference call until ACTIA completely resolves the speaker/buzzer problem with ACTIA gauges. You are invited and may invite others that I may have missed. If you have any questions, please contact Mike Layfield or me.

Thanks,
Larry

Aaron:

I will be out of the office Friday and Mike Layfield will be our contact. If you have any questions or need to make any changes, please contact Mike at 478-822-2588. The conference room telephone number is 478-822-2386.

Thanks,
Larry

—Original Message—

From: Aaron Carpenter [mailto:acarpen@actia.com]

Sent: Friday, October 07, 2005 3:51 PM

To: Larry Sheffield; ewlee@blue-bird.com; wmlayfle@blue-bird.com; msstrode@blue-bird.com; triacy@blue-bird.com; cmosshen@blue-bird.com

Cc: Jim Moberg; Enos Yoder; Russell Parks; Pete Runge

Subject: RE: ACTIA Conference Call at 10:00 Friday

Larry,

Here are the notes from our conference call this morning:

1. Frequency Test on Buzzers. ACTIA has run two separate test batches of buzzers. Results thus far, with a small sampling, show good results on buzzers driven at lower frequencies. More tests are being run through the weekend and into next week.
2. Discussions with the vendor are going slow, with difficulty in communicating with the source in Japan.
3. ACTIA is also investigating a long term solution with changing the buzzer. This would mean a PCB re-design.
4. With Burn-in time incorporated on Sept 2nd, and with a new buzzer driver incorporated on Sept 9th, we are interested in seeing if Blue Bird is experiencing any failures, from the field, on buzzers with these modifications.
5. Mike has reported that he is being told by the production floor, that there appears to be less failures with buzzers that have a modified driver and that have had a burn-in cycle.
6. Pete will work with Ernie Lee to see if there is any noticeable difference in the failure rate between the A3 and CV models.
7. Russell Parks will confirm that the packaging, for the rear run box, has been modified, to keep the toggle switches from being damaged. Russell will also update the implementation of the new package design.
8. Russell will report on the availability of diagnostic tools with USB connections.
9. Next conference call on Oct 14th, at 10:00 am, Blue Bird time.

Let me know if I have overlooked any items.

Regards,

Aaron

Mike Layfield

From: Aaron Carpenter [aacarpen@actia.com]
Sent: Friday, October 14, 2005 2:38 PM
To: Larry Sheffield; ewlee@blue-bird.com; wmlayfie@blue-bird.com; trlacy@blue-bird.com; msstrode@blue-bird.com; cmcelhen@blue-bird.com
Cc: Jim Moberg; Enos Yoder; Pete Runge; Russell Parks; Dave Troup
Subject: RE: ACTIA Conference Call at 10:00 Friday

Larry,

Here are the notes from our conference call this morning:

1. **Frequency Test on Buzzers.** Since test results on lower frequencies continue to show positive results, ACTIA is recommending that we move forward in changing the software. Russell Parks will update software, and send it to Kevin Decker for approval. Once approved, Russell Parks will e-mail the release to Roy Morrell, and also copy Mike Layfield. Further testing will continue at ACTIA.
2. **Vendor Discussions.** The vendor has agreed to perform a life test on the speaker. We will update Blue Bird as we get updates from the vendor.
3. **Long Term Solution.** ACTIA is investigating a long term solution with changing the buzzer. This would mean a PCB re-design. We have sampled 10 to 12 different speakers, but so far, we have not found any that are as loud as the one currently being used. We will continue our search.
4. **Speaker Burn-in.** With Burn-in time incorporated on Sept 2nd, and with a new buzzer driver incorporated on Sept 9th, we are interested in seeing if Blue Bird is experiencing any failures, from the field, on buzzers with these modifications.
5. **Modified Speaker Driver.** Mike has reported that he is being told by the production floor, that there appears to be less failures with buzzers that have a modified driver and that have had a burn-in cycle.
6. **In-Plant Failures as well as Warranty Failures.** Pete Runge will contact Ernie Lee to discuss Warranty (field) failures, and Sammy Strode for in-plant failures, to compare failure rates between the A3 and CV models.
7. **Rear Run Box Packaging.** Short Term packaging for the rear run box has been modified. Russell will update the implementation of the new package design.
8. **Diagnostic Tools - USB.** Russell will confirm software compatibility of the USB tools. Aaron will report on the cost and the availability of these tools.
9. **Software Implementation Status.** Discuss implementation of the software changes, starting with product from ACTIA, on Blue Bird's production line, in the yard at Blue Bird, and also in the field.
10. **Service Gauge Kits.** Aaron will check with Matt Davis on availability of service speedo's for needs that are in the field.
11. **Next Conference Call.** Oct 21st, at 10:00 am, Blue Bird time. Phone #: 478-822-2366 or 478/822-2215.

Aaron

From: Larry Sheffield [mailto:lsheffi@blue-bird.com]
Sent: Thursday, October 13, 2005 10:45 AM
To: Aaron Carpenter; ewlee@blue-bird.com; wmlayfie@blue-bird.com; trlacy@blue-bird.com; msstrode@blue-bird.com; cmcelhen@blue-bird.com
Cc: Jim Moberg
Subject: FW: ACTIA Conference Call at 10:00 Friday

We will have our third conference call with ACTIA on Friday Morning at 10:00 in the conference room between Joannie Knight and Diane Squires. We have a joint agreement with ACTIA to have a weekly conference call until ACTIA completely resolves the speaker/buzzer problem with ACTIA gauges. You are invited and may invite others that I may have missed. If you have any questions, please contact Mla Layfield or me.

Thanks,
Lerry

Larry Sheffield

From: Larry Sheffield [mailto:ldisheff@blue-bird.com]
Sent: Thursday, December 01, 2005 11:58 AM
To: 'Aaron Carpenter'
Subject: RE: Conference call

Aaron:

We will meet with Russell during his visit to Blue Bird next week. I past your message to Tim and Mike and also shared that you would be leaving ACTIA next week. Again, it has been a pleasure working with you and I wish you well in your new adventure.

Best regards,

Larry

-----Original Message-----

From: Aaron Carpenter [mailto:acarpen@actia.com]
Sent: Thursday, December 01, 2005 10:31 AM
To: Larry Sheffield
Cc: tracy@blue-bird.com; wmlayfie@blue-bird.com; Russell Parks
Subject: RE: Conference call

Larry,

I spoke with Russell Parks, and he will be down at Blue Bird most of next week, starting Tuesday morning. He will plan on meeting with you, Tim, and Mike, to give you an update on where we stand on the buzzer issue.

Please feel free to call me with any questions.

Best Regards,


Aaron

From: Larry Sheffield [mailto:ldisheff@blue-bird.com]
Sent: Tuesday, November 29, 2005 2:57 PM
To: Aaron Carpenter
Cc: tracy@blue-bird.com; wmlayfie@blue-bird.com
Subject: Conference call


Aaron:

We had tentatively planned for a conference call on Friday December 2 at 10:00 A.M. We have another commitment scheduled for our Service group on Friday morning. Would it be possible to have our conference call between Blue Bird and ACTIA on Thursday December 1 at 10:00 A.M.? If this is not acceptable, please recommend another time.

Thanks
Larry



Date Wednesday, August 09, 2006	ACTIA 10100 LINDSEY DR. CHICAGO, IL 60634 P.O. BOX 100000 CHICAGO, IL 60680 Phone: (773) 888-7788	Post ID 106283	6
104383		City Chicago	
© 2006 Any reproduction of this document without written permission is prohibited.		Page	11 / 2 / 11



Date 04 May 1984	ACTIA 2000 Highway 4 PO Box 284-1073 P.O. Box 284-1000	Product 100223	A
100203		Title China	
ACTIA has been designated as the official official hardware-supported ADRI. In addition,		Page 11 / 11	B



Product Problem Action Report
Actia PN - 100686
Star Micronics SAA-30 Speaker

BACKGROUND: Bluebird Bus Corporation has reported a number of alarm failures in master gauges for the BBCV and BBA3 vehicles. Blue Bird reports that the alarm is working when received, but fails during the assembly process of the vehicle. The Star Micronics SAA-30 speaker part number 100686 has been used in all Actia master gauges and clusters for the entire life of those product lines.

OBSERVATIONS: In all cases alarm failure was a direct result of a broken coil wire of the SAA-30 speaker. As seen in these illustrations, breakage was not consistent to a particular location, however all occurred at a point where adhesive was applied to hold the wire to the diaphragm.



Break at base of coil

Break at neg. lead

Break at pos. lead

ACTION TAKEN: 1) An attempt was made to duplicate these failures in the lab. Twelve (12) Bluebird Master Gauges were placed in an active alarm condition and run continuously. During the test the modules were subjected to numerous heat and cool cycles at various levels of humidity. After three weeks of continuous alarm operation no failures were observed in the twelve modules tested.
2) A shop air gun (~120 PSI) was directed to the speaker opening of a master gauge to see if the air pressure would cause a wire failure. No failure was caused as a result of this experiment.
3) Four (4) samples of failed speakers were returned to Star Micronics for failure analysis.
4) Actia product return records were analyzed to determine the extent of speaker failures across all product lines.
5) Reviewed module assembly process. The module assembly contractor has not changed and is used to assembly all gauge product electronic modules.

PRELIMINARY CONCLUSION: 1) Initial testing would suggest that failures are not the result of a design problem compounded by continual operation. 2) Analysis of product returns indicates that Blue Bird is experiencing buzzer failures at a rate 10 times higher than our next largest gauge customer over similar production quantities. 3) Due to the fact that there is a relatively recent spike in failures may point to a SAA-30 product batch issue with Star Micronics. 4) The possibility exists that damage is occurring to the speaker during vehicle assembly.

ACTION PLAN: 1) Follow-up with the vendor to expedite the failure analysis. They have requested additional information from Actia. Responsibility - David Troup, Kingsley Becker; Expected Completion - requested information to vendor by 7-13-2005; Analysis report from vendor by TBD
2) Analyze the design and review the EV Test to make sure nothing was missed that would compromise the design. Perform additional tests. Responsibility - David Troup, Kingsley Becker, John Harris; Expected Completion - analysis complete by 7-15-2005; additional testing will be ongoing through 7-29-2005
3) Visit Blue Bird production line to determine if failures are the result of the vehicle assembly process. Responsibility - Russell Parks, Pete Runge; Expected Completion - before 7-29-2005

Submitted by David Troup - Director of Engineering July 12, 2005



Failure Analysis Report
STAR MICRONICS CO., LTD.

4 May, 2006

Your Reference Number: None
Our Reference Number: 81-130
Attn : Actia via Star Micronics America, Inc.

1. Details of returned samples

- (a) Model No. (Part No.).....SAA-30A
- (b) Number of returned sample.....4 pcs
- (c) Date of manufacture.....Dec. 2002, Dec 2003, July & Dec. 2004
- (d) Failure mode.....Open coil no SPL

2. Failure mode identification

We found no SPL of returned samples. We found that coil wires on the diaphragm are opened. Please refer Sample photos are sent to you on July 27.

3. Driving power conditions

As far as we investigated the information of driving the speaker, we found that input power is 5.20Vrms and this is exceeding our rated input of 3.68Vrms.

4. Reasons of open coil



Based on the fact that the driving power to the speaker is exceeding to rated power, we believe that coil wires on the diaphragms got mechanical fatigues due to excessive diaphragm vibrations, resulting on the open coil.

5. Remarks



Could you kindly review the input power to the rated power as close as possible so that excessive diaphragm amplitude can be avoid and no mechanical fatigues of coil wires will be avoided.

SAA-30A returned samples photos

No.1



No.2




No.3



No.4



4. MODES OF OPERATION



4.1. Limited Mode

The Master runs in limited mode when the ignition is off but other input signals are requiring the Master to operate. The Master exits limited mode when the ignition becomes active or the signals that caused the Master to wake-up become inactive.

4.1.1. DISPLAY ODOMETER & CLOCK

The odometer and Clock is readable with the ignition off when the vehicle dimmer input level is greater than approximately 10% of the ignition voltage.

4.1.2. HAZARD WARNING LIGHTS

The right and left turn icons are operational with the ignition off when the hazard lights are turned on (right and/or left turn binary inputs high).

4.2. Start-Up Mode

The Master enters start-up mode when the ignition is on. The ignition binary input is used to sense if the key switch is on or off.

The start up self-test is an option enabled through the setup menu. The factory setting for this option is enabled.



BLUE BIRD

LIMITED WARRANTY for All American & Vision

Blue Bird Body Company (Blue Bird) warrants each bus to be free from defects in material and workmanship under normal use and service within the limits described below.

1. For a period of five (5) years/100,000 miles/160,000 kilometers, whichever occurs first from date of delivery to the original user, Blue Bird warrants the:
 - a. Chassis frame rails and crossmembers to be free from defects in structural integrity (breaking or cracking).
 - b. Body shell (those structural metal components welded or riveted together forming floor, side walls, roof, front and rear sections) to be free from defects in structural integrity (breaking or cracking) including rust-through.
 - c. Interior and exterior paint adhesion to the body shell (those structural components forming side walls, roof, front and rear sections). Paint failures caused by corrosive atmospheric conditions and road chemicals are specifically not covered.
 - d. School bus seat frames and barrier frames to be free from defects in structural integrity (breaking or cracking).
2. For a period of four (4) years/50,000 miles/80,000 kilometers, whichever occurs first from date of delivery to the original user, Blue Bird warrants the:
 - a. Front axle assembly, including king pins, I-beam, bushings and spindles, excluding brakes and wheel ends.
 - b. Rear axle assembly and differential, excluding brakes and wheel ends.
3. For a period of two (2) years/24,000 miles/40,000 kilometers, whichever occurs first from date of delivery to the original user, Blue Bird warrants the:
 - a. Suspension, excluding pins and bushings.
 - b. Driveshafts, support bearings and universal joints.
4. For a period of one (1) year/12,000 miles/20,000 kilometers, whichever occurs first from date of delivery to the original user, Blue Bird warrants all other components not covered in 1, 2 and 3 above, except engines, automatic transmissions, wheelchair lifts, air conditioners, tires and batteries, which are warranted by their manufacturers.

Blue Bird's obligation covered in this limited warranty is limited to the repair or replacement of such parts as shall, under normal use and service, appear to have been defective in workmanship or material. Without restricting the generality of this limitation, loss of use, commercial loss and maintenance are specifically not covered. This warranty shall not apply to any parts or components which must be repaired or replaced during the warranty period as a result of what is, in the opinion of Blue Bird, normal wear and/or deterioration in the course of normal operations or use, accident damage, misuse and/or abuse. Abnormal operation, misuse and abuse include, but are not limited to, excessive operation on unpaved, unmaintained roads and operation on cross-country trails or off-road conditions. If distributors, dealers or customers have any vehicle modifications or equipment installations performed without the written approval of Blue Bird, to the extent the modifications or equipment installations adversely affect other vehicle components or performance, Blue Bird shall not accept any product liability or claims under the terms of the limited warranty. These claims become the sole responsibility of the company performing the modifications and/or installations. Overloading beyond the normal seated and standing capacity voids all warranties.

THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED AND ALL OTHER OBLIGATIONS OR LIABILITIES. NO PERSON, INCLUDING SALESPERSONS, DISTRIBUTORS, DEALERS, OR FACTORY REPRESENTATIVES OF BLUE BIRD, IS AUTHORIZED TO MAKE ANY REPRESENTATION OR WARRANTY CONCERNING BLUE BIRD PRODUCTS EXCEPT TO REFER PURCHASERS TO THIS LIMITED WARRANTY. BLUE BIRD MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. BLUE BIRD SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Blue Bird reserves the right to make changes in design and changes or improvements upon its products without imposing any obligations upon itself to install the same upon products theretofore manufactured. Defects must be reported to a Blue Bird Distributor, a BusCare Service Center or a Blue Bird Factory Service Representative immediately upon discovery of the defect and within the warranty period as stated herein. Unless authorized by the Blue Bird Distributor, the BusCare Service Center or the Blue Bird Factory Service Representative, repairs under this limited warranty are to be performed by the Blue Bird Distributor or the BusCare Service Center. It is the responsibility of the owner/operator to return the bus to the Blue Bird Distributor or BusCare Service Center for warranty repairs. Defects shall be repaired promptly after discovery of the defect and within the warranty period as stated herein. All claims for warranty adjustments must be received by Blue Bird not later than 30 days after the repair date. Any suit alleging a breach of this limited warranty or of any other alleged warranty must be filed within one year of breach.

All rights under this limited warranty shall be governed by the law of Georgia, U.S.A.

BLUE BIRD BODY COMPANY, P.O. Box 837, Ft. Valley, GA 31030, U.S.A.

North American (USA & CAN) for ASFE, ASRE, BBCV

EE 03/1987 (1657YM)

Rev. 08/2004

SECN(ang)

Page: 66

Security Locks for Doors / 50

Emergency Door / 50

Exterior Compartments / 51

Battery Compartment / 51

Fuel Door / 51

Stop Arms / 52

Body Tie Downs / 54

Tires, Wheels and Rims / 55

Spare Wheel Location / 56

Jacking Instructions / 58

Changing a Flat Tire / 59

Engine Cooling System / 60

Antifreeze

Shutters

High Idle Function / 61

Prior to Starting the Engine / 62

Using Booster Cables / 63

Starting the Engine / 64

Starting Problems / 65

Automatic Transmission / 66

Manual Transmission / 69

Operation

Lubrication

Maintenance

Recommended Lubricants

Proper Oil Level

Draining Oil

Refilling

Service Brakes / 73

Parking Brake / 74

Schrader Valve / 76

Door/Brake Interlock / 76

Towing or Pushing / 76

Maintenance Charts / 77-82

Maintenance Interval Schedule

(Engines with a Shallow Oil Sump) / 83



Introduction

Thank you for selecting the Blue Bird Vision as your bus of choice. The Vision is the first conventional school bus built from the ground up for the purpose of transporting children to and from school and special events. The Vision is the result of ongoing research and school bus manufacturing experience over the past 77 years. Since 1927, Blue Bird has been committed to providing its customers with quality buses at an exceptional value and with safety in mind.

This manual has been prepared for the purpose of helping acquaint the operator with the look and function of the features of the Blue Bird Vision. While the focus of this manual is on safe and efficient operation of this Blue Bird product, it will also address general maintenance routines and minor service information. For detailed maintenance and service information, please consult the Blue Bird Vision Service Manual. The Blue Bird Vision Service Manual is available from the Technical Publications Department at Blue Bird Body Company.

You should note that the equipment and controls on your particular bus might differ in detail from that described in this manual. The optional equipment chosen at the time of manufacture will determine whether a particular unit has certain components. You should also note that legally required equipment varies from state to state. For this reason, you may have a component on your bus not covered by this operator's manual. Contact your Blue Bird Body distributor if you have questions concerning certain components on your bus that are not covered herein.

The text, illustrations and specifications used in this manual are based on information available at the time of manual publication. Blue Bird Body Company and its vendors continually strive to improve their products. As such, Blue Bird reserves the right to make changes without notification or without incurring liability.

The Blue Bird Vision Operator's Manual is intended to provide the operator general information regarding the safe operation and maintenance of the Blue Bird Vision bus. Please note that not all possible situations that may arise while operating the bus will be addressed. Therefore, the exercise of caution, common sense and good driving practices, coupled with experience, are required for continued safe operation.

If questions come up that are not specifically covered in this manual, please contact your Blue Bird distributor. Your distributor will either answer your questions or will be able to advise you on how to obtain the needed information. To report a problem with your bus, contact your Blue Bird distributor, or if you deal directly with Blue Bird, contact your Service Representative. If you are unsure of the identity of your Blue Bird Service Representative, call the Blue Bird switchboard at 478.825.2021 and ask the receptionist for the Blue Bird Service Department.

The complete line of Blue Bird parts and accessories is available through your Blue Bird distributor. You are encouraged to consult with your distributor before adding accessories to your bus in order to determine the safety of such changes.

Proper operation, service and maintenance will affect the safety and reliability of any vehicle. It is important that anyone operating this bus be thoroughly familiar with the controls and the handling of the vehicle before attempting to transport passengers.

WARNING: No one should attempt to transport passengers without thorough knowledge of the controls and safety equipment.

Summary of Contents

The service and maintenance procedures and intervals in this manual are for the operator's reference only. More comprehensive service information is located in the Blue Bird Vision Service Manual.

All procedures in this Operator's Manual are to be considered the minimum care necessary for the reasonable service life of the vehicle. Each owner has the responsibility to determine if more frequent service or maintenance procedures would be beneficial.

This manual should be read and understood by the bus operator prior to transporting passengers. The operator is responsible to ensure all legal requirements are adhered to. Please note that the OEM documentation will take precedence over information contained herein.

This manual is prepared to provide you with current information important to the operation of the Blue Bird Vision bus. Your comments and suggestions regarding this manual are welcome. Blue Bird encourages you to contact its Technical Publications Department with any comments you have. Send your comments to:

Blue Bird Body Company
Attn: Technical Publications Dept
P.O. Box 937
Fort Valley, Georgia 31030

Important Safety Information Explanation

In this manual, you will see Cautions, Warnings and Notes. Cautions and Warnings are intended to alert the reader to potentially dangerous situations. Notes are intended to clarify instructions. Specifically, Cautions are intended to address situations where personal injury or equipment damage could result from improper execution of a task or practice. Warnings are intended to address situations where personal injury



or death could occur if a task or procedure is performed improperly. In some cases, Notes explain the only known method to accomplish a given task or give additional insight to a procedure.

Blue Bird Body Company offers many accessory items. These components are designed to meet or exceed federal, state and local requirements. Properly selected equipment and accessories can help ensure the safe and reliable transportation of passengers.

Examples of this safety equipment include stop arms, crossing guards, warning lights, first aid kits, fire extinguishers, reflectors, park lights and directional turn indicator lights. There are, of course, many more safety features of this nature.

National Highway Transportation & Safety Administration (NHTSA)

If you feel your new Blue Bird Vision has a safety issue that could cause a crash or personal injury, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) with the information. You should also notify Blue Bird Body Company immediately so that it can evaluate the situation or condition.

If NHTSA receives more information of a similar nature, it may open an investigation into the matter. If NHTSA determines there is a common safety defect in a group of buses, it may issue an order for a recall. NHTSA will not, however, become involved in an individual issue between the owner/operator, distributor and/or Blue Bird Body Company.

To contact NHTSA, call the Auto Safety Hotline toll free at 1.800.424.9393 (outside the Washington, DC area). In the Washington, DC area, call 366.0123. The NHTSA may also be contacted in writing at the following address:

NHTSA
US Department of Transportation
Washington, DC 20590

Optimum Service Life

It is important that you use the right parts when replacement of parts is necessary. The right replacement parts help keep your bus performing at its optimum level and help extend the life of your investment.

For more information:

*Contact your Blue Bird distributor or Parts Sales at
Blue Bird Body Company.*

Before Placing the Bus in Service

It is the responsibility of the bus Owner/Operator to ensure compliance with all federal, state, and local regulations for school bus operation and equipment. As part of a daily pre-trip inspection, the Driver should consider it his/her responsibility to verify that the vehicle is in satisfactory working order and that all emergency equipment is in place, fully stocked (First Aid Kit), up-to-date (Fire Extinguisher), and in proper working condition.

Inspection guidelines from individual state CDL (Commercial Driver's License) manuals take precedence over those found in this manual. Guidelines found herein are in addition to those in your state's CDL manual.

The Driver is responsible for determining that the loading area is clear before stopping to load passengers. The Driver must ensure that all unloaded passengers are clear before moving the bus.

- Check the suspension U-bolt torque.
- Check the service brake adjustment.
- Check the park brake adjustment on units equipped with hydraulic brake systems.
- Check the torque on all the body "tie-down" cap screws.
- Check the engine oil level.
- Check the transmission fluid level.
- Check the engine coolant level.
- Check the air pressure in all the tires.
- Check the torque on the driveline universal joint straps.



Daily Inspections

To maintain the highest possible safety, reliability and economy of operation standards, perform the following inspections:

1. Check the fuel level.
2. Drain all air reservoir tanks, if so equipped.
3. Check the engine oil level.
4. Check the power steering fluid level (Dexron III).
5. Check the engine coolant level. (See Caterpillar publication SEBU7011-11.
6. Check the transmission fluid level (TetraSynTM or equivalent). See the Allison Transmission manual, publication number OM3063EN, as amended, for the proper method to use.
 - Start the engine and allow it to idle for about a minute.
 - With the service brakes applied, shift to Reverse ("R") for a few seconds, back to Neutral ("N") for a few seconds, to Drive ("D") for a few seconds, and then back to Neutral ("N").
 - Allow the engine to idle at about 500-800 RPM and slowly release the service brakes.
 - With the engine running, remove the dipstick and wipe it clean.
 - Insert the dipstick into the tube and remove it. Check the fluid level indicated on the dipstick. Repeat at least twice for accuracy.
 - If the fluid level is still within the cold check band, the transmission may be operated until the fluid is up to operating temperature.
 - If the fluid level is not within the cold check band, you must drain or add fluid until it is before operating long enough to reach normal temperature.
 - Perform the hot check at the first opportunity after the transmission has been operated for about an hour and has reached the normal operating temperature of 160° - 200° F (71° - 93° C).
7. Check the brake fluid level. Maintain the fluid level between the "Max" and "Min" lines on the reservoir. Use only DOT-3 brake fluid.
8. Check the windshield for cracks; clean as necessary. (There are "fold down" steps located at each side to assist in cleaning the outside of the windshield.)
9. Check all the mirrors for proper setting; clean as necessary.
10. Check the strobe light, if so equipped.

11. Check the headlights; clean as necessary.
12. Check the taillights; clean as necessary.
13. Check the directional indicator lights; clean as necessary.
14. Check the hazard lights for operation.
15. Check the brake lights; clean as necessary.
16. Check that the tail pipe is clear of obstruction.
17. Check that the rear "Emergency" door is operational:
 - It opens properly and easily
 - The warning buzzer operates
 - The door closes and latches properly
18. Check the tires:
 - Are there objects lodged between the dual wheels?
 - Are there any obvious punctures?
 - Are all the lug nuts in place?
19. Check the general exterior appearance. Is it clean for school bus identification?
20. Check the general housekeeping. Are the seats, floor, aisles and stepwell clean and clear of obstruction?
21. Check that the emergency exits are clear and operate properly.
22. Check the emergency equipment and supplies:
 - Is all the equipment in the proper place?
 - Is the supply list complete?
23. Check the fire extinguisher:
 - Is the service date okay?
 - Is the charge okay?
24. Check the First Aid Kit:
 - Is it in the proper place?
 - Is the supply list complete?
25. Do all available warning devices indicate when a door is ajar?
26. Start the engine.
27. Listen for obvious, unusual noises.



28. Check that the mirrors do not vibrate excessively.
29. Check interior lights.
30. Check the stepwell lights.
31. Check the horn.
32. Check the heater and defroster blower operation.
33. Check the windshield:
 - Is it clean?
 - Is the wiper operational?
 - What is the condition of the blades?
34. Check the brakes:
 - Does the pedal feel right?
 - Is it at the normal height?
35. Check the stepwell for debris and foreign objects that could present a hazard to passengers while loading or unloading.
36. Is your seat belt fastened?
37. Do the brakes stop and hold the bus?
38. Does the steering feel normal?
39. Does the steering make unusual noise when you turn the wheel?

Any malfunction should be corrected before making your trip. Report the necessary services to the responsible maintenance personnel.

Weekly Inspections

1. Drain all air pressure reservoirs or tanks.
2. Check the tires:
 - Is the tread okay?
 - Are there obvious signs of wear?
 - Are there signs of deterioration?
 - Are there foreign objects between the treads?
 - Is the air pressure correct?

If the air pressure is consistently low in a particular tire, it should be treated as a flat. Remove it and repair the problem.

3. Check all the passenger seat cushions:
 - Are they clean?
 - Are they properly attached to the frame?
 - Are the seat belts okay? Are the buckles operable and easy to release?
 - Is the seat frame-mounting hardware securely attached?
 - Check the stepwell trim fasteners to ensure none are loose. Tighten if necessary.



Product Identification Information

Vehicle Certification Plate

This plate certifies that the vehicle complies with all applicable Federal Motor Vehicle Safety Standards (FMVSS) in effect on the date of manufacture. Do not remove, deface or cover this decal.


Body Serial Number and Service Number Plate

This plate is located inside the bus above the windshield on the front upper panel. You must refer to this placard for registration information and to order replacement parts for the bus.

MANUFACTURED BY	
BLUE BIRD BODY COMPANY	
DATE OF MFG. 01/04	DATE 03/02
INC. MEN. MFG. BY	
SUITABLE TIME - RITE CHARGE	
GVWR : 13500 KG (29760 LB.)	
GVW : FRONT 4537 KG (10000 LB.) WITH	10R22.5 TIRES
22.5X7.50 RIMS AT 758 KPA (110 PSI) COLD SINGLE	
GVW : REAR 9966 KG (19760 LB.) WITH	10R22.5 TIRES
22.5X7.50 RIMS AT 723 KPA (105 PSI) COLD DUAL	
THIS VEHICLE CONFORMS TO ALL APPLICABLE U.S. FEDERAL MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON 03/02	
V.I.N.	TYPE CLASSIFICATION SCHOOL BUS

Axle Record and Chassis Service Number Plate

This plate is located inside the bus above the windshield on the front upper panel.



Adding Aftermarket Accessories

Electrical System Modification

From time to time, you may need to add electrical equipment, or remove and repair electrical components to the Vision. There are certain guidelines that must be followed to avoid the possibility of equipment damage or explosion. Arcing or "sparks" that can occur when electrical connections are made and/or broken causes this danger.

1. The batteries must be disconnected.

WARNING Always disconnect the NEG (-) cable from the battery first. Always disconnect the negative cable at the battery post and wrap it, to prevent accidental contact with the battery post.

CAUTION Never connect any auxiliary or add-on component to posts or terminals that are labeled "Engine" or "ECU". Any noise or spurious (unwanted) signal at these points will adversely affect engine performance. The Service Department at Blue Bird does not approve installing wiring that will produce more than 0.5 volt, voltage drop over the length of the installation.

2. Disconnect the NEG (-) battery cable from the battery post and insulate it to prevent accidental contact.
3. If necessary, remove the POS (+) battery cable. This is normally necessary only if you intend to remove the battery.
4. When adding electrical components, first ensure that the batteries and charging system are capable of the extra load.

CAUTION If the extra load causes the design parameters of the charging system to be exceeded, you must upgrade the system to accommodate the equipment. Overloading the electrical system, as manufactured, will affect the warranty. Modifying the charging system to accommodate the added load may affect the warranty. Always obtain prior approval, in writing from Blue Bird, when modifying the electrical system. If distributors, dealers or customers have any vehicle modifications or equipment installations performed without the written approval of Blue Bird, to the extent the modifications adversely affect other vehicle components or performance, Blue Bird shall not accept any product liability or claims under the terms of the limited warranty. These claims become the sole responsibility of the company or entity performing the modifications and/or installations.

5. Always use wiring of the proper gauge, protected by a high temperature insulation material. 150° C, chemically cross-linked polyethylene insulation, conforming to SAE J-1128, is one such material.



CAUTION Regardless of wiring chart estimations, never install a wire that produces voltage drop in excess of 0.5 volt over the entire length of the circuit to be added; calculations and measurement must include the "return" or ground path.

6. Ensure that any added electrical component is protected by a fuse or circuit breaker.

CAUTION Always provide additional wiring from the electrical panel. Never "tap" or "splice" into an existing wiring harness unless directed to do so by Blue Bird Engineering Department. Any added component must be installed on a dedicated circuit breaker in the electrical panel. Never connect a new component to an existing, factory installed, circuit breaker that is being used to power another component.

7. Push-on type connectors must be insulated.
8. When installing wiring, always use Blue Bird approved straps and wire ties to ensure that the insulation does not come into contact with sharp edges anywhere along the length.
9. Wiring must be supported with insulated straps and wire ties at least every 24 inches (762 mm).
10. Wherever wiring is connected to a moving component, such as the engine, ensure there is a slack loop of adequate length to prevent tension on the wire or the connections.
11. Position a wire clamp (holder) at both ends of the slack loop so that the loop (and not the wire or the connections) absorbs all movement.
12. Wires must be installed so that they do not come into contact with excessive heat. Support wiring at least 4 inches (100 mm) from high heat components (such as the exhaust system) or provide heat shielding to protect the wires.
13. Install a rubber grommet when wires pass through holes.
14. All heavy gauge "hot" or positive potential wiring must be protected with an approved loom material.
15. Ensure that all positive (+) wiring that could be exposed to extreme weather or chafing is covered with an approved loom.

WARNING Always wear protective gear when working with heavy gauge "hot" conductors, including insulated footwear.

16. Avoid routing electrical wiring less than 6 inches (150 mm) from a fuel-handling component (i.e. fuel lines, fuel tank, etc.).

17. Do not "splice" or "tap" into existing wiring when adding components. Always run full length to a proper source in the electrical panel. See Steps 8 and 9 above.
18. When adding electrical components, it is sometimes necessary to use a relay to switch the device. High power components, such as lights, are one example.
19. If the battery cables are both disconnected, always connect the POS (+) cable first. Connect the NEG (-) cable last to avoid arcing.

Keeping Your Bus Looking New

The best way to preserve the appearance of your new bus is to keep it clean. Wash the bus frequently using only cold water and mild soap. Do not wash the bus in direct sunlight or use harsh or gritty cleaning compounds. Even strong soap and cleaning chemicals can harm the paint on your bus and should be avoided.

The soap should never be allowed to dry on the surface of the paint. Rinse thoroughly and immediately to preserve the paint finish.

CAUTION Pressure washing may cause damage to the finish. Always test the effects of the pressure washer, and the chemicals you intend to use, on a similar finish prior to using it on your bus. If your pressure washer is the "re-circulating" type, there should be a filter in place to prevent blasting the paint with the grit removed from the bus.

Always polish with a non-abrasive wax to remove any accumulated residue and to avoid the "weathered" look.

Sometimes, calcium chloride (salt) and other ice melting chemicals will be deposited on the painted surfaces. If these materials are allowed to stay on the paint, they will harm the surface and allow corrosion to begin. Road oils, tree sap, pollution from industrial discharges and bird droppings will also damage the paint. These chemicals and compounds must be removed as quickly as possible.

Paint removal in localized areas due to stone impact, deep scratches and abrasive chemicals must be repaired as soon as possible. These types of damage will quickly result in major corrosion problems and may void the exterior finish warranty.

"Tracked in" petroleum products and road salts will rapidly damage the floor covering. These materials must be removed from the floor promptly to maintain the floor. Frequent mopping with mild soap is recommended to prevent premature deterioration of the floor covering.

CAUTION Continuous care is required to be certain the stepwell and entrance area are kept clean. Never use this area for storage of your ice scraper, whisk broom, etc. This practice not only presents a safety hazard for passengers, but it can also interfere with the proper operation of the door.



Driver's Area

The driver's area of the Blue Bird Vision is designed to afford the operator easy access to all the controls necessary for the safe operation of the vehicle.


The driver should always position his or her body in a comfortable manner, close to the position normally occupied while driving. The driver should look around, be aware of the location of all controls and make any adjustments necessary to the position of the seat, mirrors and pedals.



Instrument Panel and Controls

The instrument cluster can contain up to 10 gauges and 2 Telltale warning light panels. The individual gauges included in your bus are determined by the options chosen at the time of manufacture.

WARNING: Be sure to become familiar with the gauge locations and functions before transporting passengers.



Setting the Clock

Just below the LCD, on the tachometer face, are two momentary buttons. To set the clock, start the bus and press the left button repeatedly until the desired hour appears. To set the minutes, repeatedly press the right button. Parenthetically, the left button is marked "H" for "Hour" and the right button is marked "M" for "Minute".

Set the Trip Odometer

The Trip Odometer is located on the LCD on the Speedometer. The trip odometer may be displayed by pressing the "T" button. This will toggle you between the Odometer and the Trip Odometer. You will know the trip odometer is being displayed by the "T1" symbol in the top right corner of the message center display. To zero trip odometer, while "T1" is displayed, press and hold the "T" button for 5 seconds.

Cruise Control Operation

The Blue Bird Vision is equipped with a cruise control to help the driver maintain a uniform speed during operation on long periods of travel. The cruise control is designed to improve fuel economy and lessen driver fatigue.

CAUTION: The cruise control maintains speed set by the driver. Cruise control is not an "auto-pilot"; the driver must remain in place and in control of the vehicle at all times.

The Cruise Control switches are located on the dash switch panel, to the right hand side of the steering wheel.

To Operate Cruise Control:


1. Attain the desired speed in the normal manner, with the foot-operated accelerator.
2. Press the top edge of the Cruise "On-Off" switch to activate the cruise control system.
3. Press the top edge of the Cruise "Set-Resume" switch to set the speed.
4. To momentarily deactivate the cruise feature, press the brake pedal. This will disengage the cruise control and begin to apply brakes.
5. When you wish to again use the cruise control feature, simply press the lower edge of the "Set-Resume" switch. This will cause the speed to revert to the previously set level, providing the ignition has not been turned off.
6. To adjust the speed at which the cruise control is operating, release the cruise control by pressing the brake, and then use the throttle to reach the desired speed. Then press the top edge of the "Set-Resume" switch.



If the Ignition is switched "Off", it will reset the cruise control. To use it again, simply reactivate according to steps 1 through 6 above.

Indicator Light Panel

1. Park Brake - On when park brake is set; If the park brake is not set when the ignition is switched off light will flash for a period of 2 minutes or until park brake is set. Also, will flash if speed of vehicle is above 3 MPH or until park brake is disengaged.
2. Stop Light - On when the brakes are applied.
3. Hydraulic Brake Failure - Turned on when there is a failure in the hydraulic braking system. Vehicle should not be driven until hydraulic brake system is serviced.
4. Anti-Lock Braking - ABS Indicator turned on when a fault is detected in ABS system. ABS system should be serviced to identify problem.
5. Stop Engine - Turned on when there is a condition in engine that may cause damage if engine continues to run. Stop engine and have serviced.
6. Engine Retard - Turned on when engine senses something outside normal operating parameters. When this happens, engine performance will automatically be reduced. Engine should be serviced to identify problem.
7. Low Coolant Level - Turned on when coolant level drops below 50% normal range. Indicator will blink when level in reservoir indicates 0 percent. Engine should be stopped to prevent overheating.
8. Check Transmission - Turned on when fault is detected in transmission. Transmission should be serviced to identify problem.
9. High Transmission Temperature - Will come on when operation temperature of transmission fluid is greater than 250° F. Vehicle should be stopped to prevent damage to transmission.
10. High Hydraulic Oil Temperature - Turned on when hydraulic oil temperature is over 200° F. Engine should be turned off to prevent damage to hydraulic system.
11. Wait to Start - Indicator is turned on when engine is preparing itself to be started. This may include self-diagnosis and heating intake grids.
12. Range Inhibit - Turned on when the transmission senses something outside normal operating parameters. Transmission should be serviced.



Steering Column Controls

Steering Wheel Adjustment

To adjust the steering wheel position, press downward on the tilting lever located at the left side of the steering column. Tilt the column to the desired position. To raise or lower the steering wheel, pull upward on the tilt lever.

Hazard Flashers

The hazard flasher switch is mounted beneath the directional indicator lever, on the steering column. To activate the hazard flashers, pull outward on the red tang. To cancel the hazard flasher, move the turn indicator lever to indicate a turn.

Directional Indicator Lever

The directional indicator lever is located to the driver's left, mounted on the steering column. To activate the directional signal, pull the lever down to indicate a left turn and push it upwards to indicate a right turn.

Headlight Dimmer Switch

The headlight dimmer switch is located on the turn indicator lever. Pull the lever toward you to toggle the switch.

Driver's Storage

The driver's storage is located to the left of the driver's seat. The cover to the storage area serves as a left armrest.



Steering Wheel Adjustment Lever



Directional Indicator Lever

Hazard Flasher Switch (Red Tang)






Switch Panels

The switch panels, located to the left of the driver, are designed to house most of the control switches used in the daily operation of the vehicle.

Depending on the options installed at the time of manufacture, there will be several switches in the panel. The position each switch occupies is determined by the options installed at the time of manufacture.

See the "Main Switch Panel" for the switch positions and the possible function assigned to those positions.




That part of the Instrument cluster where the radio is located is to the driver's left, and forward of the main switch panel. For switch position assignments see "Radio Panel".

Main Switch Panel


Switch Possible Functions

A1	Front Dome	L.H. Dome	Dome
A2	Rear Dome	R.H. Dome	
A3	Dome	R. Rear Dome	Clearance Lights
B1	Driver's Dome		
B2	Service Door		
B3	Exit Door ARR (Air)		
C1	Fan		
C2	Fan		
C3	Fan		
D1	Panel Dimmer		
D2	Heater Mstr		
D3	Strobe		
E1	Heated Mirror		
E2	Destination Sign		
E3	Sand Refill	Sand Refill Stop	
E4	Lift		
F1	Lift Door	Lift Door / Emergency, Exit	
F2	Roof Vent		
F3	Roof Vent		
F4	Aux Heater		



Chassis Electrical Panel

The chassis electrical panel is located under the transmission shifter, mounted on the floor of the bus near in the center. The cover can be removed by removing four screws. The fuses for the chassis electrical systems are located behind this panel in two rows. The identification for each fuse function is listed on the decal in the inside of the cover. If a fuse is open or "blown", replace it one time. If the fuse opens again, seek professional help to isolate and correct the problem.





Body Electrical Panel



The electrical panel is located outside the bus, immediately under the driver's window.

To access the electrical panel:

1. Press on the button at the center of the panel latch.
2. When the latch springs open, use it as a handle to swing the compartment door open.
3. Secure the panel door in the open position with the position rod, located at the bottom inside corner of the panel. Drop the loose end into the "eye" provided in the electrical panel box.

To close the electrical panel door:

1. Remove the position rod from the "eye" in the electrical panel box and store it in the lip of the panel door.
2. Close the panel door.
3. While pressing firmly on the door, press the latch handle into the locked position.



Driver's Seat


WARNING: Do not attempt to adjust the driver's seat while the bus is in motion. Ensure your feet do not engage the seat adjustment controls while the bus is in motion.

The standard driver's seat in the Blue Bird Vision is the Routemaster, by Bostrom™. To adjust the driver's seat for maximum control, safety and comfort:

1. Push the height adjustment knob in to lower the seat, and pull out on it to adjust the seat higher. Take special care not to hit the height control knob while driving. The seat will suddenly drop. The seat should not reach the limits (top or bottom) during normal operation.
2. To adjust the driver's seat fore and aft position, hold the fore and aft position lever to the left and position the seat to allow access to the control pedals. Pushing down the back angle adjustment lever and moving your body to position the seat back at the desired angle accomplish seat back angle adjustment.
3. The seat cushion tilt adjustment is located to the right front corner of the driver's seat. Turn the knob to position the seat cushion angle as desired.
4. Lumbar adjustment is possible by turning the lumbar adjustment knob, located on the right hand side of the seat back. Rotating the knob clockwise will increase the lumbar support; counterclockwise will decrease the lumbar support.
5. The driver's seat requires periodic lubrication in order to maintain smooth operation. A white, lithium based grease is currently available for this purpose. Common 10W30 motor oil will suffice. Whatever the lubrication product used, a light coat is all that is needed. The seat should be cleaned and lubricated at 6 month or 6,000 mile intervals, whichever occurs first.

WARNING: The driver's seat belt should be worn any time the bus is moving.

The driver's seat belt on the Blue Bird Vision features automatic-locking retractors. These retractors are self-adjusting. They also feature an anti-clinch device that helps to prevent the belt from becoming uncomfortably tight while driving.





To use the belt, withdraw an adequate amount of the belt from the retractor and engage the two halves of the buckle. Release the belt, allowing the retractor to stow the unused portion. After the belt sets, tug on it to ensure the locking mechanism is engaged. To release the buckle, push the button in the center.

If your driver's seat is equipped with a shoulder restraint, it is an emergency activated restraint. The lap belt in this case may also be emergency locking. However, the lap belt may be automatic locking, depending on the options chosen at the time of manufacture. Emergency activated seat belts monitor 2 conditions: if the bus tips 15° or more, or if the seat belt/shoulder harness begins to pay out at more than a preset rate. If either of these conditions exists, the mechanism will automatically lock into place, restraining the driver.

To use the seat belt/shoulder harness, pull out an adequate amount of webbing and engage the buckle. The retractors will pull the harness snugly into place. You may adjust the height of the shoulder harness by positioning the bracket to the most comfortable level. The buckle can be released by pressing on the button at the center.



Passenger Seats

Seat Inspection and Maintenance

Blue Bird passenger seats are built to comply with Federal Motor Vehicle Safety Standards (FMVSS). To ensure your passengers the safest possible transportation, periodic inspection and maintenance must be accomplished.

- Inspect the mounting hardware securing the seat frame to the bus body at least every 90 days. Tighten as necessary.
- Weekly, check the seat cushion attachment to the seat frame. Try to move the seat frame at this time to determine if the frame is loose.
- Check the upholstery weekly for cuts, wear spots, and soil.
- Check the seat back foam for soft or worn areas. Replacement must be with a foam product approved for this purpose. There are aftermarket providers of this material. The use of these third party materials places the responsibility for FMVSS compliance with the vehicle owner.

Cleaning

It is important to keep the interior of the bus as clean as possible. This includes the passenger seating. Regular cleaning and maintenance will help to prolong the service life of the seating and will enhance the general appearance of the bus.

For the common, everyday dirt and soil, a solution of mild soap and water will suffice. For those persistent stains and particles, a stiff brush will be helpful.

For stains of paint, tar and asphalt, the stain must be removed as soon as possible. Rub the stain gently with a series of small strokes. Rinse thoroughly with clean water. This type of stain will become permanent in a very short time.

Lacquer-based stains require immediate attention as well. Soak up as much of the material as possible with a clean dry cloth. Remove the remaining stain with a non-flammable cleaning fluid. Tuff Stuff™ and Armorall™ are two examples of this type-cleaning agent.

Wax-based stains, such as chewing gum, shoe polish or grease stains may be removed in the same manner as the lacquer-based stains. These stains will become permanent in a short while.



Cushion Removal

Passenger seat cushion removal is accomplished by the following:

1. Loosen clamps in 2 places at the forward edge of the seat cushion. Do not remove the clamps.
2. Rotate the clamps to clear the retaining channel.
3. Lift the leading edge of the seat cushion 2 to 3 inches and pull forward to remove it from the seat frame.

Cushion Installation

WARNING Passenger seat cushions must be installed in the manner prescribed below. Failure to properly install the passenger seat cushions could result in injury to passengers in the event of a collision.

1. Position the rear edge of the seat cushion on the seat frame.
2. Lift the forward edge 2 or 3 inches.
3. Push the seat cushion to engage the positive clamp into the rear-retaining channel.
4. Ensure the swivel clamps at the forward edge of the seat cushion are positioned to clear the seat frame.
5. Ensure the rear clamps are securely engaged.
6. Lower the forward edge of the seat cushion into place.
7. Swivel the forward seat cushion clamps into position and tighten securely.

Seat Cushions with Seat Belts Equipped

Removal

1. Loosen the forward clamps.
2. Loosen the rearward swivel clamps.
3. Rotate the rearward clamps and lift the rear edge of the cushion.
4. Pull the seat cushion to the rear to disengage the front clamps.
5. Lift the seat cushion from the seat frame.

Installation

1. Position the forward edge of the seat cushion about 2 inches inside the seat frame.
2. Slide the seat cushion toward the front of the seat frame until the positive clamps engage the front retaining channel.
3. Lower the rear of the seat cushion and turn the swivel clamps to engage the square tubing at the rear of the seat frame.
4. Rotate the swivel clamps into locking position.
5. Tighten all hardware securely.

Seat Belts

Locking Lap Belts

Individual lap belts for passengers can be either retractable or non-retractable, depending on the options ordered at the time of manufacture. The use of the belt is essentially the same in either case.

- Place the catch securely into the buckle.
- Test for positive lock.
- Pull the loose end of the webbing to fit snugly across the lower hips.
- To remove the belt, press the button in the center of the buckle.
- To adjust the belt for larger persons, turn the buckle 90° to the webbing and pull to the desired length.



Belt Inspection / Maintenance

Inspect the passenger lap belts on a weekly basis (more often if conditions warrant).

- Check the buckle for positive lock.
- Check the webbing for adjustment.
- Check the webbing for general appearance and weak places due to wear or vandalism.
- The webbing can be safely washed with a mild soap and water solution.
- Do not use bleach or re-dye the webbing.
- Any cuts or worn lap belt webbing must be replaced as soon as possible.
- Any buckles found to be difficult or impossible to operate must be replaced as soon as possible.
- The buckle must release smoothly and easily.

WARNING Never allow a passenger to strap into a safety belt that is difficult to release. Ensure that all passengers use the lap belt properly. The webbing must be fitted snugly across the body as low as possible. Wearing the webbing high around the waist will result in risk of additional injury in the event of a collision. Do not use bleach or other harsh cleaning chemicals on the seat belt webbing. Do not re-dye the webbing. These processes can severely weaken the material.

WARNING Seat belt assemblies must be serviced as a set only! Buckles and tongues on one manufacturer's belt assembly are not designed to be interchangeable with another manufacturer's belt assembly. They may appear to fit but could unlatch when subject to forces below those required for safe restraint.

Track-Mounted Seating

If your Blue Bird Vision is equipped with track-mounted passenger seats, you are responsible to ensure seat spacing in accordance with FMVSS 222 "School Bus Passenger Seating and Crash Protection" and FMVSS 217 "Window Bus Retention and Release". A decal outlining these requirements is located above the windshield of the bus.


All passenger seats must have a seat or suitable barrier in front of them to provide compartmentalization as required by Federal Motor Vehicle Safety Standards. When you reconfigure the seats to accommodate special needs, it is possible you will need additional barriers to comply with FMVSS rules. These barriers are available from Blue Bird Body Company Parts Sales.

It is the responsibility of the entity installing seating in a school bus to ensure compliance with all applicable laws. We have quoted the known federal rules, but your state or locale may have other requirements. Blue Bird Body Company cannot be responsible for parts, equipment or seating not installed by the company at the time of manufacture. Likewise, Blue Bird Body Company cannot be responsible for any modification to factory-installed equipment and components.


FEDERAL STANDARD REQUIREMENTS FOR TRACK SEAT PLACEMENT ALL PASSENGER SEATS MUST HAVE A SEAT OR BARRIER THE SAME WIDTH AS THE SEAT IN FRONT OF IT




SEAT SPACING REQUIREMENTS
12 INCHES



SEAT SPACING - SEAT
AND BARRIER MUST BE THE SAME
WIDTH (SEE FMVSS 222)



SEAT SPACING - SEAT
AND BARRIER MUST BE THE SAME



SEAT SPACING - SEAT
AND BARRIER MUST BE THE SAME

Child Restraints

Young Children And Infants

Everyone in a vehicle needs protection. This includes infants and all other children. Neither the distance traveled nor the age and size of the traveler changes the need for everyone to use safety restraints. In fact, the law in every state in the United States and in every Canadian province says children up to a certain age must be restrained while in a vehicle.

Every time infants and young children ride in vehicles, they should have the protection provided by the appropriate restraint. Restraints must meet all applicable federal motor vehicle safety standards.

WARNING: People should never hold a baby or young child in their arms while riding in a vehicle. During a crash a baby will become too heavy to hold. For example, in a crash at only 25 mph, a 12 lb. baby will suddenly become a 240 lb. force on a person's arms. A baby should always be secured in an infant restraint. Young children must be secured in appropriate child restraints.

How Child Restraints Work

A child restraint system is any device designed for use in a motor vehicle to restrain, seat, or position children. A built-in child restraint system is a permanent part of the vehicle. An add-on child restraint system is a portable one that must be installed.

For years, add-on child restraints have used the adult belt system in the vehicle. To help reduce the chance for injury, the child must be secured within the restraint. The vehicle's belt system secures the add-on child restraint, and the add-on child restraint's harness system holds the child in place within the restraint.

When securing an add-on child restraint, refer to the instructions that come with the restraint. These instructions may be labeled on the restraint itself or in a booklet, or both.



Universal Child Restraint Anchorage


Seats in this bus equipped with the universal child restraint anchors are identified by a decal located over the seat above the window.

This vehicle may be equipped with a universal child restraint anchorage system. If so, you'll find two anchors in the front lower seatback where the bottom of the seatback meets the back of the seat cushion and a third anchor in the lower rear seatback. (See the Universal Child Restraint Anchorage Illustration.)

In order to use this system, you need either a forward-facing child restraint that has attaching points (A) at its base and a top tether anchor (B), or a rear-facing child restraint that has attaching points (A) as shown.



Whenever applicable, use the universal child restraint anchorage system instead of the vehicle's safety belts to secure a child restraint.

WARNING If a child restraint isn't attached to its anchorage points, the restraint won't be able to protect a child sitting there. In a crash, the child could be seriously injured or killed. Make sure that the child restraint is properly installed using the anchorage points.



Securing A Universal Child Restraint

1. Find the anchors (A) for the seating position you wish to use, where the bottom of the seatback meets the back of the seat cushion. See illustration.
2. Put the child restraint on the seat.
3. Attach the anchor points on the child restraint to the anchors in the bus seat. The child restraint instructions will show you how.
4. Attach the top strap to the top strap anchor (B). Tighten the top strap according to the child restraint instructions.
5. Push and pull the child restraint in different directions to ensure it is secure.



Wheelchair Lift

Either Ricon™ or Braun™ supplies this Blue Bird Vision optional feature. The appropriate operator's manual from the OEM is provided with your new bus. The wheelchair lift requires specific care and maintenance, and each vendor has requirements that must be met for the continued safe operation of the lift.

- The Ricon™ model 55010, "S" series lift provides a 34-inch (.864 m) by 51-inch (1.295 m) platform for the transport of the passenger.
- The Braun™ model L919FII also provides a 34-inch (.864 m) by 51-inch (1.295 m) platform for the transport of the passenger.
- Both lifts provide a maximum of 48 inches (1.219 m) lift from the ground (street) level to the floor of the bus.

It is important that drivers familiarize themselves with the correct operational procedure (as outlined in the OEM instruction manual) prior to attempting to load or unload a passenger.

1. The driver must bring the vehicle to a complete stop, set the parking brakes and shift the transmission to Neutral ("N").
2. The driver should activate the appropriate exterior warning lights required by state and local laws by turning the switch at the (F-1) position "On".
3. When the driver places the "Lift" (E-4) switch in the "On" position, it engages the brake interlock, to hold the bus in position.
4. The driver must go to the "Lift Door" to open it from the outside.
5. As the lift door is opened, an audible warning signal will begin and continue until the door is in the fully open position.
6. When the lift door is fully open, the area lights will come on and the warning sound will cease. The control pendant for the lift will become accessible.

CAUTION Be certain you understand the complete operating instructions for the lift before you attempt to load or unload a passenger.

7. Operate the wheelchair lift in accordance with the instructions in the OEM Operator's Manual.



After the passenger is either loaded or unloaded, the lift must be stowed and the lift door securely closed and locked. When the lift is stowed and you begin to close the door, a buzzer will sound and the power will be removed from the hydraulic pump. The door buzzer will sound until the door is properly closed and latched.

The driver must place the Lift Switch in the "Off" position to release the Interlock system.


All wheelchair lifts used in the Blue Bird Vision are provided with a method for manual operation of the lift. Refer to the OEM instruction manual for the location and manual "emergency" operation.

Windshield Wiper Blade

To replace a windshield wiper blade:

1. Remove the locknut (1) from the center of the wiper blade assembly.
2. Disconnect the washer hose.
3. Remove the wiper blade assembly.

Installation of a new wiper blade assembly is accomplished in the reverse order of the removal instructions above.



Windows

Windows are located throughout your Blue Bird Vision bus. For safety purposes, keep all windows clean to ensure maximum visibility. Use a silicone spray lube every 30 days for maintaining latches and top window slides.

Mirrors and Mirrors Adjustment

CAUTION The mirror system on this Blue Bird Vision has been designed to meet all field-of-view regulations. However, it is the responsibility of the driver to properly adjust the mirrors to provide adequate safety. Mirrors provide additional visibility and they must be properly adjusted for each driver prior to each trip. Mirrors are not a substitute for proper driver training and caution. Do not leave the bus until each disembarking passenger is accounted for and clear of the vehicle. Failure to strictly adhere to this procedure can result in serious injury or death.

There is a minimum of 4 external rearview mirrors on the Blue Bird Vision™. The curb-side rearview flat mirror and convex mirrors are both mounted from the top of the bus, near the top right-hand corner of the windshield. The two mirrors are mounted in a common housing. The driver's side rearview mirrors are mounted near the bottom left-hand corner of the windshield.

There is a minimum of 2 cross-view mirrors on the Vision, one at the forward, outside corner of each fender. The hardware for the fender mounts must be maintained at 20 – 25 Ft lb torque (27 – 34 N-m) to minimize vibration.

CAUTION Do not over-torque the mirror mounting hardware.

The outside rearview mirrors are designed to allow the seated driver a comprehensive view of the areas at each side of the bus and to the rear of the bus.

CAUTION There is a "blind spot" directly behind the bus that extends several feet to the rear of the vehicle.

Mirrors must be adjusted for each individual driver of the bus.

1. Ensure the driver's seat is properly adjusted.
2. Adjust the right-hand flat mirror so that the tops of the right-hand windows are visible in the upper edge of the mirror and the right-hand side of the bus is visible along the vertical, inside edge.
3. Adjust the right-hand convex mirror so that the view in the convex mirror overlaps the view provided by the flat mirror above it. The right-hand side of the bus must be visible in this mirror as well.
4. Adjust the left-hand flat mirror in the same manner as described for the right-hand flat mirror.






5. Adjust the left-hand convex mirror in the same manner as described for the right-hand convex mirror.
6. Adjust the elliptical cross-view mirrors by positioning each mirror so the arrow embossed on the mirror head points directly at the driver's eyes.
7. The final adjustment of the mirror system must be accomplished to provide the seated driver a view consistent with the requirements of FMVSS 111.

- The driver must be able to see the entire test cylinder in each location.
- The driver must be able to see the entire top surface of cylinders "M" and "N".
- The driver must have a view of at least 200 feet from the surface of the mirror.
- The elliptical cross-view mirrors should be adjusted so the seated driver has a complete view of all cylinders "A" through "P", when they are positioned as shown in the illustration, and not directly visible.

- The view provided by the elliptical mirrors must overlap the view afforded by the rear view driving mirror system.

All mirrors must be cleaned and adjusted as necessary to provide a safe driving environment. The use of a mild ammonia/water solution is recommended to clean mirrors.




Heaters and Defrosters

The heater on your Blue Bird Vision is a hot water type heater. The heat is produced by the engine and picked up by the engine coolant. When heat is desired in the passenger coach, the hot engine coolant is routed through heat exchangers (heater cores) located in the passenger area.

The heater may have a series of fan motors incorporated in the system to help direct warm airflow to particular areas of the coach, such as defrosters and the stepwell area. The heater controls are located to the left of the driver, on the switch panel. The warm air def-fusers are capable of being turned in different directions to help eliminate cool spots.

1. **Damper** - Adjusts air flow balance in two directions. By turning knob clockwise, a damper is moved and air is diverted toward the driver. By turning counterclockwise, the air is diverted toward passengers. The amount of air diverted is proportional to amount the knob is turned.
2. **Defrost** - Adjusts the air flow balance between the vehicle compartment and the windshield. By turning knob clockwise, a damper is moved and air is diverted toward the windshield. This should be done to defrost the windshield.
3. **Blower** - Adjusts the speed of the fan, which circulates the air in the system. In the counter clockwise position, the blower is off. By turning clockwise, 3 speeds can be achieved — low, median and high.
4. **Fresh Air Damper** - Controls the type air, which is circulated by the heater system and fan. By turning clockwise, air is circulated from the interior of the vehicle. This is desirable when trying to heat passenger compartment rapidly. By turning the control knob counterclockwise air from outside the bus is used in the system. This is helpful when trying to cool the vehicle.





The filters in the heater system must be maintained and changed on a regular basis, to maintain the airflow across the heater cores. The main heater filter is located behind a small panel at the driver's left. This panel is held in place by luggage type over the center dasps. To remove the filter, pull upward and outward. To replace the filter, press it firmly into position and replace the cover panel. The cover panel must be in place to maintain the airflow through the filter.

There is a cut-off valve located near the driver's left knee that will stop engine coolant flow into the heater core during warm weather.



There are two other heater cut-off valves to prevent engine coolant entering the passenger area during warm weather. One is at the firewall just below the engine coolant reservoir; the other is under the alternator at the engine coolant return to the water pump. All three valves must be in the open position to provide heat to the coach. Service personnel should normally position these valves at appropriate times.

If all the valves are open and there is no heat, check the coolant level. The efficiency of the heaters is determined, in part, by the speed of the engine. The water pump is a major factor in the circulation of the engine coolant; it pumps more when the engine is working. The engine also produces more heat when working than when idling. Your bus may be equipped with an auxiliary water pump in the heater system.

The Vision is equipped with a ducted defroster unit that is a part of the main or "driver's" heater. The airflow to the defroster duct is controlled by the manipulation of the switches at the driver's command.

Some options will also include a fan, mounted over the driver's head and to the left or right. This auxiliary fan will greatly increase the amount of warm air directed at the windshield.

If the auxiliary defroster fan begins to vibrate noticeably, carefully remove the front portion of the fan guard by disengaging the plastic clips around the perimeter.

Using a soft clean cloth, wipe the fan blades clean. Replace the fan guard before operating the fan.

WARNING Never operate a fan without the fan guard in place. The spinning fan blade can cause serious bodily harm.

If the preceding procedure fails to correct the vibration problem with the auxiliary fan, refer to properly qualified service personnel.





Heater Options

There are several heater options available on the Blue Bird Vision. The placement and BTU rating of these options is determined by the choices made during the manufacture of your bus. Some considerations for the heaters in the coach area include the duration and severity of the cold weather experienced in your locale.

It is important that you familiarize yourself with the placement of the ancillary heaters because the filter for each must be maintained in a clean condition. Please refer to the vendor material supplied with your bus to learn the proper method of changing the filters. Generally, the heaters will be located under a passenger seat. The heater could be mounted to the underside of the seat, or it could be mounted on the floor under the seat. The mounting is dependant upon the options chosen.

CAUTION After the first 1000 miles of operation, ensure that service personnel inspect and tighten all the hose clamps in the system to prevent engine coolant loss.

Emergency Equipment

First Aid Kit

The first aid kit is located over the windshield toward the outside of the bus. Each state has a specific location and contents guide that must be followed.

Fire Extinguisher

The fire extinguisher is located according to options selected at time of manufacture. In all cases it will be mounted in the driver's area or near the emergency exits. All states have specific requirements for the location, type and size of the fire extinguisher for school buses operating within the state. All states have the requirement that the fire extinguisher be monitored to keep the charge level within the acceptable range, and the expiration date current. It is the responsibility of the driver to ensure compliance prior to each trip.

Body Fluids Clean-up Kit

The body fluids clean-up kit is located in the general area of the first aid kit. However, each state has specific requirements for the location and labeling of this equipment. Know your state's requirements and maintain the kit accordingly.

Fire Axe and Crowbar

The fire axe and crowbar are located on the electrical panel access cover to the left of the driver. Check the fasteners every 30 days to ensure they are tightened securely.

Flare Kit

The flare kit is mounted on the left-hand side panel behind the driver's seat. The kit contents should be inventoried every 30 days, or as required by your state and local regulations. The mounting fasteners should be checked monthly to ensure security.




Triangular Markers

For those states requiring the triangular markers to be located in the driver's compartment, this container is mounted under the driver's seat. For other states, it is mounted on the floor, under the rearmost left-hand seat or under the second right hand seat. The contents of the triangular warning device kit should be checked each month or as the regulations of your state dictate.

Marker Placement:

On a two-lane roadway, place a triangular marker 100 feet (about 40 paces) to the front of the vehicle, with reflective side facing oncoming traffic. Place another triangular marker 100 feet (about 40 paces) to the rear of the vehicle, with the reflective side toward overtaking traffic.

On a four-lane roadway, place one triangular marker 100 feet (about 40 paces) to the rear of the vehicle. Place another triangular marker 200 feet (about 80 paces) from the first marker (300 feet behind the vehicle). The reflective side should be facing overtaking traffic.



Emergency Exits


Emergency exits are clearly identified with the words, "EMERGENCY EXIT". The operating instructions are written close to, or on, each exit.

Some units are equipped with an audible alarm that sounds when an emergency exit is unlatched. If a buzzer sounds when the ignition is switched to the "ON" position, check all the emergency exits to determine that they are closed and latched.

All emergency exits on this Blue Bird Vision meet FMVSS 217, "Bus Window Retention and Release". These illustrations are "typical" and depict various styles of emergency exits. The exits on this vehicle vary, depending on options selected at the time of manufacture.

CAUTION All "Emergency Exits" should be inspected and tested daily. The labels and decals should be observed to be present and in a legible condition.

Note: See also "Transpec Safety Vent" below in this manual.





Transpec Safety Vent

Transpec™ Safety Vents are designed to provide years of reliable service with a minimum of maintenance. All components are rust proofed with lifetime finishes. Moving parts are Teflon™-coated to eliminate the need for lubrication. Using paint or other coatings, such as graffiti-deterrent coating, is not recommended.

Suggested maintenance includes periodic inspection of all fasteners for evidence of loosening from tapering or vibration. Regular cleaning with mild soap and water is best. Most other cleaning solutions available contain chemicals that will attack the plastics used in the manufacture of the vent. Graffiti removing compounds usually contain acetone, ether, lacquer thinner or other similar chemicals that are known to affect the strength of high impact plastics.

Most of the component parts for the safety vent are available for repairs, except the hinge. The decals are available from your Blue Bird distributor.



Engine Access


Engine access is gained by releasing the over-the-center cam type latches. One latch is located to either side of the engine cover (hood), near the front corner post of the coach.

1. Pull the front edge of the latch toward you.
2. As the cam clears the center, the rubber latch will pull the end section free of the latch hinge.
3. Allow the rubber latch to "dangle".
4. Repeat the process on the opposite side of the bus.
5. Pull firmly on the hood from the center of the front by placing your hand into the gripwell.
6. Gas springs will limit the forward/downward motion of the hood.
7. Allow the hood to rest against the gas springs.

CAUTION: Ensure that the mirrors do not hit anything as you open the hood. Never allow the weight of the hood to rest on the mirror mounts.

To secure the hood in the closed position:

1. Release the hood lock located on either the right or left gas spring. See the pictures below.
2. Close the hood and seat it properly.
3. Position the trailing end of the latch in the fixed mounting hinge on the body cowling.
4. Working against the elasticity of the strap, push the latch end until it passes over the center of the cam.
5. Allow the latch to rest against the cowling. The elasticity of the latch strap will secure the hood while the bus is in motion.





Entrance Door

There are two styles of entrance doors available on the Vision.

- The standard outward opening door.
 - A Jackknife door set.
1. Keep the mechanism securely tightened.
 2. Lubricate the mechanism periodically, including all hinges and swivel parts.
 3. For manual door openers, ensure that the hand-operated mechanism works freely and crosses the center of the cam as the door closes.
 4. Repair or replace any worn seals as soon as possible.
 5. Before each trip, ensure that the door opens and closes properly, and that the hand lever crosses the locking cam as the door panels seat.


Regardless of the door style installed in your bus, the mechanism can be operated in only one of three ways.

The driver's manually operated opening lever is designed to incorporate an over-center cam locking action and features an automatic latching device. The driver automatically disengages the latch mechanism as the door is opened.

The doors may be pneumatically operated. In this case, the driver's manually operated lever is replaced with a control valve, and there is an "EMERGENCY" release located over the door to facilitate opening the doors if air pressure falls.

There is also an electrically operated option. The driver controls the door operation by the use of a switch that activates a motor mounted in the header. There is an "EMERGENCY" release for the electrically operated door as well.

To operate the door when the power assist (pneumatic or electrical) fails, move the "EMERGENCY RELEASE" in the door header to the right to the "OPEN" position.



Security Locks for Doors

The security lock for the outward opening door is a "bolt" that slides into a hole in the header, when the door is in the closed position. The bolt is operated with a key from outside the bus. The driver must flip the hinged stop on the control lever down to prevent the manual control lever crossing the cam center and locking the door. If this happens, entrance may usually be gained through the rear door.

The security lock for the jackknife door is a key operated latch that engages a hook on the opposite door panel. The door must be closed completely for this feature to operate properly. The mechanism can only be operated from outside the vehicle with a key. To operate the security lock, insert the key and rotate the lock ring to engage the bracket on the other door panel. Remove the key. To open the door, insert the key into the security lock and rotate the latching lever as far as possible. Remove the key and open the door.

The security lock for the rear or emergency door may be a simple slide bolt type, or it may have a lock cylinder to position in the latch mechanism. Either type operates as an interrupt in the ignition system to prevent the bus from being cranked while the door is locked.


Emergency Door

The rear center emergency door is 37.7 inches (.957 m) wide by 52.5 inches (1.333 m) high. The latching mechanism for the emergency door includes a single or three point bar lock. There is an inside handle and guard and an outside handle. The outside handle is recessed into the door. There are two panes of glass fitted in the door to assist the driver with rear view, eliminating some of the "blind" area at the rear of the bus.

This door is identified as "EMERGENCY DOOR" with 2 inch lettering. The identifying decal is located at the top of the glass panel.

The Vision is fitted with an audible alarm, activated by operation of the door latching mechanism. This alarm is provided to alert the driver that the rear door is unlatched.

Note: See also the sections of this manual entitled "EMERGENCY EXITS" and "SECURITY LOCKS" for optional variations and door locations.





Exterior Compartments

There may be a luggage compartment on either the left (street) side or the right (curb) side of your bus. This luggage compartment will be positioned between the front and rear wheels. It may be singlewide (55 inches in width) or doublewide (75 inches in width). The fuel tank option chosen will determine the actual location of the luggage compartment.

A tool compartment can be located on either side of the bus just ahead of the rear axle.

Battery Compartment

The battery compartment is located under the driver's window, immediately below the electrical access panel. Some states require that the battery access door be identified with a decal. To access the battery box, pull outward on the leading edge of the latch.

If the battery access door is provided with a lock, the fuel door key will operate it.

To secure the battery compartment door:

1. Ensure the battery tray is secure.
2. Press the battery compartment door closed.
3. The spring-operated latch will automatically latch the door.

Fuel Door

The fuel door is located in the right rear overhang. The fuel door may be fitted with a security lock. If so, you must use the key to unlock the access door before fueling.

WARNING Remove the fuel cap slowly as fuel spray may cause injury.

CAUTION Observe fueling instructions that are printed on the inside of the fuel access door to avoid fire and/or explosion that could result in serious bodily harm or death. Never fill to more than 95% liquid capacity. 95% capacity is reached at the initial pump cut-off.

Stop Arms

Federal Motor Vehicle Safety Standard 131 requires all school buses in the United States to have a "Stop Arm". However, each state has specific requirements pertaining to the installation of the stop arm or stop arms. All stop arms are provided as kits. There is a kit to match the state requirements from where the school bus was ordered. While the stop arms all provide an extra safety warning to alert other drivers, the specific requirements for the blade, lights, lettering and reflectivity vary greatly. Usually, the stop arm is located on the left side of the bus, at the front under the driver's window. Sometimes, there is another stop arm on the left toward the rear of the bus. The driver most commonly manually controls stop arms. There is a switch provided for this purpose. However, some states require that the stop arm be operated in concert with the warning lights when the bus is preparing to stop. In this case, the electronic controls are wired into the lighting system. Operation is automatic when the driver activates the warning light switch.

For pneumatically operated (air pressure) stop arms, the electric control switch operates an air solenoid valve that controls the flow of air to operate the stop arm. The air-operated system is dependant on the air brake system for pressure to operate.

The stop arm system does not require any special maintenance; however, the air pressure may need periodic adjustment. The air regulator is accessible from the electrical panel located under the driver's window, outside of the bus. Comparing it to the illustration may identify the air regulator. To adjust the air pressure, remove the wire-retaining clip and pull downward on the red lock ring. Turn the knob counterclockwise to decrease the airflow, and then slowly increase the air pressure until the stop arm is fully extended. Push the red lock ring upward and install the wire-retaining clip.



The stop arms can be electrically operated. There can be a discrete switch for the driver, or the system can be wired into the warning light circuit. In either case, the electrically operated stop arm requires some preventative maintenance to continue to operate as designed.

- Monthly, lubricate the breakaway hinge at the four pivot points. Use a high performance, penetrating lubricant. Ttflow™ with Teflon™ is one such lubricant.
- Ensure that the stop arm moves freely.
- Check all the fasteners for security and tighten as necessary.
- Quarterly, remove the covers (both front and rear) to inspect the security of the internal fasteners. Tighten as necessary.

Some stop arms are equipped with lights. If so equipped, the lights must be on when the stop arm is extended. A few states allow the lights to be on while the stop arm is retracted. In these cases, the driver will be alerted by an audible signal.

Repair, maintenance and adjustment of the pneumatically operated Stop Arms and Crossing Arms should be referred to trained service personnel.

Body Tie Downs

All body tie-down clamp bolts and shear bolts must be inspected at the first 1000 miles, 2000 miles and at 90-day intervals thereafter.

Ensure that all tie down bolts and shear bolts are tightened to a torque value of 37 – 41 Ft lb (51 – 55 N-m).

The body mounting bolts mount the body to the brackets attached to the frame rails. The body is mounted with rubber pads between the body flooring and the chassis frame rails. See the illustrations. The rubber helps to absorb shock, deaden road noise and maintain tension on the tie down clamps. Always ensure the pads are in the correct position when inspecting the tie downs.





Tires, Wheels and Rims

The tires on your Blue Bird Vision must be properly inflated whenever the vehicle is being operated. Tire pressure that is too low causes a loss of driver control, excess heat in the tire due to "flexing" of the sidewalls and excessive tire wear at the outside edges of the tire. Excessive tire pressure is dangerous because of the explosive nature of escaping pneumatic pressure and causes excessive tire wear in the center of the tread due to the crowning effect. The wheels on the Blue Bird Vision are steel, disc type wheels. There are 10 stud (or lug bolt) holes, on an 11.25-inch (285.74 mm) "hole circle" in an equidistant pattern. The wheel can be either hub-piloted or stud-piloted. There are 5 hand holes forming spokes in the wheel.

WARNING Never operate a vehicle with under-inflated tires. Low air pressure can cause the tire to "flex" too much, creating excessive heating, possibly to the point of ignition. Low tire pressure also causes a loss of driver control. An inflated tire and rim assembly is a very dangerous item. When misused or in a worn-out condition, the tire can separate from the wheel and rim in an explosive manner. Fatal accidents have occurred as a result of improper training and care while handling inflated tires. Always refer to expert service personnel when possible. Without the proper tools, training and experience, it is very dangerous to replace a tire on the bus.

The tires on the Vision are tubeless type, and are mounted on 15° drop center rims and wheels.

If there is a properly inflated spare available and you feel professional assistance is not an option, refer to the section on jacking the bus.

WARNING Never attempt to inflate a seriously low tire. The rims may become dangerous at such times. Always seek professional service in this case.

WARNING Tire inflation pressure must not exceed the recommendations of the tire manufacturer or the wheel/rim manufacturer. You must consider the specific load, speed and application when pressurizing a tire. The inflation pressure information on the tire sidewall does not take the wheel/rim capacities into consideration. Tires should never be inflated beyond the pressure listed on the vehicle certification plate without consulting the tire manufacturer and the wheel/rim manufacturer.

Spare Wheel Location

The Vision may be fitted with a spare wheel and tire, depending on the options chosen at the time of manufacture.

The recommended procedure in the event of a flat tire is to summon professional assistance. The task of replacing a wheel on this vehicle is a difficult and dangerous one.

WARNING: Read and understand all the instructions in this manual, pertaining to changing a tire, before attempting to lift the bus or remove a wheel.

The spare wheel/tire assembly may be located in any one of three possible locations, depending on the options chosen. Most buses do not have a spare wheel.

The spare may be mounted under the bus, in a special spare wheel carrier. The physical location of this carrier depends on the options chosen at the time of manufacture.

To remove a spare wheel stowed in this manner:

1. Remove 2 hex nuts securing the wheel.
2. Rotate the wheel assembly to release it from the locking mechanism.
3. Position the lug wrench into the hole provided and carefully winch the spare wheel to the ground.

WARNING: Maintain a firm grip on the lug wrench during this procedure. The wrench could slip due to the weight of the wheel and cause serious injury or death.

To place the damaged wheel and tire into the spare carrier:

1. Position the wheel on the ground beneath the carrier.
2. Place the metal strap into the center of the wheel.
3. Remove the slack in the support cable while holding the metal keeper strap in position.
4. When the weight of the damaged wheel holds the keeper strap in position, continue to winch the assembly into the locked position.
5. Rotate the assembly to secure in position.
6. Install hex nuts to lock the assembly into position for transport.

The spare wheel could be stowed in a special compartment at either side of the bus, but generally this compartment is positioned on the right-hand (curb) side of the vehicle. The exact position is determined by the options chosen at the time of manufacture.



To remove a spare wheel assembly from this type stowage:

1. Unlatch the compartment door and stow it with the chain and hook assembly provided for this purpose.
2. Remove the "keeper" pin.
3. Pull the spare wheel carrier rack toward you as far as possible.
4. Remove the wheel hold-down clamp and lift the wheel assembly to place it on the ground.

WARNING: Do not slide the wheel assembly over the edge of the sliding rack. The rack will suddenly retreat into the compartment and drop the spare wheel assembly, possibly causing serious injury.

To place the damaged wheel and tire assembly into the spare wheel compartment:

1. Position the spare carrier slide in the retracted position.
2. Position the damaged wheel against the opening in as high (nearly vertical) a position as possible.
3. Lift the damaged wheel and tire from the bottom, pushing inward at the same time.
4. The spare wheel will slide into the compartment.
5. Pull the rack out far enough to position and install the hold down clamp.
6. Secure the sliding rack.
7. Close and secure the compartment door.

The spare wheel may be mounted inside the bus. If so, it is located at the left-hand side of the bus, behind the last seat.

To remove the spare wheel and tire assembly from this stowage:

1. Open and secure the rear (EMERGENCY) door.
2. Remove the spare cover, if so equipped.
3. Remove the hexnut(s) securing the spare wheel to the carrier.
4. Carefully place the spare wheel on the ground through the rear door.

Mounting the damaged wheel and tire assembly in the spare carrier is accomplished in the reverse order of the removal procedure.

Jacking Instructions

Qualified, professional personnel, using the proper equipment, should always perform roadside tire service. This bus should be lifted by means of a floor jack or hydraulic lift on a heavy-duty tow vehicle.

CAUTION: Do not lift the vehicle by the bumper. Bumpers are designed to protect the vehicle and occupants during a collision; they are not designed for towing or jacking up the vehicle. Blue Bird does not recommend towing or jacking the vehicle by the bumpers.

A Notice to Professionals

The bus should not be lifted from the front axle unless there is a block of wood available to use as a buffer, to spread the weight over the greatest possible span of the axle. It is permissible to use specially fabricated cradles fitted to the jack or lifting device as well. When lifting to replace a front wheel, always position the lifting device in such a manner that the bus is lifted from the axle wraparound — that is, the plate from which the axle/suspension U-bolts protrude, except when using fabricated cradles to protect the axle.

1. Ensure the bus is parked on a flat, level surface of sufficient firmness to support the weight of the bus concentrated on the "footprint" of the jack.
2. Chock the wheels in both directions.

CAUTION: Never work under or around a bus supported only by a hydraulic jack. Always use jack stands or blocks as a safety device. Never lift the bus by the bumpers.


3. Position the jack at the jack point shown in the illustration, nearest the wheel to be removed.
4. Ensure the lugs are "broken loose".
5. Raise the wheel enough to rotate the wheel.
6. Position jack stands or blocks under the axle, inboard of, and as near the jack as practical.



Changing a Flat Tire

The lug nuts are tightened to a torque value of 450 - 500 Ft lb (610 - 678 N·m). Without the proper power tools, it is very difficult to remove the lug nuts. The lug nuts must be "broken loose" before lifting the wheel off the ground.

WARNING Never work around or under a bus supported only with a bottle jack.



1. Remove the lug nuts.
2. Position the spare as near to the hub as possible.
3. You will probably need to raise the hub slightly to position the wheel on the studs (lugs).
4. Hand-tighten all lug nuts.
5. Using the lug wrench, tighten all the lugs about a quarter turn.
6. Remove the blocks or jack stand.
7. Lower the bus enough to lock the wheel in place.
8. Using the pattern illustrated, tighten the lug nuts in small increments (about 20 Ft lb (27 N·m)).
9. Tighten the lug nuts as much as possible (at least 300 Ft lb (406 N·m)). See the final torque value in the Warning following step 12.
10. Lower the jack and remove it from under the axle.
11. Stow the damaged wheel and tire assembly.
12. Stow the tools.

WARNING Drive very carefully to the nearest professional tire service. Have the lug nuts tightened to a torque value of 450 - 500 Ft lb. (610 - 678 N·m) if you intend to drive on the spare wheel and tire assembly.

Engine Cooling System

WARNING Exercise extreme care when removing the cap from the engine coolant reservoir. Always allow time for the engine to cool before removing the cap. The pressurized coolant may be very hot and can spray out, causing serious burn injuries.

Check the engine coolant level in the sight glass daily to ensure adequate level. When the coolant level is low, fill only with pre-mixed coolant of the proper specifications. Never fill with plain water. H₂O is corrosive at engine operating temperatures. When pre-mixing antifreeze, always use distilled or ionized water.

Antifreeze

The Blue Bird Vision is filled with an extended life coolant mixture at the time of manufacture. This coolant does not require change as often as regular, heavy-duty antifreeze. The service life of extended life antifreeze is 6 years or 600,000 miles (967,000 km), whichever occurs first.

An extender additive is required at 300,000 miles (483,000 km) or 3 years, whichever occurs first. The amount of extender addition to the system is dependant on the total system capacity. Your Caterpillar engine and the cooling section (radiator, transmission cooler, attendant hoses and the standard heater/defroster) holds 7.5 gallons of coolant. To this, you must add the capacity of the heater system options included on the unit under repair. Calculate the heater options at a rate of 2/3 cup of coolant per foot of heater hose and core length. You must also add the capacity of the water filter and attendant hoses if this unit is so equipped. Refer to Caterpillar publication SEBU7011-11 (3126 engine) or SEBU7766 (C-7 engine) for the appropriate amount of extender to add to the coolant system on your bus.

CAUTION Failure to drain the heater/defroster system and the water filter any time the system is filled with new coolant (changed) causes the coolant service life to revert to the date those parts of the system were filled.

The coolant mixture is 55% antifreeze (ethylene glycol) and 45% distilled or ionized water (H₂O). This coolant mixture will protect against freezing to -40° F (-40° C). This mixture also provides boil protection to 228° F (109° C) at sea level. The Vision should never be operated without this coolant mixture.

CAUTION Water is corrosive at engine operating temperatures. Never add plain water to the system.

When addition of coolant is necessary, a premixed solution is required; you may premix the solution from concentrate and distilled water, or you may purchase a pre-diluted solution. Either way, it must meet the certified parameters of EC-1 and ASTM 4985 or ASTM 5345. Caterpillar ELC™ is one such product.



Please refer to the appropriate Operator's Manual from the manufacturer of the engine in your bus for complete details concerning coolant requirements (i.e., Caterpillar publication number SEBU7011-11 for the Caterpillar 3126 engine or Caterpillar publication number SEBU7766 for the Caterpillar C-7 engine). The OEM documentation will always take precedence over this publication in the event of conflicting information.

Shutters

If your bus is equipped with radiator shutters, the purpose is to help control the engine operating temperature in extremely cold weather. The shutters are automatically controlled by the operating temperature of the engine, and are effective by controlling the amount of air flowing through the radiator cooling fins.

The shutters must be maintained and kept free of foreign material that would prevent them from operating. It is a good idea to inspect them for obstruction on a routine schedule, such as when checking the engine oil level. Remove any debris and, if necessary, seek technical assistance to determine whether the shutters operate properly.

High Idle Function

The high idle control positions the throttle at high idle. This allows the engine to warm up faster than at the normal low idle position. High idle is limited to 1000 to 1200 revolutions per minute (RPM) to avoid engine damage. High idle can be activated by a switch in the driver's area. With the transmission in the neutral position and the park brake set, move the toggle switch to the "HIGH IDLE" position to maintain a constant engine RPM above the normal idle speed.

CAUTION Do not move the toggle switch to the high idle position unless the transmission is in Neutral and the park brake is engaged.

Prior to Starting the Engine

For the most complete engine starting details, refer to the Operator's Handbook from the engine manufacturer. A copy of this manual is provided in the material shipped with your new Blue Bird Vision. The information and/or instructions in the manufacturer's handbook will take precedence over the limited information in this manual.

Your Blue Bird Vision may be equipped with an engine alarm system, designed to help prevent major damage due to high coolant temperature and/or low engine oil pressure. If so equipped, when the engine coolant temperature exceeds 210° F (99° C) and/or the engine lubricating oil pressure falls below 6 psig, an alarm will sound.

CAUTION *The engine must be shut down immediately when the alarm sounds to avoid costly engine damage.*

WARNING *Engine exhaust contains products of combustion that may be harmful to your health. Always start and operate the bus in a well-ventilated area. If the engine must be operated in an enclosed area, vent the exhaust to the outside.*

Perform the required, daily, under-the-hood inspection and maintenance. Also perform any other periodic maintenance prior to starting the engine. This routine can help avoid costly major repairs later.

CAUTION *Engage parking brake for safety purposes.*

1. Look for obvious oil leaks, coolant leaks, loose belts and trash build-up.
2. Remove trash build up and arrange for any necessary repairs as a result of your inspection.
3. Look for cracks in the coolant hoses that may not be leaking yet.
4. Look for cracks in the drive belts and check that they are tight enough to drive the accessories.
5. Check the wiring for loose connections and obvious breaks in the insulation or frayed wires.
6. Check the oil level.
7. Check the fuel supply. Drain water from the separator, if equipped. Ensure the fuel supply valve is open.
8. Check the coolant level.
9. Check the air intake service indicator.



Using Booster Cables

WARNING Ensure that the ignition switch of the disabled vehicle is in the "OFF" position. Always connect the POS (+) battery cable first. Connect the NEG (-) cable to the chassis, away from the batteries. The batteries produce a highly flammable gas. Do not smoke while working near batteries. Take all precautions to prevent sparks from any source in the proximity of the batteries.

1. Ensure the posts on the jumper and bus batteries are clean.
2. Using the RED jumper cable, connect the POS (+) terminal of the bus battery to the POS (+) terminal of the Jumper battery.
3. Using the BLACK Jumper cable, connect one end to the NEG (-) terminal of the Jumper battery.
4. Connect the other end of the BLACK Jumper cable to a solid chassis ground on the bus, such as the engine. Do not connect the black Jumper cable to the NEG (-) terminal of the bus battery.

CAUTION Do not crank the engine for more than 30 seconds. Allow the cranking motor to cool at least 2 minutes between attempts to start the engine.

5. Allow time for the jumper battery to boost the bus battery before attempting to start the engine.
6. After the engine starts, remove the NEG (-) BLACK booster cable from the ground on the bus.
7. Remove the NEG (-) BLACK booster cable from the terminal of the booster battery.
8. Remove the POS (+) RED booster cable from the POS (+) terminal of the bus battery.
9. Remove the RED booster cable from the POS (+) terminal of the booster battery.

Starting the Engine

WARNING Never use ether as an aid in trying to start the engine.

1. Engage the parking brake and place the transmission in neutral.
2. Turn the keyed ignition switch to the "ON" position.

CAUTION Wait until the "Wait to Start" light is no longer illuminated before turning the ignition to the "Start" position.

3. Once the "Wait to Start" light is no longer illuminated, turn the key to "START", to crank the engine.

Note: If the engine does not start after 15 to 20 seconds of cranking, release the key start switch.

The air inlet heater will turn on if the sum of the coolant temperature and the air inlet temperature is less than 109° F (25° C). The "Wait to Start" indicator time may vary somewhat depending upon the temperature. Colder temperatures may increase the time the "Wait to Start" indicator illuminates.

CAUTION The switch should be held in the "Start" position for a maximum of 30 seconds. If the engine has not started in 30 seconds, the operator should not try to start the engine again for at least 2 minutes, in order to allow the starter (cranking motor) time to cool.

If the ignition fails to make a connection, check the vandal lock(s) to ensure it/they is/are not engaged.

4. The "CHECK ENGINE" lamp will flash while the engine is cranking. This lamp will extinguish after the engine starts and achieves proper oil pressure.
 - if the lamp fails to flash during cranking, have qualified service personnel correct the problem.
 - if the lamp continues to flash after the engine is running, refer to qualified service personnel.

The "AIR INLET HEATER" indicator lamp will flash for a minimum of 2 seconds, regardless of the coolant temperature. If the "AIR INLET HEATER" flashes for more than 2 seconds, wait until the lamp stops flashing before attempting to start the engine.

CAUTION Do not engage the cranking motor when the flywheel is turning. Do not attempt to start the engine under load.

CAUTION The oil pressure should rise within 15 seconds after the engine starts. Do not increase engine speed until the oil pressure gauge indicates normal. If oil pressure is not indicated on the gauge in 15 seconds, do not operate the bus. Stop the engine and refer to qualified service personnel.

5. Release the key switch and allow it to return to the "ON" (or run) position immediately after the engine starts. After the engine starts, ensure that the transmission is still in the neutral position. Once a normal engine oil pressure and air pressure are established, the vehicle may be operated at a light load and speed.
6. After the engine has started, the air inlet heater may continue to run in a "continuous" mode or intermittently. The air inlet heater will automatically turn off when the sum of the engine coolant temperature and the air inlet temperature exceeds 127° F (35° C).
7. If the engine is operated at a light load and low speed, it will reach normal operating temperature more quickly than if it idles at no load. When idling in cold weather, increase the engine idle speed to a maximum of 1200 revolutions per minute (RPM); this is the "HIGH IDLE" function. Do not exceed the no-load recommended RPM during the warm up process. Limit unnecessary idle time to 10 minutes.


Starting Problems

For more detailed instructions, refer to the engine manufacturer's Operator's Manual or Handbook.

One or more of the following items may cause an occasional starting problem:

- Low battery charge.
- A malfunctioning starter.
- Problems with the wiring harness or connections.
- A lack of fuel.

If the fuel system has been run dry, fill the fuel tank and prime the fuel system. Locate the remote fuel filter between the frame rails near the rear axle. Press the black button on top of the filter repeatedly to prime the system. When button becomes hard to press, system is primed.




Automatic Transmission

Your Blue Bird Vision is fitted with an Allison™ 2000 series transmission. The shifter lever is mounted on the dash to the driver's right. Gear selection is straightforward; only brief instruction is required to master the shift possibilities on the Vision.

The information in this Operator's Manual is intended to assist the driver in selecting the proper gear for the circumstances. It is accurate to Blue Bird's knowledge, based upon the information available at the time of printing. However, you must remember, Allison has intimate knowledge of its product(s) and, for this reason, the appropriate Allison Operator's Manual will take precedence over this publication. Please refer to Allison publication number OM3063EN. (Please note that this publication number was valid at the time of this manual's publication, but may be subject to change. For clarification, please contact Allison Transmission.)

WARNING: Each time you park the bus or leave the driver's seat while the engine is running:

- Bring the bus to a complete stop using the service brakes.
- Ensure the engine idle is in the "low" position.
- Put the shifter lever in the Neutral ("N") position.
- Apply the emergency (hand) brake on hydraulic systems.
- Pull the "Parking Brake" valve on units with air brakes.
- Chock the wheels and take any other precautionary measures necessary to ensure the bus doesn't move.



If this procedure is not followed, the bus could move unexpectedly and cause serious injury or death and/or property damage.

WARNING: The transmission may not shift into Reverse ("R") due to an active range inhibitor. Check for the illumination of the "Check Transmission", "Range Inhibited" or the "Check Engine" light(s) on the driver's latitude display. Check the Shift Inhibits section of the Allison Operator's Manual for complete details.

CAUTION: Do not idle in Reverse ("R") for more than 5 minutes. Extended idling in Reverse may cause transmission damage and overheating. Always select Neutral ("N") whenever idle time exceeds 5 minutes.

"Reverse" is used to back the bus. Completely stop the bus and allow the engine to return to low idle before shifting from a forward gear to Reverse, or from Reverse to a forward range. The Reverse warning signal is activated when the shift selector is in the "R" position. To shift the lever into Reverse, press the lockout button in the shifter handle, and move the lever into position.



WARNING Bus service brakes, parking brakes or emergency brake must be applied while the transmission is in the Neutral ("N") position. Neutral does not automatically apply vehicle brakes.

WARNING Do not let the vehicle "coast" in Neutral. There is no engine braking and you could lose control, endangering yourself and others. It may be impossible to shift the transmission back into gear while the bus is moving.

Use "Neutral" for the following.

- To start or stop the engine.
- To idle while checking the accessories.
- To operate the engine at idle for periods longer than 5 minutes.

WARNING The engine should not start with the shifter in the "D" position. The transmission may not shift into Drive ("D") because of an active range inhibitor. Check for the illumination of the "RANGE INHIBITED" light or the "CHECK ENGINE/TRANSMISSION" light on the driver's telltale panel. Refer to the Shift Inhibits section of Allison™ publication number OM3063EM.

CAUTION Do not idle in Drive for more than 5 minutes. Extended idling in Drive may cause the transmission to overheat and could damage the transmission. For idle periods of more than 5 minutes, always shift into Park ("P") or Neutral ("N").

Turn the High Idle switch to the Off or Low Idle position before attempting to shift from neutral to a motion gear. A range inhibitor will prevent any shift from Neutral while the engine is set to high idle.

Use overdrive for normal driving. The transmission will automatically move through the gear sequence, starting in 1st and progressing to 4th, depending on the configuration of your transmission. The transmission will also downshift automatically as you slow the bus.

WARNING The engine should not start with the shifter in this position. The transmission has a "hold" feature to prohibit upshifting, above the range selected during normal driving. While descending steep inclines, select a lower shifter position to assist in slowing the bus. However, if the incline is steep enough to cause the engine to exceed its governed speed, the transmission may suddenly shift to a higher gear. This could cause loss of control. Use the vehicle service brakes to prevent the engine from exceeding its governed speed in the hold range.

WARNING: To help avoid a loss of control, use a combination of the vehicle service brake and downshift of the transmission, to maintain speed while descending steep grades. The bus should never be allowed to travel faster than the brakes are capable of stopping, so plan ahead. Downshift before you begin the descent.

Use the 4th gear selection while driving in city traffic and/or while descending or climbing inclines. The transmission will automatically start in 1st gear and progress into 3rd.

WARNING: The engine should not start in this position.

Use 3rd gear selection for steeper inclines and heavy city traffic. The bus will automatically start moving in 1st gear and shift into 2nd, as the torque load becomes less.

WARNING: The engine should not start in this position.

Use 1st gear under the following conditions:

- When pulling through mud or deep snow.
- When maneuvering in tight places.
- When driving up or down very steep grades.

First gear (1) provides the bus with the maximum driving torque and maximum engine braking effect. The transmission will not shift into a higher gear unless the maximum engine RPM is exceeded. The transmission may then shift into a higher gear to prevent engine damage. This could result in a loss of control during the descent of a very steep incline. Use the bus service brakes to help avoid the transmission upshifting.

The pressure the driver applies to the throttle pedal determines the shifting point of the transmission. With the pedal fully depressed, the transmission will take longer, and reach a higher speed, before shifting to the next gear. The action will influence fuel economy as well.



Manual Transmission

Optionally, your Blue Bird Vision may be equipped with an Eaton FS-6406A manual transmission. This six-speed transmission will benefit operators of any skill level. The uncomplicated shifting sequence is a convenience for the skilled driver and a real benefit for the less proficient.

The information in this Operator's Manual is intended to assist the driver in shift sequence operation and lubrication of the manual transmission. For further detailed information on the Eaton FS-6406A transmission see the Roadranger Driver Instructions manual or visit their website at www.roadranger.com.

The Eaton FS-6406A provides six forward speeds and one reverse, and are shifted as you would shift any synchronized manual transmission. Follow the simple 6-speed shift pattern.

Operation

Driving Tips

- Always use the clutch when making upshifts or downshifts. Premature synchronizer failure can result from not using the clutch.
- Always select an initial starting gear that provides sufficient reduction for the load and terrain.
- Never slam or jerk the shift lever to complete gear engagements.
- Never coast with shift lever in neutral position.
- Never downshift at too high of a road speed.

WARNING When parking the vehicle or leaving the cab, always place the shift lever in neutral and set the parking brakes.

Initial Start-Up

WARNING Before starting a vehicle always be seated in the driver's seat, move the shift lever to neutral and set the parking brakes.

1. Make sure the shift lever is in neutral and the parking brakes are set.
2. Turn on the key switch, start the engine.
3. Apply the service brakes.
4. Depress the clutch pedal to the floor.
5. Move the shift lever to the desired initial gear.
6. Release the parking brakes on the vehicle.
7. Slowly release the clutch pedal and apply accelerator.

In the following instructions, it is assumed that the driver is used to operating heavy-duty trucks and tractors, and can coordinate the shift lever movement and clutch pedal to make smooth gear engagements while upshifting or downshifting.

Upshifting

1. Depress the clutch pedal, move the shift lever to the next desired speed.
2. Release the clutch pedal.
3. Accelerate.
4. Continue upshifting.

Downshifting

Although the transmission's first gear is synchronized it is advised that a downshift into first gear be completed at a very slow speed to prevent engine over-speed.

1. Always use the clutch when downshifting from gear to gear to prevent premature synchronizer failure.
2. Depress the clutch pedal, move the shift lever to the next desired speed.
3. Release the clutch pedal.
4. Slow the vehicle.
5. Continue downshifting.

CAUTION Before working on the vehicle or when leaving the cab with the engine running, place the transmission in neutral, set the parking brakes, AND block the wheels.


Lubrication

Proper lubrication procedures are the key to a good all-around maintenance program. If the oil is not doing its job, or if the oil is ignored, all the maintenance procedures in the world are not going to keep the transmission running or assure long transmission life.

The Eaton transmission is designed so that the internal parts operate in an oil circulating bath created by the motion of the gears and shafts.

Thus, all parts are amply lubricated if these procedures are closely followed:

1. Maintain oil level.
2. Follow maintenance interval chart.
3. Use only recommended lubricant.
4. Buy from a reputable dealer.





Maintenance Interval Chart

Eaton Roadranger CD50 Transmission Fluid	
HIGHWAY USE - Heavy Duty and Mid-Range	
Initial Fill with Eaton Roadranger CD50 Transmission Fluid	
Every 10,000 miles (16090 Km)	Check fluid level. Check for leaks.
Every 250,000 miles (402336 Km)	Change transmission fluid.
OFF-HIGHWAY USE	
Every 40 hours	Inspect lubricant level. Check for leaks.
Every 500 hours	Change transmission fluid where severe dirt conditions exist.
Every 1,000 hours	Change transmission fluid (Normal off-highway use.)
HIGHWAY USE - Heavy Duty and Mid-Range	
Initial Fill with Other Recommended Oil	
First 3,000 to 5,000 miles (4827 to 8045 Km)	Factory fill initial drain. Refill with Eaton Roadranger CD50 Transmission Fluid; thereafter follow maintenance intervals above.
Heavy Duty Engine Lubricant or Mineral Gear Lubricant	
HIGHWAY USE	
First 3,000 to 5,000 miles (4827 to 8045 Km)	Factory fill initial drain.
Every 10,000 miles (16090 Km)	Inspect lubricant level. Check for leaks.
Every 50,000 miles (80450 Km)	Change transmission lubricant.
OFF-HIGHWAY USE	
Every 30 hours	Change transmission lubricant on new units.
Every 40 hours	Inspect lubricant level. Check for leaks.
Every 500 hours	Change transmission fluid where severe dirt conditions exist.
Every 1,000 hours	Change transmission lubricant (Normal off-highway use.)

Change your transmission oil filter every time the fluid or lubricant is changed.

Change your transmission oil filter every time the fluid or lubricant is changed.

Recommended Lubricant

Type	Grade (SAE)	Fahrenheit Ambient Temperature
Eaton Roadranger CD50 Transmission Fluid	50	All
Heavy Duty Engine Oil MIL-L-2104B, C or D or API-SF or API-CD (Previous API Designations Acceptable)	50 40 30	Above 10 degrees F. Above 10 degrees F. Below 10 degrees F.
Mineral Gear Oil with rust and oxidation inhibitor API-GL-1	90 80W	Above 10 degrees F. Below 10 degrees F.

CAUTION: Do not use EP gear oil or multi-purpose gear oil. Additives and friction modifiers must not be introduced.

Proper Oil Level

Make sure oil is level with filler opening. Because you can reach oil with your finger does not mean oil is at proper level. (One inch of oil level is about one gallon of oil.)

Draining Oil

Drain transmission while oil is warm. To drain oil remove drain plug at case bottom. Clean the drain plug before re-installing.

Refilling

Clean case around filler plug and remove plug from case side. Fill the transmission to the level of the filler opening. If the transmission has two filler openings, fill to the level of both openings.

The exact amount of oil depends on the transmission inclination and model.

CAUTION: Do not over fill - this causes oil to be forced out of the case through the front bearing cover.

CAUTION: When adding oil, types and brands of oil should not be mixed because of possible incompatibility.



Improper Oil Level



Proper Oil Level



Service Brakes

Your Blue Bird Vision may be fitted with hydraulic disc brakes or air-powered drum type brakes, depending on the options chosen at the time of manufacture.

There is a different feel to the operation of hydraulic brakes versus air brakes; however, they perform the same task. Either system is designed and built to stop and hold the bus under the full range of driving conditions for which the Vision is intended to operate.

WARNING Hydraulic brakes are power assisted. The brakes will be noticeably less effective when the engine is not running. The bus should not be moved without the engine running.

The hydraulic brakes are arranged in a dual system, whereby the front brakes and the rear brakes operate independently of each other. The braking function will be greatly diminished by the loss of either the front or the rear brakes; however, it will be possible to stop the bus.

WARNING Do not operate the bus with the loss of either the front or the rear portion of the system. Stop the vehicle and obtain professional assistance immediately.

The hydraulic brake system includes an auxiliary electric pump that acts as a backup for the hydraulic pressure supplied by the power steering pump. With the engine not running and the key switch in the "ON" position, the electric pump will come on. This will provide some assistance in the brake system, but it will be much less effective than the power assist provided by the power steering pump.

WARNING Check the operation of this auxiliary pump before each trip. If it fails to come on when the key is turned to the "ON" position, before the engine starts do not operate the bus. Seek immediate professional assistance.

WARNING Inspect the level of the brake fluid in the reservoir on a regular basis. Too little fluid in the system will cause a malfunction. Be careful to put only brake fluid in the brake system and power steering fluid in the steering system.

Inspect the level of the brake fluid reservoir at least weekly; more often if there is reason to believe it is low. When the brake pedal depresses more than normal (goes closer to the floor) or when the pedal feels "mushy", check the reservoir level. If you need to add fluid (DOT-3) frequently, have the system checked out by a professional mechanic.

CAUTION Use only DOT-3 brake fluid in the brake system. Ensure that the fluid is put into the proper reservoir. The power steering fluid reservoir is located adjacent to the brake fluid reservoir. The brake fluid reservoir is mounted to the top of the brake master cylinder. The power steering reservoir is mounted to the firewall, adjacent to the brake master cylinder.

Parking Brake

Your Blue Bird Vision may be equipped with either hydraulic or air brakes. The two systems employ different kinds of parking brake mechanisms.

A Blue Bird Vision equipped with hydraulic brakes employs a hand-operated parking brakelever, located to the Driver's left. When the driver pulls this lever into the engaged position, a mechanical linkage causes a brake shoe assembly to close around the driveshaft, preventing the bus from moving. (It should be noted that this type parking brake becomes inoperative if the driveshaft is disconnected, as when the bus is being prepared for towing.) The mechanical parking brake must be kept adjusted properly for maximum holding power.

Adjust the cable linkage by turning the grip portion of the hand brake lever. The brake shoes should not engage the driveshaft when the brake is released; however, they should grip the driveshaft securely when the hand brake is engaged. When the parking brake is properly adjusted, the lever will snap firmly into place, and lever effort will be 120-125 pounds.

The parking brake should hold the fully loaded bus on a 20% incline on a dry paved surface. If the incline is wet or covered with ice or snow, do not park on it. The brake will hold, but the tires may not.

WARNING *Parking the bus on an incline of more than 20% will require the use of wheel chocks properly placed.*

On Blue Bird Visions equipped with air brakes, the parking brake function is provided by coil springs incorporated within the rear wheel brake actuation chambers. When the parking brake valve on the dash is pulled outward, air pressure is vented from the rear brake actuators, allowing the springs to engage the rear brakes and locking the rear wheels. When the parking brake valve is pushed in, it allows the air pressure in the rear brake actuators to overcome the spring pressure, thereby releasing the rear spring brakes.

In the air brake system, if the air compressor becomes inoperative, low air pressure may cause the rear brakes to engage and lock. If this happens, the Driver should call for professional help. If the bus must be moved, it is possible to release the rear brake chambers with a tool designed for the purpose. This tool is stowed in a tubular housing located on the side of the rear air chamber housings.

WARNING *Never attempt to release the spring brake until the wheels have been chocked in both directions. The bus will begin to move as the spring brakes are released, depending on the incline of the parking space.*

To release the spring brake manually:

1. Chock the wheel in both directions.
2. Remove the spring brake release stud from the stowage pocket on the side of the air chamber.





3. Run the hex nut of the release stud as far up the threads as necessary to insert the tang end into the spring brake chamber.
4. Clean the end of the spring brake chamber.
5. Remove the plastic plug in the end of the spring brake chamber.
6. Insert the tang end of the release stud into the spring brake chamber.
7. Turn the release stud 1/4-turn to the right (clockwise).

WARNING Ensure the wheels are chocked in both directions, before releasing the spring brake manually. The bus will move without restraint and could result in serious injury or death.

- B. Using a wrench of the proper size, tighten the hexnut on the release stud until the brake releases.


Ensure that the release stud is removed from the air chamber and stowed properly before placing the bus back in service.

If your bus is air brake equipped, it is necessary to maintain the air storage tanks and the drain valve for continued safe operation.

To drain the air tanks, turn the petcock located on the tank to allow the air pressure and water to escape the tank. This procedure should be performed daily.

WARNING Do not move the bus until the air system is pressurized.

If your air system is fitted with a dryer, there should be little, if any, moisture in the tanks. However, it should be checked.



Schrader Valve

The air brake system is fitted with a Schrader valve to assist in maneuvering the bus when the engine isn't running. The Schrader valve is located on the wet tank. Using this valve will allow the system to be pressurized with any standard air hose, such as those designed to pressurize tires.



Door/Brake Interlock

The Door/Brake Interlock system is designed to prevent the vehicle from moving while a door is open. The Interlock causes the throttle to be inoperative, and locks the brake system when any of the vehicle doors are open. The Interlock also works in concert with the wheelchair lift. The lift must be properly stored and locked before the Interlock will permit the bus to move. A momentary disable switch is provided for special circumstances when the vehicle must be moved with a door open.

Towing or Pushing

The Vision should not be pushed or towed any more than enough to free the vehicle from mud or snow. Optional tow hooks are located at the front and/or rear of the vehicle under the bumper. Tow hooks are designed to tow or pull with both hooks simultaneously.

CAUTION Do not pull or tow with an individual hook. Blue Bird does not recommend towing or jacking the vehicle by the bumpers.

When towing more than a few feet, always disconnect the drive shaft or lift the rear wheels off the ground. When uncoupling the drive shaft on a vehicle equipped with hydraulic brakes, the emergency or park (hand) brake becomes inoperative. Never leave the bus in this condition without securely blocking the wheels in both directions.



Maintenance Charts

The following charts show recommended maintenance and service intervals. More frequent service intervals should be considered if the vehicle is operated in extreme conditions such as high humidity and/or dusty environments.

Body Components

INTERVALS MONTHS/1000 MILES								
	whichever occurs first							
OPERATION	1/3,000	3/5,000	3/24,000	6/6,000	6/10,000	12/12,000	12/24,000	24/24,000
NOTE								
Outward Opening Door								
Adjust door linkage	as required						Adjust linkage for proper door operation.	
Jackknife Door								
Adjust door control rod				*				
Adjust roller bracket	*							Adjust for ease of operation.
Adjust control rod bracket	*							Adjust to prevent pivot pin from binding.
Lubricate hinge pins	*							Use LPS number 1.™
Power Jackknife Door								
Lubricate hinge pins	*							Use Apply.™
Adjust pneumatic pressure	*							Refer to Service Manual, Doors section.
Adjust the switch	*							Refer to Service Manual, Doors section.
Window								
Lubricate latches and slides	*							Use silicone lubricant.
Pneumatic Stop Gun								
Adjust	as required						Adjust for full deployment and retraction.	
Electric Strap Gun								
Lubricate	*							Lubricate 4-point pivot with Dry-Flo.™
Tighten fasteners	*							Check interior and exterior fasteners for loosening.
Window Locks								
Lubricate entrance door lock				*				Use Apply.™
Lubricate key lock		*						Use Apply.™
Lubricate sliding bolt lock		*						Use LPS number 1.™
Exterior Body								
Wash exterior	as required to prevent oxidation							
Emergency Exit								
Lubricate roof latch	*							Use silicone lubricant.
Lubricate door hinges				*				Use LPS number 1.™
Lubricate hold-open hinges	*							Apply ASTM D4950 GC-1B Grade 2.
Emergency Equipment Brackets								
Inspect, tighten mountings								Ensure all fasteners and brackets are secure.
Heaters & Defrosters								
Check interior hose connections					*			Inspect for leaks and deterioration.
Check filters and covers					*			Clean dust from covers and replace filters.
Check fasteners					*			Inspect for loosening and tighten as necessary.

Chassis Components

INTERVAL: MONTHS/1000 MILES

whichever occurs first

OPERATION	000'E/L	000'S/E	000'Y/S	000'Y/S	000'Y/S	12/12,000	000'Y/S	12/24,000	000'Y/S	NOTES
Charging System										
Check battery electrolyte level	•									Replenish with distilled water
Inspect battery posts				•						Clean as often as necessary. Apply corrosion retarder.
Inspect alternator				•						Inspect for loose wires, cracked or missing insulator hoses, etc.
Exhaust System										
Inspect piping & joints				•						Check for loose clamps, leaks, damage. Repair immediately.
Transmission										
Check fluid level	Check daily, following Allison recommendations									Use Transynd™ fluid.
Change main filter								•		Inspect for signs of leakage or damage.
Change pump filter								•		Change after first 5000 mi (8000 km) & at interval thereafter.
Inspect vent								•		
Inspect shift cable								•		
Adjust shift cable	as required									See Service Manual for details.
Driveline										
Inspect driveline		•								See Service Manual for details.
Check torque on cap screws		•								
Steering										
Lubricate steering column					•					Follow Hendrickson recommendations.
Lube intermediate steering shaft					•					
Lubricate king pins					•					
Lubricate tie rod ends					•					
Lubricate drag link					•					
Lubricate shock absorber					•					
Lubricate cam brake housing					•					
Lubricate steering gear					•					Use HLG# Number 2 EP or grease rated GC-LB. Use hand-operated grease gun only.
Check fluid level					•					Frequent low levels indicate repair is needed.
Change reservoir filter						•				More frequently in severe operating conditions.
Inspect hydraulic pump						•				
Inspect steering gear						•				If leaks are indicated, repair immediately.
Air Intake System										
Check air restriction indicator	Check daily									Replace filter element if indicator is red (25 inches H ₂ O).
Inspect intake duct & elbow		•								
Tighten clamps & fasteners		•								See Service Manual for appropriate torque values.
Inspect support bracket		•								
Inspect charged air cooler		•								
Inspect air dryer element		•								Check that element is properly seated and cover is secure.
Replace air dryer element								•		More frequently, if indicated by operating conditions



Brakes

INTERVALS MONTHS/1000 MILES

whichever occurs first

OPERATION	1/3,000	3/3,000	3/24,000	6/6,000	6/10,000	12/12,000	12/24,000	24/24,000	NOTES
Air Brakes									
Replace compressor filters				•					
Clean governor				•					
Inspect air dryer			•						See Bendix® AD-10 Handbook.
Drain air tanks	daily in cold weather; weekly in warm weather								Drain condensation.
Check, clean pop-off valves							•		See the appropriate Bendix® publications for details.
Inspect check valves				•					
Clean, lube treadle valve				•					
Clean relay valves								•	
Clean spring brake valve								•	
Clean parking brake valve								•	
Clean quick-release valve								•	
Inspect brake chambers	•								
Air Brake Wheel Ends									
Inspect, adjust shoes	weekly or as needed in severe applications								Refer to Meritor™ Maintenance Manual 4
Lubricate S-Cam		•							
Lubricate slack adjusters		•							
Inspect linings & fittings	•								
Hydraulic Brakes									
Check fluid level	•								Use DOT-3 brake fluid.
Inspect booster & master cylinder			•						Inspect for signs of leakage or damage.
Adjust park brake lever				•					Adjust engagement pressure at the lever to 120-125 lbs.
Hydraulic Disc Wheel Ends									
Inspect callipers				•					Inspect for signs of leakage or damage.
Lubricate callipers		•							See Meritor documentation.
Check pad thickness	weekly or as needed in severe applications								Minimum 1/8 inch (3.175 mm).

Hendrickson Front Axle & Suspension

INTERVAL:
Miles/Kilometers
whichever
occurs first

First 1000 miles	6 / 6,000	12 / 12,000
------------------	-----------	-------------

OPERATION

NOTES

Front Suspension			
Inspect visually		*	Check for visual damage. See Hendrickson publication 17730-248.
Check U-bolt torque	*		Tighten to 285-305 ft. lbs. (32-34 Nm).
Lubricate steering grease fittings		*	Use NLGI #2 EP or equivalent.
Inspect spring pin lock bolts		*	Tighten to 380-420 ft. lbs. (515-569 Nm).
Inspect shackle bracket pivot bolt		*	Tighten to 380-420 ft. lbs. (515-569 Nm).
Inspect shocks		*	Check for signs of leaks, wear, or damage.
Torque shock mounting bolts		*	Tighten to 215 ft. lbs. (25 Nm).
Air Suspension			
Inspect visually		*	Check for wear, damage, misalignment. See Hendrickson publication 17730-248.
Check axle to suspension fasteners	*		Tighten to 285-305 ft. lbs. (32-34 Nm).
Lubricate steering grease fittings		*	Use NLGI #2 EP or equivalent. Lubricate with suspension loaded.
Inspect pin lock bolts		*	Tighten to 380-420 ft. lbs. (515-569 Nm).
Inspect shackle bracket pivot bolt		*	Tighten to 380-420 ft. lbs. (515-569 Nm).
Torque shock mounting bolts		*	Tighten to 215 ft. lbs. (25 Nm).
Inspect air spring cushions		*	Check for wear, abrasion, cuts, or other damage.
Check air spring fasteners		*	
Inspect shocks		*	Check for signs of leaks, wear, or damage.
Check suspension height	*		Shock length, eye to eye: 18.5" ± .25" (470 ± 6 mm).
Check ride height control valve bolts	*		Tighten to 8-10 ft. lbs. (11-14 Nm).



Rear Axle & Suspension

INTERVAL:
Miles/1000 Miles
whichever occurs first

OPERATION	first 1000 miles	1/10,000	5/6,000	5/10,000	12/12,000	12/24,000	NOTES
Rear Axle							
Check lubricant		*					See Monitor RS21145 Maintenance Manual SA, Lubrication Manual 1.
Change lubricant						*	
Spring Suspension							
Inspect visually			*				
Check rebound pins					*		Verify that cotter pins are installed.
Torque spring radius fasteners					*		Tighten locknuts to 100–125 ft. lbs. (11–14 Nm).
Torque shock mounting bolts					*		Tighten locknuts to 75–100 ft. lbs. (9–11 Nm).
Torque U-bolt fasteners					*		Torque U-bolts to 300–350 ft. lbs. (34–39 Nm).
Air Suspension							
Inspect visually			*				Check for wear, damage, loose or missing parts.
Torque upper shock mount				*			Tighten to 50–70 ft. lbs. (68–95 Nm)
Torque lower shock mount				*			Tighten to 150–180 ft. lbs. (203–244 Nm)
Check ride height	*		*				Shock length, eye to eye: 22.68" ± .25" (576 ± 6 mm)
Check U-bolts 7/8–14 UNF 2B	*			*			Tighten to 400–450 ft. lbs. (542–610 Nm)
Check U-bolts 3/4–16 UNF 2B	*			*			Tighten to 260–320 ft. lbs. (353–434 Nm)
Torque lower shock mount to spring				*			Tighten to 260–320 ft. lbs. (353–434 Nm)
Torque air spring anchor bolts				*			Tighten to 20–30 ft. lbs. (27–41 Nm)
Torque spick align bolts				*			Tighten to 525–575 ft. lbs. (712–800 Nm)
Torque lever linkage locknut				*			Tighten to 100–150 ft. lbs. (11–17 Nm)
Torque leveling valve mount bolt				*			Tighten to 60–85 ft. lbs. (7–10 Nm)

Cooling System

INTERVAL:
Months/1000 Miles
whichever occurs first

OPERATION					NOTES
	Daily	3 / 1,000	36 / 100,000	72 / 600,000	
Coolant					
Check fluid level	*				Also check coolant level whenever engine runs hotter than normal. Repair any leaks immediately. Use only approved coolant. See Caterpillar® Operations and Maintenance Manual SEBU7011-11 or LE8T2835, as appropriate.
Add coolant	as required				
Add inhibitor			*		Use only approved coolant. See Caterpillar publications referenced above.
Change coolant				*	Use Caterpillar ELC or equivalent. See Caterpillar publications referenced above.
Pumps & Clamps					
Inspect		*			Inspect for leaks or deterioration. Tighten radiator hoses to 30 in. lbs (10 Nm) and heater hose clamps to 45 in. lbs (5 Nm).



Maintenance Interval Schedule (Engines with a Shallow Oil Sump)

Ensure that the Safety Information, warnings and Instructions are read and understood before operation or maintenance procedures are performed.

Use distance (odometer), fuel consumption, service hours, or calendar time (whichever occurs first), in order to determine the maintenance intervals. Engines that operate in severe operating conditions may require more frequent maintenance.

Before each consecutive Interval is performed, all of the maintenance requirements from the previous Interval must also be performed.

When Required

Air Dryer — Check

Battery — Replace

Battery or Battery Cable — Disconnect

Engine Storage Procedure — Check

Fuel System — Prime

Severe Service Application — Check

Daily

Cooling System Coolant Level — Check

Engine Air Cleaner Service Indicator — Inspect

Engine Oil Level — Check

Fuel System Water Separator — Drain

Walk-Around Inspection

Initial 17,700 km (11,000 miles) or 4150 L (1,100 US gallons) of Fuel or 250 Service Hours or 6 Months

Engine Valve Lash — Inspect/Adjust

**PM Level 1 — Every 11,000 miles (17,700 km) or 1,100 US gallons (4150 L)
of Fuel or 250 Service Hours or 6 Months**

Aftercooler Core — Inspect

Air Compressor Filter — Clean/Replace

Battery Electrolyte Level — Check

Belt — Inspect

Cooling System Supplemental Coolant Additive (SCA) — Test/Add

Cylinder Head Grounding Stud — Inspect/Clean/Tighten

Engine Crankcase Breather — Clean

Engine Oil Sample — Obtain

Engine Oil and Filter — Change

Fan Drive Bearing — Lubricate

Fuel Inlet Screen — Clean/Inspect/Replace

Fuel System Primary Filter — Replace

Fuel System Secondary Filter — Replace

Fuel Tank Water and Sediment — Drain

Hoses and Clamps — Inspect/Tighten/Replace

Radiator — Clean



PM Level 2 — Every 100,000 miles (161,000 km) or 15,000 US gallons (56,850 L) of Fuel or 2000 Service Hours or 2 Years

Aftercooler Core — Clean/Test

Air Compressor — Inspect

Alternator — Inspect

Belt Tensioner — Inspect

Cooling System Water Temperature Regulator — Replace

Crankshaft Vibration Damper — Inspect

Engine — Clean

Engine Mounts — Inspect

Engine Valve Lash — Inspect/Adjust

Starting Motor — Inspect

Turbocharger — Inspect

Water Pump — Inspect

Every 3 Years or 322,000 km (200,000 miles)

Cooling System Coolant (DEAC) — Change

Every 483,000 km (300,000 miles)

Cooling System Coolant Extender (ELC) — Add

Every 6 Years or 566,000 km (350,000 miles)

Cooling System Coolant (DEAC) — Change

Cooling System Coolant (ELC) — Change

Every 114,000 L (30,000 US gallons) of Fuel

Overhaul Considerations