


TECHNICAL INSTRUCTIONS
FOR
CAMPAIGN G0C
CENTER AIRBAG SENSOR ASSEMBLY (SRS ECU)
CERTAIN 2005 – 2006 MY SEQUOIA

The repair quality of covered vehicles is extremely important to Toyota. All dealership technicians performing this repair are required to successfully complete the most current version of the E-Learning course “Safety Recall and Service Campaign Essentials”. To ensure that all vehicles have the repair performed correctly; technicians performing this repair are required to currently hold at least one of the following certification levels:

- Toyota Expert Electrical
- Master Technician
- Master Diagnostic Technician

Always check which technicians can perform the recall remedy by logging on to <https://www.uotdealerreports.com>. It is the dealership’s responsibility to select technicians with the above certification level or greater to perform this repair. Carefully review your resources, the technician skill level, and ability before assigning technicians to this repair. It is important to consider technician days off and vacation schedules to ensure there are properly trained technicians available to perform this repair at all times.

I. OPERATION FLOW CHART



II. IDENTIFICATION OF AFFECTED VEHICLES

- Check the TIS Vehicle Inquiry System to confirm the VIN is involved in this SSC and that the campaign has not already been completed prior to dealer shipment or by another dealer.
- TMS warranty will not reimburse dealers for repairs conducted on vehicles that are not affected or were completed by another dealer.

III. PREPARATION

A. PARTS

Part Number	Part Description	Quantity
04006-2330C	Airbag Sensor Assy	1


NOTE: Not all listed parts are needed for the each vehicle. To determine which part number to order, input the VIN into the following website: <https://g0c-glb-parts-lookup.imagespm.info/>. Default password is xxxxx.

B. TOOLS & EQUIPMENT

- Techstream
- Molding Remover Set
- Torque Wrench
- Standard Hand Tools

IV. BACKGROUND

The subject vehicles are equipped with side Curtain-Shield-Airbags (CSAs) which deploy from the roof rails in the event of certain types of crashes. Due to improper programming in the airbag control module, there is a possibility that, under certain specific and limited conditions shortly after vehicle startup, the CSAs and seat belt pretensioners could activate when not necessary. Unexpected activation of the CSAs could increase the risk of injury to the occupant.



K1500260064a


V. SAFETY PRECAUTIONS

STOP

CRITICAL INFORMATION – READ THOROUGHLY

STOP


Failure to follow these procedures correctly could cause the SRS to unexpectedly deploy during servicing or the SRS may fail to operate correctly when required after reassembly. Confirm all work is performed safely as described in the following Technical Instructions.



1. DISCONNECT THE BATTERY TERMINAL

STOP

- Always disconnect the negative terminal and wait 90 seconds before performing work to prevent airbag and seatbelt pre-tensioner deployment due to back-up battery supply.



2. ELIMINATE STATIC ELECTRICITY

- a) Before removing ECU ground yourself by touching a metallic part of the vehicle.



3. DO NOT DROP THE CENTER AIRBAG SENSOR

VI. REPLACING THE CENTER AIRBAG SENSOR (SRS ECU)

1. PERFORM HEALTH CHECK

- a) Check to verify if there any air bag DTC's present (current, history, or pending).



This campaign only covers the replacement of the Airbag Sensor Assembly (SRS ECU). No further components in the SRS system are covered by this campaign.


2. RECORD AND DOCUMENT CUSTOMERS VEHICLE SETTINGS

3. DISCONNECT THE NEGATIVE BATTERY TERMINAL




- Wait at least 90 seconds after disconnecting the cable from the negative battery terminal to prevent airbag and seat belt pre-tensioner deployment.
- Follow all precautions as outlined on TIS before servicing the SRS system.

4. COMPONENTS INVOLVED IN THE REMOVAL OF THE CENTER AIRBAG SENSOR (SRS ECU)




N*m (kgf*cm, ft.*lbf) : Specified torque



5. REMOVE THE SHIFT LEVER KNOB


- a) Twist the shift lever knob in the direction indicated by the arrow and remove it.



6. REMOVE SHIFTING HOLE COVER


- a) Using a screwdriver, disengage the 4 clips and remove the shifting hole cover.

NOTE: Tape the screwdriver tip before use.




7. REMOVE UPPER CONSOLE PANEL

- a) Detach the 12 clips and remove the console panel.




8. REMOVE REAR CONSOLE TERMINAL (W/ rear A/C or heater)

- a) Using a tapered tip screw driver, remove the rear heater control panel or headphone terminal,
- b) Disconnect the connector.




9. REMOVE REAR CONSOLE BOX

- a) Remove the 4 bolts and rear console rear box
- b) With rear seat entertainment:
 - 1) Remove the disc bracket.
 - 2) Remove the 3 bolts and disc player.
 - 3) Disconnect the connector.
 - 4) Remove the 4 bolts and rear console box.



10. REMOVE FRONT CONSOLE BOX

- a) Detach the 2 clamps.
- b) Remove the 2 clips.
- c) Remove the 5 screws and the front console box.




11. REMOVE THE CENTER AIRBAG SENSOR



• Confirm that the negative battery terminal is disconnected before performing the operation. Even an impact to only the airbag sensor will cause the airbag to deploy.

- a) Pull the lever and detach the connector holder.
- b) Remove the 3 bolts and remove the airbag sensor

VII. INSTALLATION OF THE NEW CENTER AIRBAG SENSOR




1. INSTALL THE NEW CENTER AIRBAG SENSOR

- a) Check that the ignition switch to the LOCK position.
- b) Install the center airbag sensor with the 4 bolts.
- c) Tighten the 3 bolts to the specified torque.

Torque:


17.5 N•m {179 kgf•cm, 13ft•lbf}

- d) Connect the holder (with connectors) to the center airbag sensor.
- e) Check that the waterproof sheet is properly set.




2. REINSTALL FRONT CONSOLE BOX

- a) Attach the 2 clamps.
- b) Attach the 2 clips.
- c) Reinstall the 5 screws and the front console box




3. REINSTALL REAR CONSOLE BOX

- a) Reinstall the 4 bolts and rear console box
- b) With rear seat entertainment:
 - 1) Reinstall the disc bracket.
 - 2) Reconnect the connector.
 - 3) Reinstall the 3 bolts and disc player.
 - 4) Reinstall the 4 bolts and rear console box.




4. REINSTALL REAR CONSOLE TERMINAL (W/ rear A/C or heater)

- a) Re-connect the connector, then Reinstall the rear heater control panel or headphone terminal.




5. REINSTALL UPPER CONSOLE PANEL

- a) Attach the 12 clips and reinstall the console panel.



6. REINSTALL SHIFTING HOLE COVER


- a) Engage the 4 clips and reinstall the shifting hole cover.



7. REINSTALL SHIFT LEVER KNOB

- a) Reinstall the shift lever knob and twist it in the direction indicated by the arrow.

8. RECONNECT THE NEGATIVE BATTERY TERMINAL AND PERFORM ANY NEEDED INITIALIZATIONS



9. INSPECT SRS WARNING LIGHT

- a) Turn the ignition switch to the ON position, and check that the SRS warning light comes on for approximately 6 seconds (primary check).
- b) Check that the SRS warning light goes off approximately 6 seconds after the ignition switch is turned to the ON position (constant check).


◀ VERIFY REPAIR QUALITY ▶

- Confirm all precautions are followed to ensure safety during repair.

If you have any questions regarding this repair, please contact your area representative.

VIII. APPENDIX

A. CAMPAIGN DESIGNATION DECODER



B. CAMPAIGN PARTS DISPOSAL

As required by Federal Regulations, please make sure all campaign parts (original parts) removed from the vehicle are disposed of in a manner in which they will not be reused, ***unless requested for parts recovery return.***