TO: Mercedes-Benz Dealer Principals, General Managers, Sales Managers, Service Managers, Parts Managers	FROM: Anthony Washington, Senior Manager, Regulations and Certifications
Re: Launch Recall Campaign Notification Model: Metris (447) Model Years: 2017-2019 Tire and Tire Loading Information Label (wave 1)	DATE: April, 2024



IMPORTANT RECALL CAMPAIGN INFORMATION

Please see the attached documents related to the campaign listed above.

THERE IS NO REIMBURSEMENT AVAILABLE FOR THIS RECALL AS ALL AFFECTED VEHICLES MAY BE ELIGIBLE FOR A NEW SET OF TIRES

Mercedes-Benz USA, LLC

A Mercedes-Benz Group AG Company One Mercedes-Benz Drive Sandy Springs, GA 30328 770.705.0600



News Channel Update | Vans Customer Service and Parts

Campaign No. :	Campaign	Desc. :	Tire and Tire Loading Information Label	
2024020016	VS2LAS	STRE	Wave 1	
This is to notify you of a Recall Campaign launch concerning the tire and tire loading information label on approximately 2,000 MY 2017-2019 Metris Vans. The recall campaign will be visible on the <u>www.safercar.gov</u> website and may generate questions from customers. All affected VINs will be flagged as "OPEN" in VMI and cannot be sold until remedied.				
			Background	
lssue	Issue Mercedes-Benz AG ("MBAG"), the manufacturer of Mercedes-Benz vans, has determined that on certain Mercedes-Benz Metris vehicles (Platform 447), the sum of the maximum load ratings of the tires may exceed the permissible maximum axle load rating pursuant to FMVSS 110, S4.2.2.2. Overloading over time could cause excessive tire wear and in a worst case scenario, could lead to tire failure, increasing the risk of a crash.			
What We're Doing	 MBUSA is conducting a voluntary recall. An authorized Mercedes-Benz Metris dealer will replace the tires and tire loading information label on the B-pillar and fuel filler door. Dealers will also check the tires on the vehicle to verify that they are the correctly specified tires. If the tires on the vehicle are of a lower rating than what is specified in the Operator's Manual, the tires will be replaced with new tires having the specified load rating. This repair will be done free of charge. 			
Parts	Parts are avai	lable and ca	n be ordered as necessary.	
			Vehicles Affected	
Vehicle Model Year(s)	2017-2019			
Vehicle Model	Metris			
			Vehicle Populations	
Population	2,000			
Dealer Inventory	0			
Given this notice, it is <u>a violation of Federal law</u> for a dealer to sell or lease any <u>new</u> vehicles in dealer inventory covered by this notification until the vehicle has been repaired.				
			continue to be driven, but must not be retailed until repaired. <u>al Law</u> for rental companies to rent vehicles covered by this notification until	
		the v	vehicle has been repaired.	
		N	lext Steps/Notes	
Customer Notification	Timeline	An owner no	tification letter to be mailed in late April, 2024	
AOMS/SOMS	AOMs – This recall may generate questions from your dealers. Please forward this notice			
Rental Fleet Partners This recall may affect vehicles in your fleet. Please contact your respective MBUSA fleet representative for further information and next steps. For repairs, please contact your preferred MBUSA dealer.		e for further information and next steps. For repairs, please contact your		
While we regret any inconvenience this may cause, we are determined to maintain a high level of vehicle quality and customer satisfaction.				

A Mercedes-Benz Group AG Company One Mercedes-Benz Drive Sandy Springs, GA 30328 770.705.0600



Model 447.603/605/703 #3 as of 000527 up to 535373 with engine 274 with code MM1 (Engine M274 DEH 20 LA 155 kW (211 hp) 5500 rpm) with code XA6 (Weight variant 3.05 t) with code ZU7 (National version for Canada)
Model 447.603/605/703 #3 as of 000527 up to 535373 with engine 274 with code MM1 (Engine M274 DEH 20 LA 155 kW (211 hp) 5500 rpm) with code XA6 (Weight variant 3.05 t) with code ZU8 (National version for USA)

Operation no. of the operation texts or standard texts and flat rates

Category	Op. no.	Operation text	Time	Damage Code	Codeword
Ρ	02 0108	Operations: Replace tire. Includes: Replace tire pressure specification information label on fuel filler flap and tire pressure specification adhesive label on left B-pillar, and insert supplementary booklet for operator's manual into operator's manual and enclose in glove compartment	1.9 h	40 922 12	VS2LASTRE
Ρ	02 0109	Operations: Extra work for replacing tire on veh. with spare wheel or emergency spare wheel. Includes: Attach adhesive label for maximum permissible speed on rim of spare wheel or emergency spare wheel	0.6 h	40 922 12	VS2LASTRE
Р	02 0221	Operations: Extra work for replacing tire on veh. with tire pressure loss warning system	0.3 h	40 922 12	VS2LASTRE

- 1 Information label on tire pressure specification
- 2 Fuel filler flap
- 3 Adhesive label for tire pressure specification
- 4 Left B-pillar



S40.10-A001-76

Notice	Notes on carrying out repair work in the vehicle interior		AH68.00-D-0001-01KOS
4	Check		
1	Check if vehicle is affected by measure.		
X	Remove		
2	Remove spare wheel or emergency spare wheel.	Model 447 with code RR6 (Spare wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For removal of spare wheel and emergency spare wheel, see operator's manual.	

	Replace		
3	Replace tire of spare wheel or emergency spare wheel.	Model 447 with code RR6 (Spare wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall)	
AR		 i For the new tire required for the spare wheel or emergency spare wheel, it is essential to take into account the information in the parts ordering note below regarding the size, the tire make and the tire model as well as the load capacity and maximum speed index. The spare wheel tire or emergency spare wheel tire specified in the parts ordering note table below is not available from Mercedes-Benz. The spare wheel tire or emergency spare wheel tire with the specifications shown must be ordered on the open market (e.g. from a local tire dealer). i The spare wheel and emergency spare wheel are never equipped with a tire pressure sensor. i Dispose of removed tires, valves, balance weights, etc. properly. Observe the applicable legal requirements and specifications of 	AR40.10-S-1030E
4	Attach adhesive label indicating maximum permissible speed to rim of spare wheel or emergency spare wheel.	the relevant country. Model 447 with code RR6 (Spare wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) () The bonding area on the rim of the spare wheel and emergency spare wheel must be absolutely free of	
		wheel must be absolutely nee of dust and grease. Otherwise, there may be adhesion problems. i When ordering, ensure that the correct adhesive label (mph or km/h) is ordered for the respective country. For this, see the part ordering note table below.	

5	Replace all running tires.		
₩ĨAR			AR40.10-S-1030E
		 i For the new running tires required, it is essential to take into account the information in the parts ordering note below on the size, the tire make, the tire model and the load capacity and maximum speed index. The running tires specified in the parts ordering note table below are not available from Mercedes-Benz. These running tires with the specifications shown must be ordered on the open market (e.g. from a tire dealer nearby). i Dispose of removed tires, valves, balance weights, etc. properly. Observe the applicable legal requirements and specifications of the relevant country. 	
6	Replace information label for tire pressure specification (1) on fuel filler flap (2).	 The bonding area on the fuel filler flap (2) must be absolutely free of dust and grease. Otherwise, there may be adhesion problems. I To do so, remove old information label for tire pressure specification (1) using a suitable tool and remove adhesive residue with a suitable cleaning agent. Attach new information label for tire pressure specification (1) to same position. Dispose of old, removed information label for tire pressure specification (1) properly. Observe the applicable legal requirements and specifications of the relevant country. 	

-			
7	Replace adhesive label for tire		
	pressure specification (3) on left B-	The bonding area on the left B-	
	pillar (4).	pillar (4) must be absolutely free of dust and grease.	
		Otherwise, there may be adhesion	
		problems.	
		i	
		To do so, remove old adhesive	
		label for tire pressure specification	
		(3) using a suitable tool and remove adhesive residue with a	
		suitable cleaning agent.	
		Attach new adhesive label for tire	
		pressure specification (3) to same position.	
		ī	
		Dispose of old, removed adhesive	
		label for tire pressure specification	
		(3) properly. Observe the	
		applicable legal requirements and	
		specifications of the relevant	
		country.	
X	Install		
8	Install spare wheel or emergency	Model 447 with code RR6 (Spare	
	Install spare wheel or emergency spare wheel.	wheel with jack), Model 447 with	
		wheel with jack), Model 447 with code RR8 (Inner spare wheel	
		wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall)	
		wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i	
		wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and	
		wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i	
		wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see	
	spare wheel.	wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see	
8	spare wheel.	wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual.	AD00.00-S-2000-04E
8 9	spare wheel.	wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. Always use the latest XENTRY	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. Always use the latest XENTRY Diagnosis software release with all	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. I Always use the latest XENTRY Diagnosis software release with all available add-ons.	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. i Always use the latest XENTRY Diagnosis software release with all available add-ons. i 	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. Always use the latest XENTRY Diagnosis software release with all available add-ons. i It is absolutely essential to 	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. i Always use the latest XENTRY Diagnosis software release with all available add-ons. i 	AD00.00-S-2000-04E
8 9	spare wheel.	 wheel with jack), Model 447 with code RR8 (Inner spare wheel carrier to side wall) i For installation of spare wheel and emergency spare wheel, see operator's manual. Always use the latest XENTRY Diagnosis software release with all available add-ons. i It is absolutely essential to precisely follow the operation steps 	AD00.00-S-2000-04E

	Initialization		
10	Initialization Reinitialize tire pressure sensors using vehicle diagnosis system.	Model 447 with code RY2 (Tire pressure loss warning system at front axle and rear axle, wireless) i To do this, select the following menu items: Quick test view \rightarrow N88/1 - Tire pressure monitoring system (TPM) (code: RY2) \rightarrow Adaptations \rightarrow Teach-in processes \rightarrow Write identification numbers of tire pressure sensors. i Follow instructions in XENTRY	
		Diagnosis.	
	Carry out variant coding		
11	Perform process for variant coding of tire size using XENTRY Diagnosis.	To do this, select the following menu items: Special functions → Variant coding of tire size i Follow instructions in XENTRY	
		Diagnosis.	
	Remove		
12	Remove vehicle diagnosis system from vehicle.		
	Enclose		
13	Insert supplementary booklet for operator's manual into operator's manual and insert in glove compartment.	i The supplementary booklet is part of the printed METRIS operator's manual. Please advise your customer of this situation.	

Parts ordering note

Part no.	Designation	Quantity
A 000 400 54 13	Tire valve (running tires) (without code RY2)	n. B. (4)
A 000 400 54 13	Tire valve (spare wheel and emergency spare wheel) (only on vehicles with code RR6 or RR8)	
A 447 905 93 01	Repair kit for tire pressure sensor (with code RY2)	n. B. (4)
A 170 584 00 38	Adhesive label indicating maximum permissible speed in mph (50 mph (with code ZU8)) on rim of spare wheel and emergency spare wheel (only on vehicles with code RR6 or RR8)	n. B. (1)
A 170 584 02 38	Adhesive label indicating maximum permissible speed in km/h (80 km/h (with code ZU7)) on rim of spare wheel and emergency spare wheel (only on vehicles with code RR6 or RR8)	n. B. (1)
RUNNING TIRE	Tires (running tires) 235/55R17XL 103H Continental VanContact A/S (all-season tires) the running tires must be ordered on the open market (e.g. dealer tire)	4
SPARE TIRE	Tires (spare wheel and emergency spare wheel) 225/55R17C 109/107H (104H) Goodyear Vector4SeasonsCargo (all-season tire) (only on vehicles with code RR6 or RR8) the tire of the spare wheel and emergency spare wheel must be ordered on the open market (e.g. dealer tire)	1
A 447 584 08 06*	Information label for tire pressure specification on fuel filler flap (please quote vehicle identification number when ordering)	1
A 906 584 66 38 26*	Adhesive label for tire pressure specification on left B-pillar (please quote vehicle identification number when ordering)	1
A 447 584 46 12	Supplementary booklet for operator's manual (bilingual, English and French)	1
KG40	Balance weight	n. B.
	Additional replacement part scopes, small parts and consumable materials required for carrying out this service measure must be replaced in accordance with the information in the repair documents referenced in this document. These must be determined according to the vehicle identification number (FIN) via the "XENTRY Parts Information" system and, whilst not listed in the parts ordering note, they are included in the costing.	

*The labels will be printed and shipped by GSP in Germany. It may take several days for delivery.

Plan to order the labels in advance when workshop visit appointment is set up to reduce unnecessary waiting time for customer