

## TECHNICAL INSTRUCTIONS

FOR

SAFETY RECALL 24LA04

ENGINE MAY STALL DURING DRIVING

CERTAIN MODEL YEAR 2022 - 2023 LX 600

**Updated**

**02.21.2025 – Updated Oil Quantity and Engine Oil Level Step**

**02.28.2025 – Revised Catalytic Converter Removal/Installation Process**

**03.13.2025 – Updated Engine Hoist Height Adjustment Note, Added Damaged Engine Flow Chart and Added Wiper Cowl Removal/Installation Steps**


The repair quality of covered vehicles is extremely important to Lexus. All dealership technicians performing this recall are required to successfully complete the most current version of the E-Learning course “Safety Recall and Service Campaign Essentials”. To ensure that all vehicles have the repair performed correctly; technicians performing this repair are required to currently have completed the following courses:

- LIC201A Engine Repair
- TES001 V35A-FTS
- LER024A- 24LA04 Engine Replacement Process and Best Practices

Always check which technicians can perform the repair by logging on to <https://lexuscertification.com/certlogin.jsp>. It is the dealership’s responsibility to select technicians that have completed the above courses to perform this repair. Carefully review your resources, the technician’s skill level, and ability before assigning technicians to this repair. It is important to consider technician days off and vacation schedules to ensure there are properly trained technicians available to perform this repair at all times.

## I. DAMAGED ENGINE SHIPMENT FLOW CHART

The flow chart is for reference only. Follow TAS case creation process below to ensure concern is resolved quickly.



## 1. Case Type

- a. Select "Documentation Only" for TAS Case Creation
- b. Enter VIN
- c. Enter Repair Order Date
- d. Enter Repair Order
- e. Enter Odometer
- f. Confirm Miles/KM
- g. Enter Visits for Concern
- h. Enter Customer Type
- i. Select "Save and Continue"

TAS - Technical Assistance System

**Case Type** ⓘ

Technical  Documentation Only  Collision Center  Parts Release

*Select "Documentation Only"*

**Vehicle Information**

|   |  |                                    |                                      |
|---|--|------------------------------------|--------------------------------------|
| <b>VIN *Required</b>                        | <b>Year</b>                                  | <b>Model</b>                       | <b>Case Creation Date</b>            |
| <input type="text" value="██████████"/>     | 2022   | Tundra                             | Jan 30, 2025                         |
| <b>Repair Order Date *Required</b>          | <b>Repair Order *Required</b>                | <b>Odometer *Required</b>          | <b>Miles/KM *Required</b>            |
| <input type="text" value="Jan 28, 2025"/> ⓘ | <input type="text" value="123456"/>          | <input type="text" value="12500"/> | <input type="text" value="Miles"/> ▼ |
| <b>Dealer Visits for Concern *Required</b>  | <b>Customer Type *Required</b>               |                                    |                                      |
| <input type="text" value="1"/> ▼            | <input type="text" value="Private Owner"/> ▼ |                                    |                                      |

**Technician Information**

|   |   |   |   |
|---|---|---|---|
| <b>Technician Name *Required</b>        | <b>Dealer Code / Name *Required</b>     | <b>Dealer Phone Number</b>              | <b>Direct Contact Phone *Required</b>   |
| <input type="text" value="██████████"/> | <input type="text" value="██████████"/> | <input type="text" value="██████████"/> | <input type="text" value="██████████"/> |

## 2. Case Details

- a. Enter Customer Concern as 24TA07 – Describe damage to engine
  - i. Example: 24TA07 – Dipstick Tube damaged
- b. Select “Powertrain” as Service Group
- c. Select “Engine/Hybrid System” as Service Category
- d. Select “Engine Mechanical” as Section
- e. Select “Fluid Dip Stick” as Sub-Component
- f. Select “Design/Less than Expectation” as Condition
- g. Select “N/A” as Pre-Call Worksheet
- h. Select “Save and Continue”

The screenshot shows the 'Case Details' step in the TAS - Technical Assistance System. The interface includes a progress bar at the top with five steps: General Information (checked), Case Details (active, highlighted with a '2'), Diagnostic Information (checked), Review (checked), and Submitted (5). Below the progress bar, the 'Case Details' section contains several required fields:

- Customer Concern \*Required:** A text input field containing '24TA07 - Dip Stick Tube Damaged'. A note below indicates a 'Limit 10,000 characters'.
- Service Group \*Required:** A dropdown menu with 'Powertrain' selected.
- Service Category \*Required:** A dropdown menu with 'Engine/Hybrid System' selected.
- Section \*Required:** A dropdown menu with 'Engine Mechanical' selected.
- Sub-Component \*Required:** A dropdown menu with 'Fluid Dip Stick' selected.
- Condition \*Required:** A dropdown menu with 'Design/Less Than Expectation' selected.
- Pre-Call Worksheet \*Required:** A dropdown menu with 'N/A' selected.

At the bottom of the form, there are three buttons: 'Save and Continue' (highlighted in blue), 'Back', and 'Cancel'.

### 3. Diagnostic Information

- a. Provide description of damage
- b. Provide clear photos showing damage to engine/crate
- c. Select "Save and Continue"

The screenshot shows the TAS - Technical Assistance System interface. At the top, there is a header with the text "TAS - Technical Assistance System" and a navigation bar with icons for "TAS Home", "Create a TAS Case", "Case Management", and "Pre-Call Worksheets". Below the navigation bar is a progress indicator with five steps: "General Information", "Case Details", "Diagnostic Information" (highlighted with a blue circle and the number 3), "Review", and "Submitted".

The main content area is titled "Diagnostic Steps Performed" and contains a form for entering a description. The form has a label "Description \*Required" and a text input field containing the text "Disassembled crate and found fluid dip stick tube damaged". Below the input field, there is a note "Limit 10,000 characters".

The screenshot shows the file upload section of the TAS interface. At the top, there is a dashed box with the text "Drag and drop file(s) here or" and a button labeled "Click To Browse". Below this, there is a note "Supported file types" with a help icon.


Below the dashed box, there is a preview of an uploaded file: "IMG\_3486.JPG" with a size of "3.22 MB of 3.22 MB". To the right of the file name is a trash icon. Below the file name is a text input field labeled "Comment" and a "Save" button.

Below the file preview, there is a note "Press the sync mobile button to update and sync files from mobile upload" and a "Sync Mobile" button.

At the bottom of the form, there are three buttons: "Save and Continue", "Back", and "Cancel".

#### 4. Review

- a. Confirm all details are correctly input
- b. Select "Submit"



The screenshot displays the 'TAS - Technical Assistance System' interface. The form is titled 'Pre-Call Worksheet' and shows the following details:

- Pre-Call Worksheet:** N/A
- Diagnostic Information:** A section header.
- Diagnostic Steps Performed:** A section header.
- Description:** Disassembled crate and found dip stick tube damaged
- Primary DTC:** A section header.
- Communication Method:** Digital Communication
- Attached Documents (1):** A list of documents, including 'IMG\_3486.JPG' (3.22 MB of 3.22 MB) with a green checkmark icon.


At the bottom of the form, there are three buttons: 'Submit' (highlighted in blue), 'Back', and 'Cancel'.

- Include a good call back number
- Attach clear pictures illustrating the damaged components
- Submit the TAS case.
- TAS will put the case in open status and forward the case to the FTS for review. Submit the completed case in TAS; allow 3 days for FTS to review the case. After 3 days, check the TAS case for status. If the repair is approved, the case will be marked closed. Additionally, the FTS will provide the necessary labor op-code as well as the maximum allowable time for the repairs requested.

NOTE: It is critical that dealers document all damaged components in the TAS case and attach pictures of the damaged components. TMNA will review all claims utilizing this special labor op-code to ensure the allowable time noted in the TAS case by the FTS matches the warranty claim filed by the dealer. (Include TAS case # on claim).

## II. OPERATION FLOW CHART

The flow chart is for reference only. DO NOT use it in place of the full technical instructions. Follow ALL steps as outlined in the full technical instructions to confirm the campaign is completed correctly.



### III. IDENTIFICATION OF AFFECTED VEHICLE

#### 1. CHECK VEHICLE FOR CAMPAIGN ELIGIBILITY

- a. Compare the *vehicle's VIN to the* VIN listed on the Repair Order to ensure they match.
- b. Check the TIS Vehicle Inquiry System to confirm the VIN is involved in this Campaign, and that it has not already been completed.

#### NOTICE:

TMNA warranty will not reimburse dealers for repairs completed on vehicles that are not affected or were previously completed, even by another dealer.

### IV. PREPARATION

**NOTE:** All parts in red will be ordered via the website.

#### A. PARTS

| Part Number | Part Description  | Quantity       |
|-------------|---|----------------|
| 04004-23170 | Engine, Assy LX (Not returnable)                        | 1              |
| 17279-0W040 | Gasket, Turbine Outlet Elbow                            | 2              |
| 00272-SLLC2 | Genuine Toyota Super Long Life Coolant                  | 5              |
| 00289-ATFWS | World Standard Automatic Transmission Fluid (If needed) | 2              |
|             | 0W20 Motor Oil - Genuine Lexus                          | Up to 8 quarts |
| 04004-29160 | Gasket Kit (SSP Kit)*                                   | 1              |

\* The kit above includes the following parts

| Part Number | Part Description        | Quantity |
|-------------|-------------------------|----------|
| 16418-15520 | PACKING, RADIATOR DRAIN | 1        |
| 16418-70730 | PACKING, RADIATOR DRAIN | 1        |
| 17451-28041 | GASKET, EXHAUST PIPE    | 2        |
| 17451-52050 | GASKET, EXHAUST PIPE    | 1        |
| 17452-70010 | CLAMP, EXHAUST PIPE     | 2        |
| 90099-14119 | O-RING                  | 2        |
| 90099-14120 | O-RING                  | 2        |
| 90099-14121 | O-RING                  | 1        |
| 90105-10590 | BOLT, FLANGE            | 2        |
| 90430-12008 | GASKET                  | 1        |
| 90430-18008 | GASKET                  | 1        |
| 90467-08217 | CLIP                    | 4        |
| 90468-12023 | CLIP                    | 1        |
| 90917-06070 | GASKET, EXHAUST PIPE    | 1        |




If used engine assembly is not returned according to the [job aid](#), the entire warranty claim amount is subject to debit. Ensure the used engine is returned following the engine return instructions.

**TOOLS & EQUIPMENT**

|  |                                 |                      |  |                      |
|--|---------------------------------|----------------------|--|----------------------|
| • GTS+                                 | • Standard Hand Tools           | • 1/2" Torque Wrench | • Pipe Insulator                                 | • 3/8" Torque Wrench |
| • Bolts & nuts to secure chain on hook | • Chain (600+ lb weight rating) | • Small plastic bags | • Plywood or cardboard sheet to protect radiator |                      |

Campaign SSTs: The following Campaign SSTs were shipped to your dealer prior to remedy launch of this recall and are required to be used for the remedy repair.

| Image   | Name               | Quantity |
|---|--------------------|----------|
|  | Norco Engine Hoist | 1        |



**NOTE:** Confirm acme rod on engine hoist bottle jack is adjusted to about 1" (approximately 7 threads) to ensure engine hoist height requirement is met as shown above.

**NOTE:** Each dealer was provided one Norco High-Lift Engine Hoist at the launch of this recall. At the time of launch, this engine hoist **CANNOT** be ordered through the approved dealer equipment program. If an additional engine hoist is needed, and a dealer wishes to procure one at their own expense, please ensure engine hoist height from the hook to the ground is at least 91" or hoist will not be tall enough to complete repair.

**NOTE: The engine hoist legs are longer than usual for additional stability. The vehicle may need to be backed into the stall or rolled backwards (if pulled in forward) depending on your shop space limitations to maneuver the engine hoist.**


Service Hooks/Bolts: The following service hooks/bolts were shipped to your dealer prior to remedy launch of this recall and are required to be used for the remedy repair. These parts can be ordered through the dealer’s parts network.

| Part Description          | Part Number |
|---------------------------|-------------|
| Service Engine Hook No. 1 | 12281-70080 |
| Service Engine Hook No. 2 | 12282-70050 |
| Service Engine Hook Bolts | 90105-A0354 |


## V. BACKGROUND

There is a possibility that certain machining debris may not have been cleared from the engine when it was produced. In the involved vehicles, this can lead to potential engine knocking, engine rough running, engine no start and/or a loss of motive power. A loss of motive power while driving at higher speeds can increase the risk of a crash.


## VI. COMPONENTS



|   | PROCEDURE                                       | PART NAME CODE |
|---|---|----------------|
| 1 | PRECAUTION                                      | -              |
| 2 | DISCHARGE FUEL SYSTEM PRESSURE                  | -              |
| 3 | ENGINE SIDE COVER RH                            | 51473C         |
| 4 | ENGINE SIDE COVER LH                            | 51474B         |
| 5 | RELEASE PARKING BRAKE                           | -              |
| 6 | DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL | -              |




| Procedure |   | Part Name Code          |
|-----------|---|-------------------------|
| 8         | NO. 1 ENGINE UNDER COVER ASSEMBLY       | 51410                   |
| 9         | NO. 2 ENGINE UNDER COVER ASSEMBLY       | 51420                   |
| 10        | FRAME UNDER COVER ASSEMBLY RH           | 51430A                  |
| 11        | FRAME UNDER COVER ASSEMBLY LH           | 51450C                  |
| 12        | FRONT TRANSMISSION UNDER COVER ASSEMBLY | 51460D                  |
| 13        | OIL PAN PROTECTOR ASSEMBLY              | 51440                   |
| *a        | w/o Oil Pan Protector                   | *b w/ Oil Pan Protector |




H

| PROCEDURE |                                      | PART NAME CODE |
|-----------|--------------------------------------|----------------|
| 7         | FRONT WHEEL                          | -              |
| 8         | FRONT FENDER APRON TRIM<br>PACKING A | 53782          |
| 9         | FRONT FENDER APRON TRIM<br>PACKING B | 53783          |
| 1<br>0    | FRONT FENDER APRON TRIM<br>PACKING C | 53784          |
| 1<br>1    | FRONT FENDER APRON TRIM<br>PACKING D | 53785B         |




| Procedure |   | Part Name Code |
|-----------|---|----------------|
| 19        | RECOVER REFRIGERANT FROM REFRIGERATION SYSTEM | -              |
| 20        | DRAIN ENGINE OIL                              | -              |
| 21        | DRAIN ENGINE COOLANT                          | -              |
| 22        | DRAIN COOLANT (for Intercooler)               | -              |
| 26        | HOOD INSULATOR                                | 53341B         |
| 27        | WINDSHIELD WASHER HOSE ASSEMBLY               | 85370          |
| 28        | HOOD SUB-ASSEMBLY                             | 53301          |
| •         | Non-reusable part                             |                |






| Procedure |   | Part Name Code |
|-----------|---|----------------|
| 55        | NO. 2 PCV HOSE (NO. 2 VENTILATION HOSE) | 12262          |
| 56        | NO. 1 AIR INLET DUCT                    | 17311          |
| 57        | FUEL TUBE SUB-ASSEMBLY                  | 23901          |
| 58        | NO. 2 AIR INLET DUCT                    | 17312D         |
| *1        | COOL AIR INLET BRACKET                  |                |



| Procedure                |   | Part Name Code      |
|--------------------------|---|---------------------|
| 59                       | NO. 6 TURBO INSULATOR                   | 1728C               |
| 60                       | ENGINE WIRE                             | 82121               |
| 61                       | ENGINE HANGER                           | -                   |
| 62                       | SUCTION HOSE SUB-ASSEMBLY               | 88704               |
| 63                       | NO. 1 COOLER REFRIGERANT DISCHARGE HOSE | 88711               |
| 64                       | COMPRESSOR ASSEMBLY WITH MAGNET CLUTCH  | -                   |
| 65                       | GENERATOR ASSEMBLY                      | 27020               |
| 66                       | NO. 10 ENGINE WIRE                      | 8212B               |
| <input type="checkbox"/> | N*m (kgf*cm, ft.*lbf): Specified torque | • Non-reusable part |



| Procedure |                                      | Part Name Code                          |
|-----------|--------------------------------------|---|
| 77        | FRONT ENGINE MOUNTING INSULATOR LH   | 12362A                                  |
| 78        | FRONT ENGINE MOUNTING INSULATOR RH   | 12361E                                  |
| *1        | FRONT NO. 2 FLEXIBLE HOSE BRACKET RH | *2 FRONT NO. 2 FLEXIBLE HOSE BRACKET LH |



## VII.

1. Ensure engine is ordered using instructions in [24LA04 Dealer Letter](#).
2. Engine Crate Disassembly



Engine Crate will be reused to return the OLD engine, so **DO NOT** damage the crate/box or the plastic bag inside the crate.

- a. Carefully cut the side of each strap with the shortest flap on the outside of the crate as shown below




Do not discard straps or buckles as they are required for engine recovery.

### 3. Engine Assembly 04004-23170 Overview

While the **NEW** engine assembly contains most components such as intercooler, turbos, and fuel system, some components will need to be transferred from the existing engine to the replacement engine such as:

- Starter
- Engine Wire Harness
- Alternator
- A/C Compressor
- Drive belt tensioner
- Drive belts

See pictures below for reference of engine assembly.



## VI. REPAIR INSTRUCTIONS



**Only complete the following repair procedure after completing steps above.**


### 1. REMOVE THE ENGINE ASSEMBLY

#### NOTICE:

Carefully read the cautions written in the repair manual and perform the written instructions correctly.



**IF ENGINE IS SEIZED (CANNOT BE TURNED OVER BY HAND) SEE STEP 84 OF THIS SECTION.**




### 1. CHECK FOR DTCS

- a. Using a Techstream/GTS+, check for Diagnostic Trouble Codes.

**NOTICE:**


This Safety Recall only covers the engine replacement. It does not cover the diagnosis or replacement of any other systems on the vehicle.

### 2. REMOVE ENGINE SIDE COVER RH



|  |                              |  |                              |
|--|------------------------------|--|------------------------------|
|  | Remove in this Direction (1) |  | Remove in this Direction (2) |
|--|------------------------------|--|------------------------------|


### 3. REMOVE ENGINE SIDE COVER LH



|  |                              |  |                              |
|--|------------------------------|--|------------------------------|
|  | Remove in this Direction (1) |  | Remove in this Direction (2) |
|--|------------------------------|--|------------------------------|

#### 4. DISABLE PARKING BRAKE and DISCHARGE FUEL PRESSURE

- a. Turn the ignition ON (key on, engine off).
- b. Depress brake pedal
- c. Press the electric parking brake switch on the center console to release the brake
- d. Check that the parking brake indicator light on the combination meter turns off
- e. Remove the EFI-MAIN No. 2 relay.
- f. Loosen or remove the fuel tank cap assembly.
- g. Start the engine and slightly depress the accelerator pedal (50% or more).
- h. Keep accelerator applied until engine stops running
- i. Turn the ignition switch OFF
- j. Install fuel cap
- k. Install EFI-MAIN No.2 Relay.




#### 5. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

#### 6. RECOVER REFRIGERANT FROM REFRIGERATION SYSTEM


Recover the refrigerant from the A/C system using a refrigerant recovery unit.

## 7. REMOVE NO. 1 ENGINE UNDER COVER ASSEMBLY









- Remove the 5 bolts.
- Move the side of the No. 1 engine under cover assembly facing the front of the vehicle toward the LH side and detach the temporary holding guide.
- Remove the No. 1 engine under cover assembly while detaching the 2 temporary holding guides of the No. 1 engine under cover assembly as shown in the illustration.




## 8. REMOVE NO. 2 ENGINE UNDER COVER ASSEMBLY



## 9. REMOVE FRAME UNDER COVER ASSEMBLY RH




|   |   |
|---|---|
|    | <p><b>10. REMOVE FRAME UNDER COVER ASSEMBLY LH</b></p>  |
|    | <p><b>11. REMOVE FRONT TRANSMISSION UNDER COVER ASSEMBLY (w/o Oil Pan Protector)</b></p>  |
|   | <p><b>12. REMOVE OIL PAN PROTECTOR ASSEMBLY (w/ Oil Pan Protector)</b></p>  |
|  | <p><b>13. REMOVE FRONT WHEEL</b></p> <ol style="list-style-type: none"> <li><b>Remove the 6 lug nuts and remove front wheel</b></li> <li><b>Repeat on other side</b></li> </ol> |
|  | <p><b>14. REMOVE FRONT FENDER APRON TRIM PACKING A</b></p>  |

|   |  |
|---|--|
|    | <p><b>15. REMOVE FRONT FENDER APRON TRIM PACKING B</b></p> |
|    | <p><b>16. REMOVE FRONT FENDER APRON TRIM PACKING C</b></p> |
|   | <p><b>17. REMOVE FRONT FENDER APRON TRIM PACKING D</b></p> |
| <p><b>18. DRAIN ENGINE OIL</b></p> <ol style="list-style-type: none"> <li>a. Remove drain plug and drain engine oil.</li> <li>b. Reinstall drain plug after empty.</li> </ol>   |  |
| <p><b>19. DRAIN ENGINE COOLANT</b></p> <ol style="list-style-type: none"> <li>a. Connect a hose with an inside diameter of 9 mm (0.354 in.) to the radiator drain cock as shown in the illustration.</li> <li>b. Connect a hose with an inside diameter of 8 mm (0.315 in.) to the cylinder block water drain cock plug as shown in the illustration.</li> <li>c. Loosen the radiator drain cock plug</li> <li>d. Remove the reserve tank cap. Then drain the engine coolant</li> <li>e. Loosen the cylinder block water drain cock plug</li> <li>f. Tighten the cylinder block water drain cock plug.<br/>Torque:</li> </ol> |  |


## 12.7 N·m {130 kgf·cm, 9 ft·lbf}

- g. Tighten the radiator drain cock plug by hand
- h. Disconnect the hose from the cylinder block water drain cock plug
- i. Disconnect the hose from the radiator drain cock




## 20. DRAIN ENGINE COOLANT (FOR INTERCOOLER)


- a. Connect a hose with an inside diameter of 8 mm (0.315 in.) to the radiator drain cock sub-assembly
- b. Loosen the radiator drain cock sub-assembly (for Intercooler) and drain the coolant
- c. Tighten the radiator drain cock sub-assembly (for Intercooler) by hand after empty




**21. REMOVE UPPER RADIATOR SUPPORT SEAL**




**22. REMOVE V-BANK COVER SUB-ASSEMBLY**




**23. REMOVE HOOD INSULATOR**



**24. DISCONNECT WINDSHIELD WASHER HOSE ASSEMBLY**





**25. REMOVE HOOD SUB-ASSEMBLY**



**NOTE:** Be sure to perform this procedure with several people as the hood sub-assembly is very heavy.

## 26. REMOVE FRONT WIPER ARM HEAD CAP




|   |                          |   |                 |
|---|--------------------------|---|-----------------|
|  | Remove in this Direction |  | Protective Tape |
|---|--------------------------|---|-----------------|

a. Using a screwdriver with its tip wrapped with protective tape, disengage the claw as shown in the illustration to remove the front wiper arm head cap.

**NOTE:** Use the same procedure for the RH and LH sides. The procedure described below is for the LH side.

## 27. REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY LH and RH






- Remove the nut and front wiper arm and blade assembly RH.
- Remove the nut and the front wiper arm and blade assembly LH.

**NOTE:** While holding the front wiper arm and blade assembly RH, loosen the nut.

**NOTE:** While holding the front wiper arm and blade assembly LH, loosen the nut.


## 28. REMOVE WINDSHIELD OUTSIDE MOULDING RH




|   |                          |   |                 |
|---|--------------------------|---|-----------------|
|  | Remove in this Direction |  | Protective Tape |
|---|--------------------------|---|-----------------|

- a. Using a clip remover with its tip wrapped with protective tape, detach the clip and remove the windshield outside moulding RH.


## 29. REMOVE WINDSHIELD OUTSIDE MOULDING LH




|   |                          |   |                 |
|---|--------------------------|---|-----------------|
|  | Remove in this Direction |  | Protective Tape |
|---|--------------------------|---|-----------------|

- a. Using a clip remover with its tip wrapped with protective tape, detach the clip and remove the windshield outside moulding LH.


## 30. REMOVE HOOD TO COWL TOP SEAL



### 31. REMOVE COWL TOP VENTILATOR LOUVER RH




|  |                              |   |   |
|--|------------------------------|---|---|
|  | Remove in this Direction (1) | - | - |
|--|------------------------------|---|---|




|  |                              |  |                              |
|--|------------------------------|--|------------------------------|
|  | Remove in this Direction (1) |  | Remove in this Direction (2) |
|--|------------------------------|--|------------------------------|

### 32. REMOVE COWL TOP VENTILATOR LOUVER LH




|  |                              |   |   |
|--|------------------------------|---|---|
|  | Remove in this Direction (1) | - | - |
|--|------------------------------|---|---|




|  |                              |  |                              |
|--|------------------------------|--|------------------------------|
|  | Remove in this Direction (1) |  | Remove in this Direction (2) |
|--|------------------------------|--|------------------------------|

### 33. REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY


**NOTE:** To prevent damage to the windshield glass, remove any foreign matter (sand, dust, etc.) from around the contacting surfaces of the cowl top ventilator louver sub-assembly and windshield glass.




|  |                          |   |   |
|--|--------------------------|---|---|
|  | Remove in this Direction | - | - |
|--|--------------------------|---|---|




### 34. DISCONNECT NO. 3 WATER BY-PASS HOSE



### 35. DISCONNECT OUTLET HEATER WATER HOSE




**36. DISCONNECT NO. 2 WATER BY-PASS HOSE**




**37. REMOVE RADIATOR RESERVE TANK ASSEMBLY**


**38. DISCONNECT ENGINE COOLANT TEMPERATURE SENSOR**







**NOTE:** If the engine coolant temperature sensor has been struck or dropped, replace it.




**39. REMOVE NO. 1 RADIATOR HOSE**




**40. DISCONNECT NO. 2 RADIATOR HOSE**

|  |   |
|--|---|
|    | <p><b>41. DISCONNECT NO. 2 WATER BY-PASS PIPE</b></p>                                 |
|    | <p><b>42. DISCONNECT OIL COOLER ASSEMBLY WITH OIL COOLER HOSE</b></p>                 |
|   | <p><b>43. DISCONNECT OIL COOLER TUBE SUB-ASSEMBLY</b></p>                             |
|  | <p><b>44. REMOVE OIL COOLER TUBE AND OIL COOLER HOSE WITH OIL COOLER ASSEMBLY</b></p> |


**45. REMOVE AIR CLEANER ASSEMBLY RH WITH AIR CLEANER HOSE ASSEMBLY RH**




**46. REMOVE AIR CLEANER ASSEMBLY LH WITH AIR CLEANER HOSE ASSEMBLY LH**




**47. REMOVE UPPER ENGINE SIDE UNDER COVER PLATE LH**




**48. REMOVE REAR ENGINE SIDE UNDER COVER ASSEMBLY LH**




**49. REMOVE ENGINE SIDE UNDER COVER RH**



**50. REMOVE BATTERY AND BATTERY CARRIER ASSEMBLY**



## 51. DISCONNECT ECM CONNECTOR



- a. Detach the 2 wire connector clamps.
- b. Push in the locks on the 3 levers, raise the 3 levers, and disconnect the 3 ECM connectors.

**NOTE:** After disconnecting the ECM connectors, make sure that dirt, water and other foreign matter does not contact the connecting parts of the ECM connectors.




- c. Detach the 3 wire harness clamps.
- d. Remove the 3 bolts and ECM.

**NOTE:** If the ECM has been struck or dropped, replace it.


## 52. DISCONNECT ENGINE WIRE

**NOTE:** After disconnecting the wire harness, secure it with tape or equivalent to keep it out of the way.




\*A




0

|   |                          |   |   |
|---|--------------------------|---|---|
| *A  | for LH Side              | - | - |
|  | Remove in this Direction | - | - |


\*A



0



|   |                          |   |   |
|---|--------------------------|---|---|
| *A  | for RH Side              | - | - |
|  | Remove in this Direction | - | - |

### 53. DISCONNECT FUEL TUBE SUB-ASSEMBLY




- a. Remove the fuel pipe clamp from the fuel tube connector.
- b. Disconnect the fuel tube sub-assembly.

#### 54. REMOVE NO. 2 PCV HOSE




#### 55. REMOVE NO. 1 AIR INLET DUCT




#### 56. REMOVE FUEL TUBE SUB-ASSEMBLY

- a. Disconnect the fuel tube sub-assembly.
- b. Detach the 2 clamps and remove the fuel tube sub-assembly.








#### 57. REMOVE NO. 2 AIR INLET DUCT




#### 58. REMOVE NO. 6 TURBO INSULATOR

## 59. DISCONNECT ENGINE WIRE



|    |                |    |                |
|----|----------------|----|----------------|
| *A | for Upper Side | *B | for Front Side |
| *C | for Rear Side  | *D | for RH Side    |
| *E | for LH Side    | -  | -              |



## 60. REMOVE NO. 10 ENGINE WIRE


## 61. DISCONNECT SUCTION HOSE SUB-ASSEMBLY



- a. Disconnect the connector.
- b. Remove the bolt and disconnect the suction hose sub-assembly.
- c. Remove the O-ring from the suction hose sub-assembly.

**NOTE:** Seal the openings of the disconnected parts using vinyl tape to prevent moisture and foreign matter from entering them.


## 62. REMOVE NO. 1 COOLER REFRIGERANT DISCHARGE HOSE



- a. Remove the bolt and No. 1 cooler refrigerant discharge hose.
- b. Remove the O-ring from the No. 1 cooler refrigerant discharge hose.


**NOTE:** Seal the openings of the disconnected parts using vinyl tape to prevent moisture and foreign matter from entering them.

### 63. REMOVE COOLING FAN WIRE




1. Push the lever down to release the lock and disconnect connector A.
2. Disconnect the connector B.
3. Remove the 2 bolts and cooling fan wire.

### 64. REMOVE NO. 1 V BELT (COOLER COMPRESSOR TO CRANKSHAFT PULLEY)




|    |                                  |    |      |
|----|----------------------------------|----|------|
| *1 | V-ribbed Belt Tensioner Assembly | -  | -    |
| *a | 5 mm Hexagon Wrench              | *b | Hole |
|    | Turn in this Direction           | -  | -    |

1. Release the No. 1 V belt (cooler compressor to crankshaft pulley) tension by turning the V-ribbed belt tensioner assembly clockwise and remove the No. 1 V belt (cooler compressor to crankshaft pulley) from the V-ribbed belt tensioner assembly.
2. Rotate the V-ribbed belt tensioner assembly clockwise to align the holes and then insert a 5 mm hexagon wrench to secure the V-ribbed belt tensioner assembly in place.
3. Remove the No. 1 V belt (cooler compressor to crankshaft pulley).




**65. DISCONNECT ENGINE WIRE**



**66. REMOVE NO. 1 AIR TUBE SUPPORT**





**67. REMOVE FAN AND GENERATOR V BELT**



|    |                                  |    |      |
|----|----------------------------------|----|------|
| *1 | V-ribbed Belt Tensioner Assembly | -  | -    |
| *a | 5 mm Hexagon Wrench              | *b | Hole |
|    | Turn in this Direction           | -  | -    |

1. Release the fan and generator V belt tension by turning the V-ribbed belt tensioner assembly clockwise and remove the fan and generator V belt from the V-ribbed belt tensioner assembly.
2. Rotate the V-ribbed belt tensioner assembly clockwise to align the holes and then insert a 5 mm hexagon wrench to secure the V-ribbed belt tensioner assembly in place.
3. Remove the fan and generator V belt.

## 68. REMOVE FAN SHROUD




|   |                          |   |   |
|---|--------------------------|---|---|
|  | Remove in this Direction | - | - |
|---|--------------------------|---|---|


1. Loosen the 4 nuts holding the fluid coupling assembly with fan.
2. Remove the 2 bolts holding the fan shroud.
3. Remove the 4 nuts.
4. Remove the fan shroud together with the fluid coupling assembly with fan.

**NOTE:** Be careful not to damage the radiator core.


5. Remove the fan pulley from the engine water pump assembly.

## 69. DISCONNECT NO. 3 WATER BY-PASS HOSE






**70. DISCONNECT NO. 4 WATER BY-PASS HOSE**



**71. DISCONNECT NO. 1 FUEL VAPOR FEED HOSE**

**72. DISCONNECT HEATER WATER HOSE L**




|    |          |   |          |
|----|----------|---|----------|
| *a | Retainer | - | -        |
|    | Pull out |   | Pull off |

a. Disconnect the heater water hose L connector from the water by-pass hose assembly.

**NOTE:** Remove any foreign matter on the water by-pass hose assembly and heater water hose L connector before performing this work.

1. Pull out the retainer to disengage the lock claws and pull off the heater water hose L connector.
2. Check that there is no foreign matter on the sealing surfaces of the disconnected water lines. Clean them if necessary.
3. Cover the disconnected heater water hose L connector with a plastic bag to prevent damage and contamination.

### 73. DISCONNECT OUTLET HEATER WATER HOSE




|    |          |   |          |
|----|----------|---|----------|
| *a | Retainer | - | -        |
|    | Pull out |   | Pull off |

- a. Disconnect the outlet heater water hose B connector from the No. 4 water by-pass pipe.

**NOTE: Remove any foreign matter on the No. 4 water by-pass pipe and outlet heater water hose B connector before performing this work.**

1. Pull out the retainer to disengage the lock claws and pull off the outlet heater water hose B connector.
2. Check that there is no foreign matter on the sealing surfaces of the disconnected water lines. Clean them if necessary.
3. Cover the disconnected outlet heater water hose B connector with a plastic bag to prevent damage and contamination.

### 74. DISCONNECT NO. 4 WATER BY-PASS HOSE ASSEMBLY



|    |          |   |          |
|----|----------|---|----------|
| *a | Retainer | - | -        |
|    | Pull out |   | Pull off |


- a. Disconnect the No. 4 water by-pass hose assembly connector from the water by-pass hose assembly.



**NOTE: Remove any foreign matter on the water by-pass hose assembly and No. 4 water by-pass hose assembly connector before performing this work.**

- b. Pull out the retainer to disengage the lock claws and pull off the No. 4 water by-pass hose assembly connector.
- c. Check that there is no foreign matter on the sealing surfaces of the disconnected water lines. Clean them if necessary.
- d. Cover the disconnected No. 4 water by-pass hose assembly connector with a plastic bag to prevent damage and contamination.

**75. DISCONNECT NO. 1 VACUUM HOSE CONNECTOR**


**NOTE:** Be sure to disconnect the No. 1 vacuum hose connector by hand.



|   |          |   |          |
|---|----------|---|----------|
| *a  | Retainer | -   | -        |
|  | Pinch    |  | Pull off |

- a. Pinch the retainer of the No. 1 vacuum hose connector, and then pull the No. 1 vacuum hose connector off of the vacuum pump assembly.

**76. DISCONNECT SUCTION HOSE SUB-ASSEMBLY**




- a. Remove the bolt and disconnect the suction hose sub-assembly.
- b. Remove the O-ring from the suction hose sub-assembly.

## 77. DISCONNECT NO. 1 COOLER REFRIGERANT DISCHARGE HOSE




- a. Disconnect the connector.
- b. Remove the bolt and disconnect the No. 1 cooler refrigerant discharge hose.
- c. Remove the O-ring from the No. 1 cooler refrigerant discharge hose.

**NOTE:** Seal the openings of the disconnected parts using vinyl tape to prevent moisture and foreign matter from entering them.




## 78. DISCONNECT AIR FUEL RATIO SENSOR

- a. Disconnect the air fuel ratio sensor connector
- b. Detach the wire harness clamp




## 79. DISCONNECT NO. 2 AIR FUEL RATIO SENSOR

- a. Disconnect the air fuel ratio sensor connector
- b. Detach the 4 wire harness clamps




## 80. DISCONNECT NO. 3 AIR FUEL RATIO SENSOR

- a. Disconnect the air fuel ratio sensor connector
- b. Detach the 3 wire harness clamps




## 81. DISCONNECT NO. 4 AIR FUEL RATIO SENSOR


- a. Disconnect the air fuel ratio sensor connector
- b. Detach the 2 wire harness clamps



**82. REMOVE NO. 4 TURBO INSULATOR**




**83. REMOVE NO. 2 TURBO INSULATOR**




**84. REMOVE NO. 2 PROPELLER SHAFT HEAT INSULATOR**

**85. REMOVE FRONT PROPELLER SHAFT ASSEMBLY**




|    |           |   |   |
|----|-----------|---|---|
| *a | Matchmark | - | - |
|----|-----------|---|---|

- a. Place matchmarks on the propeller shaft flange and differential flange.
- b. Remove the 4 nuts and 4 washers.
- c. Place matchmarks on the propeller shaft flange and transfer flange.
- d. Remove the 4 nuts and 4 washers.




e. Remove the front propeller shaft assembly in the order shown in the illustration.


### 86. REMOVE CONVERTER WITH CATALYST ASSEMBLY LH




**87. REMOVE CONVERTER WITH CATALYST ASSEMBLY RH**




**88. REMOVE NO. 2 MANIFOLD STAY**





**89. REMOVE MANIFOLD STAY**




**90. REMOVE STARTER COVER**



## 91. REMOVE STARTER ASSEMBLY



## 92. REMOVE TRANSMISSION CONTROL CABLE INSULATOR




## 93. DISCONNECT TRANSFER BREATHER HOSE SUB-ASSEMBLY

**NOTICE:** The transfer breather hose sub-assembly can be disconnected without tilting the automatic transmission assembly with transfer assembly. When tilting the automatic transmission assembly with transfer assembly, do not tilt it excessively to allow the cooling fan and fan shroud to contact each other.

## 94. DISCONNECT TRANSMISSION/TRANSFER CASE WIRE HARNESS CONNECTIONS AND UNBOLT BRACKETS

**NOTICE:** The wire harness can be disconnected without tilting the automatic transmission assembly with transfer assembly. When tilting the automatic transmission assembly with transfer assembly, do not tilt it excessively to allow the cooling fan and fan shroud to contact each other.




| *a | Transmission Wire Connector | *b | TCM connector           |
|----|-----------------------------|----|-------------------------|
|    | Connector                   |    | Bolt                    |
|    | Pull Down the Lever         |    | While Pressing the Lock |
|    | Pull Up the Lever           | -  | -                       |

a. Disconnect the 5 connectors.

**NOTICE:** Disconnect the claw, pull down the lever, and then disconnect the transmission wire connector. Disconnect the TCM connector lever while pressing the lever lock as shown in the illustration.

- b. Detach the clamp.
- c. Remove the 5 bolts and disconnect the wire harness from the automatic transmission assembly with transfer assembly.

## 95. REMOVE BELL HOUSING BOLTS



1. Remove the 11 bolts from the transmission assembly.

**NOTE:** Do not use excessive force to pry out the automatic transmission assembly with transfer assembly when separating it from the engine assembly to prevent the knock pins from being damaged.

## 96. REMOVE FLYWHEEL HOUSING SIDE COVER



1. Remove flywheel housing side cover
2. Remove the 6 drive plate and torque converter setting bolts from the drive plate and ring gear sub-assembly through the flywheel housing side cover hole.

**NOTE:** Turn the crankshaft to a position where the drive plate and torque converter setting bolts can be removed and remove the drive plate and torque converter setting bolts while securing the crankshaft pulley bolt with a wrench.


## 97. SEIZED ENGINE REMOVAL



**IF ENGINE IS NOT SEIZED (CAN BE TURNED OVER BY HAND) SKIP THIS STEP.**

**NOTICE: Confirm starter is functional by ensuring it will spin freely. If starter does not spin freely by hand, the starter will need to be replaced.**

1. If engine is seized (cannot be turned over by hand), follow these steps:
  - a. Using pole jack, stabilize rear of the engine to prevent twisting/shifting of the engine mounts due to the weight of the torque converter when removing the transmission.



- b. Remove transmission while leaving torque converter attached to engine. Avoid excessive movement while removing transmission to avoid damage to the front pump.




c. Remove torque converter bolts using open ended wrench.




**NOTICE:** Carefully read the cautions written in the repair manual and perform the written instructions correctly.

**98. PROTECT RADIATOR FINS BY ADDING A CARDBOARD SHEET OR PLYWOOD COVER**




### 99. PROTECT WINSHEILD EDGE WITH PIPE INSULATOR.

Note: Use caution around the windshield defroster wire.



### 100. INSTALL/TORQUE SERVICE ENGINE HOOKS/BOLTS



|    |                     |    |                     |
|----|---------------------|----|---------------------|
| *1 | No. 1 Engine Hanger | *2 | No. 2 Engine Hanger |
|----|---------------------|----|---------------------|

1. Using the hooks on the new engine assembly or service hooks/bolts, install the No. 1 engine hanger and No. 2 engine hanger with the 4 bolts as shown in the illustration.


| Part Description          | Part Number |
|---------------------------|-------------|
| Service Engine Hook No. 1 | 12281-70080 |
| Service Engine Hook No. 2 | 12282-70050 |
| Service Engine Hook Bolts | 90105-A0354 |

#### Torque:

43 N·m {438 kgf·cm, 32 ft·lbf}


## 101. REMOVE ENGINE ASSEMBLY

**NOTE:** When attaching the engine lift chain to the engine crane boom-chain hook, make sure the entire chain link is placed inside the hook. Then, secure it by installing one or two through bolts of the appropriate size with a nut and washers to prevent any slipping while hoisting the engine as shown below.



**The chain must be centered, and the center of gravity set before installing the through bolts.**

1. Attach an engine sling device and hang the engine with a chain block.
2. Using a 17 mm hexagon wrench, remove the 4 hexagon socket head cap bolts.



3. Remove the engine assembly by operating the engine sling device and chain block.


**NOTE:** Make sure that the engine is clear of all wiring and hoses. While removing the engine from the vehicle, do not allow it to contact the vehicle.

**NOTE:** Engine wiring harness will be removed with engine.

## 102. Transfer original components from original engine to new engine

- a. Transfer the following components from the **OLD** engine assembly to the **NEW** engine assembly.
- Engine Wiring Harness
  - Generator
  - A/C Compressor
  - Drive Belt Tensioner
  - Drive Belts
  - Misc. hoses/brackets


### 1. REMOVE GENERATOR ASSEMBLY



|  |                          |   |   |
|--|--------------------------|---|---|
|  | Remove in this Direction | - | - |
|--|--------------------------|---|---|


1. Remove the 2 bolts and 2 nuts.
2. Using an E8 "TORX" socket wrench, remove the 2 stud bolts and generator assembly.
3. Remove the generator assembly as shown in the illustration.

### 2. REMOVE COMPRESSOR WITH MAGNET CLUTCH



1. Remove the 2 bolts and 2 nuts.
2. Using an E8 "TORX" socket wrench, remove the 2 stud bolts and compressor with magnet clutch.

### 3. INSTALL COMPRESSOR WITH MAGNET CLUTCH



1. Using an E8 "TORX" socket wrench, temporarily install the compressor with magnet clutch with the 2 stud bolts.

**Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}**

2. Install the compressor with magnet clutch with the 2 bolts and 2 nuts in the order shown in the illustration.

### 4. INSTALL GENERATOR ASSEMBLY



1. Using an E8 "TORX" socket wrench, temporarily install the generator assembly with the 2 stud bolts.


**Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}**

2. Install the generator assembly with the 2 bolts and 2 nuts.

**Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}**


5. **Open V35A-FTS Engine Serial Number Registration Website**

- a. Open the 24LA04 serial number registration website by selecting the following link:  
<https://24la04.imagespm.info/>
- b. Confirm language of website




- c. Enter your dealer login credentials and follow the instructions to complete the engine serial number registration process.  
**Username: Dealer code**  
**Password: XXXXX**

**Note: Default password is XXXXX. This password can be changed by the dealership after the first login. Please make sure all eligible technicians in your dealership know the password for your dealership.**



- d. Enter VIN




- e. Register original and new engine serial numbers.
- i. Enter **Original** Engine Serial Number (can be found on front of engine block or on sticker on top of intercooler)
  - ii. Upload photo of **New** Engine Serial Number
  - iii. Scan **New** Engine Serial Number (can be found on sticker on top of intercooler)
  - iv. Enter Technician Name
  - v. Enter Technician Email
  - vi. Enter Spin Number

NOTE: In order to register the serial number, the website requires a record of an engine being ordered for that VIN. If the VIN you enter goes to the parts order screen an engine has not yet been ordered for this vehicle.

The screenshot shows the 'Serial Number Registration' page on the Toyota website. The page is titled 'Serial Number Registration' and has a sub-header '1. Enter Original Engine Serial Number'. It features three main sections: 1. A photo of an engine block with a serial number 'A087945' visible. 2. A section for uploading a photo of the engine serial number, with a 'Choose File' button and the text 'No file chosen'. 3. A section for scanning the new engine serial number from the intercooler barcode, with a 'USE ATTACHED SCANNER' button. Below these sections are input fields for '4. Technician Name', '5. Technician Email', and '6. Technician SPIN Number'. At the bottom are 'SUBMIT' and 'BACK' buttons. A sidebar on the right contains a warning message: 'If the new engine serial number cannot be scanned in due to the intercooler label being damaged or missing, please contact quality\_compliance@toyota.com with the following information:' followed by a bulleted list: Dealer Code, Technician Name, SPIN Number, Original Engine Serial Number on Block, and Photo of New Engine Serial Number on Block.

 If you have any issues, please email [quality\\_compliance@toyota.com](mailto:quality_compliance@toyota.com) for further assistance.

f. Confirm all information was input correctly as shown below.



The screenshot shows a Toyota web portal interface. At the top left is the Toyota logo and the text "TOYOTA | Engine May Stall During Driving". At the top right are links for "Home | Reset Password | Sign Out". The main heading is "Serial number confirmation" with a "PRINT" button to its right. Below the heading is a message: "If you have any issues, please email [quality\\_compliance@toyota.com](mailto:quality_compliance@toyota.com) for further assistance." A photograph of an engine block is shown, with a metal plate on the block containing the numbers "22" and "076". Below the photo, the following information is displayed: "VIN: STF [redacted]", "Dealer Code: [redacted]", "Dealer Name: [redacted]", "SPIN ID: XXXXXXXX9456", "Technician Name: John Doe", "Original Serial number: A087945", and "New Engine Serial number: A453047".



**Once a new engine serial number is registered to a VIN it must be used in that vehicle, no exceptions!**

**If you have any issues, please email [quality\\_compliance@toyota.com](mailto:quality_compliance@toyota.com) for further assistance.**

## 6. INSTALL ENGINE ASSEMBLY

**NOTICE:** Carefully read the cautions written in the repair manual and perform the written instructions correctly.



Ensure oil dip stick tube is not impacted during engine install. Impact to dip stick tube can cause tube to become unseated which can cause an oil leak. If you have any issues, please email [quality\\_compliance@toyota.com](mailto:quality_compliance@toyota.com) for further assistance.




Ensure torque converter is seated correctly as shown below before installing engine assembly. If torque converter is not completely seated, damage may occur to transmission or engine. If you have any issues, please email [quality\\_compliance@toyota.com](mailto:quality_compliance@toyota.com) for further assistance.

OK




NG



## 1. INSTALL ENGINE ASSEMBLY

! i, ii



- Slowly lower the engine into the engine compartment.
- Using a 17 mm hexagon wrench, install the front engine mounting insulator LH and front engine mounting insulator RH with the 4 hexagon socket head cap bolts.

**Torque: 144 N·m {1468 kgf·cm, 106 ft·lbf}**

## 2. INSTALL BELL HOUSING BOLTS

|    |             |    |                                       |
|----|-------------|----|---------------------------------------|
| *1 | Drive Plate | *2 | Crankshaft                            |
| *a | Matchmark   | *b | Torque Converter Assembly Centerpiece |
|    | Knock Pin   |    | Bolt A                                |
|    | Bolt B      |    | Clutch Spline Grease                  |

1. Confirm that the 2 knock pins are installed to the engine assembly and are not damaged.
2. Make sure that the matchmark is positioned as shown in the illustration.
3. Apply clutch spline grease to the surface of the crankshaft that contacts the torque converter assembly centerpiece.

**Clutch Spline Grease:**  
**Toyota Genuine Clutch Spline Grease or equivalent**

**Maximum Grease Amount:**  
**Approximately 1 g (0.0353 oz.)**

4. While keeping the engine assembly and automatic transmission assembly horizontal, align the 2 knock pins with the holes in the automatic transmission assembly and install the automatic transmission assembly with the 11 bolts.

**Torque:**  
**for bolt A :**  
**71 N·m {724 kgf·cm, 52 ft·lbf}**

**for bolt B :**  
**37 N·m {377 kgf·cm, 27 ft·lbf}**

**NOTE:**

- Do not use excessive force when installing the automatic transmission assembly.
- When mounting the automatic transmission assembly to the engine assembly, make sure to securely fit the 2 knock pins into the knock holes.
- When tightening the bolts, make sure that the contact surfaces of the engine assembly and the automatic transmission assembly are in close contact with one another.
- When installing the automatic transmission assembly, make sure that the oil cooler tube does not become damaged.
- Check that the torque converter assembly rotates smoothly after installation of the automatic transmission assembly.

| Item   | Length           |
|--------|------------------|
| Bolt A | 50 mm (1.97 in.) |
| Bolt B | 45 mm (1.77 in.) |

### 3. INSTALL DRIVE PLATE AND TORQUE CONVERTER SETTING BOLT



- a. Install the torque converter assembly to the drive plate and ring gear sub-assembly with the 6 drive plate and torque converter setting bolts through the flywheel housing cover hole.


**Torque: 64 N·m {653 kgf·cm, 47 ft·lbf}**

**NOTE:**

- Start by tightening the positioning drive plate and torque converter setting bolt (black), and then uniformly tighten the remaining 5 drive plate and torque converter setting bolts (silver).
- Turn the crankshaft to a position where the drive plate and torque converter setting bolts can be installed, and install the drive plate and torque converter setting bolts while securing the crankshaft pulley bolt with a wrench.

- b. Install flywheel housing cover


#### 4. INSTALL STARTER ASSEMBLY



#### Torque:

Starter assembly : 46 N·m {469 kgf·cm, 34 ft·lbf}

Engine wire : 9.8 N·m {100 kgf·cm, 87 in·lbf}




#### 5. INSTALL STARTER COVER

- c. Temporarily install the starter cover with the bolt and nut.
- d. Tighten the bolt and nut in the order shown in the illustration.

Torque: 11.5 N·m {117 kgf·cm, 8 ft·lbf}

## 6. INSTALL CONVERTER WITH CATALYST ASSEMBLY RH


- e. Temporarily install a **NEW** gasket to the converter with catalyst assembly RH.
- f. Using a plastic-faced hammer and wooden block, tap in the gasket until its surface is flush with the converter with catalyst assembly RH.



|    |              |   |   |
|----|--------------|---|---|
| *1 | Gasket       | - | - |
| *a | Wooden Block | - | - |

### NOTE:

- Be sure to install the gasket so that it faces the correct direction.
- Do not reuse the OLD gasket.
- Do not damage the **NEW** gasket.



|    |  |    |  |
|----|--|----|--|
| *1 | Converter With Catalyst Assembly RH                | *2 | Turbine Outlet Elbow Gasket RH                                   |
| *a | 1.5 mm (0.0590 in.) or less                        | *b | Knock Pin  |
| *c | Alignment Protrusion on Exhaust Pipe Clamp Side RH | *d | Alignment Protrusion on Converter With Catalyst Assembly RH Side |
| *e | Position Alignment Range                           | -  | -  |

- g. Install a **NEW** turbine outlet elbow gasket RH to the converter with catalyst assembly RH as shown in the illustration.

**NOTE:** When reusing the converter with catalyst assembly RH, thoroughly clean the gasket groove so that no old gasket remains. Fully insert the **NEW** gasket into the gasket groove of the converter with catalyst assembly RH.

- h. Set a **NEW** exhaust pipe clamp RH to the converter with catalyst assembly RH.

**NOTE:** Make sure the end of the exhaust pipe clamp RH does not open 140 mm (5.51 in.) or more (standard amount approximately 60 mm (2.36 in.)).

- i. Temporarily install the converter with catalyst assembly RH to the manifold stay with the nut.

**NOTE:** Tighten the nut by hand until it contacts the surface.

- j. Align the converter with catalyst assembly RH with the knock hole on the No. 2 turbocharger sub-assembly side to connect the converter with catalyst assembly RH.

**NOTE:** Make sure that there is a knock pin on the converter with catalyst assembly RH.

- k. Align the flange surfaces of the No. 2 turbocharger sub-assembly and converter with catalyst assembly RH, and then temporarily install the exhaust pipe clamp RH.

**NOTE:** Make sure that there is a knock pin on the converter with catalyst assembly RH.

- l. Align the position alignment protrusions on the exhaust pipe clamp RH side to within the range of the position alignment protrusions on the converter with catalyst assembly RH side.

- m. Tighten the exhaust pipe clamp RH.

**Torque: 25 N·m {255 kgf·cm, 18 ft·lbf}**

- n. Tighten the nut.


**Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}**

- o. Connect the converter with catalyst assembly RH to the front exhaust pipe assembly with the 2 compression springs and 2 bolts.

**Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}**

## 7. INSTALL CONVERTER WITH CATALYST ASSEMBLY LH


- p. Temporarily install a **NEW** gasket to the converter with catalyst assembly LH.
- q. Using a plastic-faced hammer and wooden block, tap in the gasket until its surface is flush with the converter with catalyst assembly LH.



|    |              |   |   |
|----|--------------|---|---|
| *1 | Gasket       | - | - |
| *a | Wooden Block | - | - |

### NOTE:

- Be sure to install the gasket so that it faces the correct direction.
- Do not reuse the OLD gasket.
- Do not damage the **NEW** gasket.



|    |  |    |  |
|----|--|----|--|
| *1 | Converter With Catalyst Assembly LH                | *2 | Turbine Outlet Elbow Gasket LH                                   |
| *a | 1.5 mm (0.0590 in.) or less                        | *b | Knock Pin  |
| *c | Alignment Protrusion on Exhaust Pipe Clamp Side LH | *d | Alignment Protrusion on Converter With Catalyst Assembly LH Side |
| *e | Position Alignment Range                           | -  | -  |

- r. Install a **NEW** turbine outlet elbow gasket LH to the converter with catalyst assembly LH as shown in the illustration.

**NOTE:** When reusing the converter with catalyst assembly RH, thoroughly clean the gasket groove so that no old gasket remains. Fully insert the **NEW** gasket into the gasket groove of the converter with catalyst assembly LH.

- s. Set a **NEW** exhaust pipe clamp LH to the converter with catalyst assembly LH.

**NOTE:** Make sure the end of the exhaust pipe clamp RH does not open 140 mm (5.51 in.) or more (standard amount approximately 60 mm (2.36 in.)).

- t. Temporarily install the converter with catalyst assembly LH to the manifold stay with the nut.

**NOTE:** Tighten the nut by hand until it contacts the surface.

- u. Align the converter with catalyst assembly LH with the knock hole on the No. 1 turbocharger sub-assembly side to connect the converter with catalyst assembly LH.

**NOTE:** Make sure that there is a knock pin on the converter with catalyst assembly LH.

- v. Align the flange surfaces of the No. 1 turbocharger sub-assembly and converter with catalyst assembly LH, and then temporarily install the exhaust pipe clamp LH.

**NOTE:** Make sure that there is a knock pin on the converter with catalyst assembly LH.

- w. Align the position alignment protrusions on the exhaust pipe clamp LH side to within the range of the position alignment protrusions on the converter with catalyst assembly LH side.

- x. Tighten the exhaust pipe clamp LH.





**Torque: 25 N·m {255 kgf·cm, 18 ft·lbf}**

- y. Tighten the nut.


**Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}**

- z. Connect the converter with catalyst assembly LH to the front exhaust pipe assembly with the 2 compression springs and 2 bolts.

**Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}**

|   |   |
|---|---|
|    | <p><b>8. INSTALL NO. 2 TURBO INSULATOR</b></p> <p>Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}</p>   |
|    | <p><b>9. INSTALL NO. 4 TURBO INSULATOR</b></p> <p>Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}</p>   |
|   | <p><b>10. CONNECT TRANSFER BREATHER HOSE SUB-ASSEMBLY</b></p> <p><b>NOTICE:</b> The transfer breather hose sub-assembly can be connected without tilting the automatic transmission assembly with transfer assembly. When tilting the automatic transmission assembly with transfer assembly, do not tilt it excessively to allow the cooling fan and fan shroud to contact each other.</p> |
|  | <p><b>11. INSTALL TRANSMISSION CONTROL CABLE INSULATOR</b></p> <p>a. Install the transmission control cable insulator to the automatic transmission assembly with the 2 bolts.</p> <p><b>NOTICE:</b> Tightening order: Temporarily install bolt A and bolt B → Tighten bolt A → Tighten bolt B</p> <p>Torque: 12 N·m {122 kgf·cm, 9 ft·lbf}</p>   |

## 12. CONNECT TRANSMISSION/TRANSFER CASE WIRE HARNESS CONNECTIONS AND BRACKETS



| *a | Transmission Wire Connector | *b | TCM connector |
|----|-----------------------------|----|---------------|
|    | Connector                   |    | Bolt          |
|    | Push Up                     |    | Securely Lock |


- a. Connect the wire harness to the automatic transmission assembly with transfer assembly with the 5 bolts.

**Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}**

- b. Attach the clamp.
- c. Connect the 5 connectors.


**NOTE: Push up the lever until the claw of the transmission wire connector makes a connection sound. Securely lock the TCM connector lever.**

### 13. INSTALL NO. 2 MANIFOLD STAY




Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}

### 14. INSTALL NO. 2 MANIFOLD STAY




Torque: 43 N·m {438 kgf·cm, 32 ft·lbf}




### 15. CONNECT AIR FUEL RATIO SENSOR

- a. Connect the air fuel ratio sensor connector
- b. Attach the wire harness clamp




### 16. CONNECT NO. 2 AIR FUEL RATIO SENSOR

- a. Connect the air fuel ratio sensor connector
- b. Attach the 4 wire harness clamps



### 17. CONNECT NO. 3 AIR FUEL RATIO SENSOR


- a. Connect the air fuel ratio sensor connector
- b. Attach the 3 wire harness clamps




### 18. CONNECT NO. 4 AIR FUEL RATIO SENSOR

- a. Connect the air fuel ratio sensor connector
- b. Attach the 2 wire harness clamps

### 19. INSTALL FRONT PROPELLER SHAFT ASSEMBLY



- a. Completely remove any oil, etc. and clean the contact surfaces of the 2 propeller shaft flanges, differential flange and transfer flange.
- b. Temporarily install the front propeller shaft assembly to the transfer and differential in the order shown in the illustration.




|    |           |   |   |
|----|-----------|---|---|
| *a | Matchmark | - | - |
|----|-----------|---|---|

- c. Align the matchmarks on the propeller shaft flange and differential flange.
- d. Install the front propeller shaft assembly with the 4 nuts and 4 washers.

**Torque: 88.3 N·m {900 kgf·cm, 65 ft·lbf}**

- e. Align the matchmarks on the propeller shaft flange and transfer flange.
- f. Install the front propeller shaft assembly with the 4 nuts and 4 washers.

**Torque: 88.3 N·m {900 kgf·cm, 65 ft·lbf}**



## 20. INSTALL NO. 2 PROPELLER SHAFT HEAT INSULATOR

- a. Install the No. 2 propeller shaft heat insulator with the 2 bolts.

**Torque: 15.7 N·m {160 kgf·cm, 12 ft·lbf}**

**NOTICE:** Install so that the direction of the arrow points to the front of the vehicle.

## 21. CONNECT NO. 1 COOLER REFRIGERANT DISCHARGE HOSE



- a. Connect the compressor connector.
- b. Remove the vinyl tape from the No. 1 cooler refrigerant discharge hose and connecting part of the compressor with magnet clutch and then sufficiently apply compressor oil to a **NEW** O-ring and the fitting surface of the No. 1 cooler refrigerant discharge hose.

Compressor Oil: ND-OIL 12 or equivalent

- c. Install the **NEW** O-ring to the No. 1 cooler refrigerant discharge hose.

**NOTICE:** Keep the **NEW** O-ring and O-ring fitting surface free of foreign matter.


- d. Install the No. 1 cooler refrigerant discharge hose to the compressor with magnet clutch with the bolt.

**Torque: 9.8 N·m {100 kgf·cm, 87 in·lbf}**

**NOTICE:** Make sure not to cut the O-ring while installing it. (Cut O-rings cannot be installed.)

- e. Connect the connector.

## 22. CONNECT SUCTION HOSE SUB-ASSEMBLY



- a. Remove the vinyl tape from the suction hose sub-assembly and connecting part of the compressor with magnet clutch and then sufficiently apply compressor oil to a **NEW** O-ring and the fitting surface of the suction hose sub-assembly.

Compressor Oil: ND-OIL 12 or equivalent

- a. Install the **NEW** O-ring to the suction hose sub-assembly.


**NOTICE:** Keep the O-ring and O-ring fitting surface free of foreign matter.

- b. Install the suction hose sub-assembly to the compressor with magnet clutch with the bolt.

**Torque: 9.8 N·m {100 kgf·cm, 87 in·lbf}**

**NOTICE:** Make sure not to cut the O-ring while installing it. (Cut O-rings cannot be installed.)

## 23. REMOVE SERVICE ENGINE HOOKS/BOLTS FROM NEW ENGINE








|    |                     |    |                     |
|----|---------------------|----|---------------------|
| *1 | No. 1 Engine Hanger | *2 | No. 2 Engine Hanger |
|----|---------------------|----|---------------------|


**NOTE: DO NOT DISCARD ENGINE HOOKS OR BOLTS.**

- a. Remove the No. 1 engine hanger and No. 2 engine hanger with the 4 bolts as shown in the illustration.

## 24. CONNECT ENGINE WIRE




|    |                |    |                |
|----|----------------|----|----------------|
| *A | for Upper Side | *B | for Front Side |
| *C | for Rear Side  | *D | for RH Side    |
| *E | for LH Side    | -  | -              |



- 25. CONNECT NO. 1 VACUUM HOSE CONNECTOR**
- b. Align the No. 1 vacuum hose connector with the vacuum pump assembly, and push them together until the No. 1 vacuum hose connector makes a "click" sound.

## 26. CONNECT OUTLET HEATER WATER HOSE B




|    |          |   |         |
|----|----------|---|---------|
| *a | Retainer | - | -       |
|    | Push     |   | Push in |

**NOTE:** Check that there is no damage or foreign matter on the connecting parts of the water lines.

- Connect the outlet heater water hose B connector to the No. 4 water by-pass pipe as shown in the illustration.
- Push in the retainer.
- Check that the No. 4 water by-pass pipe and outlet heater water hose B are securely connected by pulling on them.

## 27. CONNECT HEATER WATER HOSE L




|    |          |   |         |
|----|----------|---|---------|
| *a | Retainer | - | -       |
|    | Push     |   | Push in |

**NOTE:** Check that there is no damage or foreign matter on the connecting parts of the water lines.

- Connect the heater water hose L connector to the water by-pass pipe as shown in the illustration.
- Push in the retainer.
- Check that the No. 4 water by-pass pipe and outlet heater water hose B are securely connected by pulling on them.

## 28. CONNECT NO. 4 WATER BY-PASS HOSE




|    |          |   |         |
|----|----------|---|---------|
| *a | Retainer | - | -       |
|    | Push     |   | Push in |


- c. Connect the No. 4 water by-pass hose assembly connector to the water by-pass hose assembly.

**NOTE:** Check that there is no damage or foreign matter on the connecting parts of the water lines.

- d. Align the protrusion of the water by-pass pipe assembly with the cutout in the No. 4 water by-pass hose assembly connector and securely insert the No. 4 water by-pass hose assembly connector to the stopper of the pipe.
- e. Push in the retainer.
- f. Check that the water by-pass pipe assembly and No. 4 water by-pass hose assembly connector are securely connected by pulling on them.




## 29. CONNECT NO. 3 WATER BY-PASS HOSE




## 30. CONNECT NO. 4 WATER BY-PASS HOSE

### 31. CONNECT NO. 1 FUEL VAPOR FEED HOSE



### 32. INSTALL FAN SHROUD



- a. Install the fan pulley to the engine water pump assembly.
- b. Place the fan shroud together with the fluid coupling assembly with fan between the radiator and engine.

**NOTE:** Be careful not to damage the radiator core.

- c. Temporarily install the fluid coupling assembly with fan to the engine water pump assembly with the 4 nuts. Tighten the nuts as much as possible by hand.
- d. Attach the claws of the fan shroud to the radiator as shown in the illustration.
- e. Install the fan shroud with the 2 bolts.


**Torque: 6.5 N·m {66 kgf·cm, 58 in·lbf}**



- f. Tighten the 4 nuts of the fluid coupling assembly with fan.

**Torque: 21 N·m {214 kgf·cm, 15 ft·lbf}**

### 33. INSTALL FAN AND GENERATOR V BELT

**NOTE:** When re-using the fan and generator V belt, check the entire circumference of the belt for wear and cracks on the ribs and rear side. Replace belts where wear and cracks have advanced to the wire core and belts with missing rib rubber.



|   |                        |   |                                  |
|---|------------------------|---|----------------------------------|
| *1  | Generator Assembly     | *2  | Water Pump Assembly              |
| *3  | Crankshaft Pulley      | *4  | V-ribbed Belt Tensioner Assembly |
| *a  | Correct                | *b  | Incorrect                        |
| *c  | 5 mm Hexagon Wrench    | -   | -                                |
|  | Turn in this Direction |  | Remove the 5 mm hexagon wrench   |


- Set the fan and generator V belt onto each part.
- Rotate the V-ribbed belt tensioner assembly clockwise, and then remove the 5 mm hexagon wrench.



**NOTE:** Make sure that the fan and generator V belt is properly installed to each pulley.

- Check that the belt fits properly in the ribbed grooves.

### 34. INSTALL NO. 1 V BELT (COOLER COMPRESSOR TO CRANKSHAFT PULLEY)

**NOTE:** When re-using the No. 1 V belt (cooler compressor to crankshaft pulley), check the entire circumference of the belt for wear and cracks on the ribs and rear side. Replace belts where wear and cracks have advanced to the wire core and belts with missing rib rubber.




|   |                                 |   |                                  |
|---|---------------------------------|---|----------------------------------|
| *1  | Crankshaft Pulley               | *2  | No. 2 Idler Pulley Sub-assembly  |
| *3  | Compressor Assembly with Pulley | *4  | V-ribbed Belt Tensioner Assembly |
| *a  | Correct                         | *b  | Incorrect                        |
| *c  | 5 mm Hexagon Wrench             | -   | -                                |
|  | Turn in this Direction          |  | Remove the 5 mm hexagon wrench   |

- Set the No. 1 V belt (cooler compressor to crankshaft pulley) onto each part.
- Rotate the V-ribbed belt tensioner assembly clockwise, and then remove the 5 mm hexagon wrench.


**NOTE:** Make sure that the No. 1 V belt (cooler compressor to crankshaft pulley) is properly installed to each pulley.

Check that the belt fits properly in the ribbed grooves.



### 35. CONNECT ENGINE WIRE



Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}



### 36. INSTALL NO. 1 AIR TUBE SUPPORT

Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}

### 37. INSTALL COOLING FAN WIRE




|    |                                 |    |                                  |
|----|---------------------------------|----|----------------------------------|
| *1 | Crankshaft Pulley               | *2 | No. 2 Idler Pulley Sub-assembly  |
| *3 | Compressor Assembly with Pulley | *4 | V-ribbed Belt Tensioner Assembly |
| *a | Correct                         | *b | Incorrect                        |
| *c | 5 mm Hexagon Wrench             | -  | -                                |
|    | Turn in this Direction          |    | Remove the 5 mm hexagon wrench   |

a. Install the cooling fan wire with the 2 bolts.

Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}


- b. Connect the connector A.
- c. Connect connector B and lock it with the lever.

**NOTE:** When connecting the connectors, make sure that dirt, water or other foreign matter does not become stuck between the connectors and other parts. Make sure that the lever are securely locked.




### 38. CONNECT NO. 10 ENGINE WIRE

Torque: 10 N·m {102 kgf·cm, 7 ft·lbf}



### 39. INSTALL NO. 6 TURBO INSULATOR


Torque: 25 N·m {255 kgf·cm, 18 ft·lbf}




### 40. INSTALL FUEL TUBE SUB-ASSEMBLY

- a. Connect the fuel tube sub-assembly.
- b. Attach the 2 clamps and install the fuel tube sub-assembly.

### 41. CONNECT FUEL TUBE SUB-ASSEMBLY



- a. Connect the fuel tube sub-assembly.
- b. Install the fuel pipe clamp.




#### 42. INSTALL NO. 2 AIR INLET DUCT

Torque:

bolt: 10 N·m {102 kgf·cm, 7 ft·lbf}

hose clamp: 4.0 N·m {41 kgf·cm, 35 in·lbf}




#### 43. INSTALL NO. 1 AIR INLET DUCT


Torque:

bolt: 10 N·m {102 kgf·cm, 7 ft·lbf}

hose clamp: 4.0 N·m {41 kgf·cm, 35 in·lbf}



#### 44. INSTALL NO. 2 PCV HOSE LH (NO. 2 VENTILATION HOSE)






#### 45. INSTALL NO. 2 PCV HOSE RH (NO. 2 VENTILATION HOSE)

#### 46. CONNECT ENGINE WIRE

**NOTE:** After disconnecting the wire harness, secure it with tape or equivalent to keep it out of the way.


\*A






0

|    |             |   |   |
|----|-------------|---|---|
| *A | for LH Side | - | - |
|----|-------------|---|---|

\*A




0

|   |             |   |       |
|---|-------------|---|-------|
| *A  | for RH Side | -   | -     |
|  | Bolt        |  | Nut A |
|  | Nut B       | -   | -     |

**Torque:**  
**for bolt :**  
**20 N·m {204 kgf·cm, 15 ft·lbf}**  
**for nut A :**  
**10 N·m {102 kgf·cm, 7 ft·lbf}**  
**for nut B :**  
**8.0 N·m {82 kgf·cm, 71 in·lbf}**

## 47. CONNECT ECM




- a. Install the ECM with the 3 bolts.

**Torque: 13 N·m {133 kgf·cm, 10 ft·lbf}**

**NOTE: If the ECM has been struck or dropped, replace it.**

- b. Attach the 2 wire harness clamps.  
 c. Connect the 3 connectors to the ECM and push down the lever to lock it.  
 d. Attach the 2 wire connector clamps.

## 48. INSTALL AIR CLEANER ASSEMBLY LH WITH AIR CLEANER HOSE ASSEMBLY LH



\*a Upper Side

\*b RH Side


- a. Attach the 3 grommets to install the air cleaner assembly LH with air cleaner hose assembly LH.  
 b. Tighten the hose clamp in the position shown in the illustration.

**Torque: 2.8 N·m {29 kgf·cm, 25 in·lbf}**

**NOTE: Make sure that the clamp bolt of the hose clamp are within the area shown in the illustration.**

- c. Attach the clamp and connect the connector.

### 49. INSTALL AIR CLEANER ASSEMBLY RH WITH AIR CLEANER HOSE ASSEMBLY RH




|    |            |    |         |
|----|------------|----|---------|
| *a | Upper Side | *b | RH Side |
|----|------------|----|---------|

- a. Attach the 3 grommets to install the air cleaner assembly RH with air cleaner hose assembly RH.
- b. Tighten the hose clamp in the position shown in the illustration.

**Torque: 2.8 N·m {29 kgf·cm, 25 in·lbf}**


**NOTE: Make sure that the clamp bolt of the hose clamp are within the area shown in the illustration.**

- c. Attach the clamp and connect the connector.




### 50. INSTALL BATTERY AND BATTERY CARRIER ASSEMBLY


**Torque: 21 N·m {214 kgf·cm, 15 ft·lbf}**




### 51. INSTALL ENGINE SIDE UNDER COVER RH



### 52. INSTALL REAR ENGINE SIDE UNDER COVER ASSEMBLY LH




### 53. INSTALL UPPER ENGINE SIDE UNDER COVER PLATE LH



### 54. INSTALL OIL COOLER TUBE AND OIL COOLER HOSE WITH OIL COOLER ASSEMBLY

### 55. CONNECT OIL COOLER TUBE SUB-ASSEMBLY



|    |  |    |                                     |
|----|--|----|-------------------------------------|
| *a | Paint Mark                             | *b | Stopper                             |
| *c | -1.5 to 1.5 mm (-0.0591 to 0.0591 in.) | *d | 2.0 to 7.0 mm (0.0787 to 0.276 in.) |
| *e | 60°                                    | -  | -                                   |

- a. Connect the oil cooler tube sub-assembly to the fan shroud with the 3 bolts.


**Torque: 5.5 N·m {56 kgf·cm, 49 in·lb}**

**NOTE: Tightening order: Temporarily install bolt A → Tighten bolt B → Tighten bolt C → Tighten bolt A**

- b. Connect the oil cooler tube sub-assembly to the radiator assembly and slide the hose clip to secure it as shown in the illustration.

**NOTE: Make sure the oil cooler tube sub-assembly is securely inserted to the stopper.**

## 56. CONNECT OIL COOLER ASSEMBLY WITH OIL COOLER HOSE



|    |                                     |    |  |
|----|-------------------------------------|----|--|
| *a | Paint Mark                          | *b | Stopper                                |
| *c | 2.0 to 5.0 mm (0.0787 to 0.197 in.) | *d | -1.5 to 1.5 mm (-0.0591 to 0.0591 in.) |
| *e | 2.0 to 7.0 mm (0.0787 to 0.276 in.) | *f | 120°                                   |
| *g | 60°                                 | *h | Upper Side                             |
| *i | RH Side                             | -  | -                                      |


a. Connect the oil cooler assembly with oil cooler hose to the fan shroud with the 3 bolts.

**Torque: 5.5 N·m {56 kgf·cm, 49 in·lbf}**

**NOTE: Tightening order: Tighten bolt A → Tighten bolt B → Tighten bolt C**

b. Connect the oil cooler assembly with oil cooler hose to the radiator assembly and slide the 2 hose clips to secure it as shown in the illustration.


**NOTE: Install so that the paint mark and positioning stopper are securely overlapped. Make sure the oil cooler assembly with oil cooler hose is securely inserted to the stopper.**



## 57. CONNECT NO. 2 WATER BY-PASS PIPE

**Torque: 5.0 N·m {51 kgf·cm, 44 in·lbf}**

## 58. CONNECT NO. 2 RADIATOR HOSE




|    |                                     |    |         |
|----|-------------------------------------|----|---------|
| *a | Paint Mark                          | *b | Stopper |
| *c | 2.0 to 7.0 mm (0.0787 to 0.276 in.) | *d | 120°    |
| *e | Upper Side                          | *f | RH Side |

- a. Attach the clamp.
- b. Connect the No. 2 radiator hose to the water inlet pipe and slide the hose clip to secure it as shown in the illustration.

**NOTE:** Install so that the paint mark and positioning stopper are securely overlapped.

**NOTE:** Make sure the No. 2 radiator hose is securely inserted to the stopper.

## 59. CONNECT NO. 1 RADIATOR HOSE




|    |                                     |    |         |
|----|-------------------------------------|----|---------|
| *a | Paint Mark                          | *b | Stopper |
| *c | 2.0 to 5.0 mm (0.0787 to 0.197 in.) | *d | 120°    |
| *e | Upper Side                          | *f | RH Side |
| *g | Front Side                          | -  | -       |

- a. Install the No. 1 radiator hose to the water outlet pipe and radiator assembly and slide the 2 hose clips to secure it as shown in the illustration.


**NOTE:** Install so that the paint mark and positioning stopper are securely overlapped.

**NOTE:** Make sure the No. 1 radiator hose is securely inserted to the stopper.






### 60. CONNECT NO. 3 WATER BY-PASS HOSE

### 61. CONNECT ENGINE COOLANT TEMPERATURE SENSOR



### 62. INSTALL RADIATOR RESERVE TANK ASSEMBLY



|   |                                     |   |         |
|---|-------------------------------------|---|---------|
| *a  | Paint Mark                          | *b  | Stopper |
| *c  | 2.0 to 5.0 mm (0.0787 to 0.197 in.) | *d  | 30°     |
| *e  | Upper Side                          | *f  | RH Side |
|  | Bolt A                              |  | Bolt B  |

- a. Install the radiator reserve tank assembly to the radiator assembly with the 3 bolts.


**Torque: 7.0 N·m {71 kgf·cm, 62 in·lbf}**

- b. Connect the radiator reserve tank hose to the radiator assembly and slide the hose clip to secure it as shown in the illustration.

**NOTE: Install so that the paint mark and positioning stopper are securely overlapped.**

**NOTE: Make sure the radiator reserve tank hose is securely inserted to the stopper.**

### 63. CONNECT NO. 2 WATER BY-PASS HOSE




|    |                                     |    |         |
|----|-------------------------------------|----|---------|
| *a | Paint Mark                          | *b | Stopper |
| *c | 2.0 to 5.0 mm (0.0787 to 0.197 in.) | *d | 25°     |
| *e | Rear Side                           | *f | RH Side |

a. Connect the No. 2 water by-pass hose to the water inlet pipe and slide the hose clip to secure it as shown in the illustration.


**NOTE:** Install so that the paint mark and positioning stopper are securely overlapped.

**NOTE:** Make sure the No. 2 water by-pass hose is securely inserted to the stopper.



### 64. CONNECT OUTLET HEATER WATER HOSE

### 65. CONNECT NO. 2 WATER BY-PASS HOSE




|    |                                     |    |         |
|----|-------------------------------------|----|---------|
| *a | Paint Mark                          | *b | Stopper |
| *c | 2.0 to 7.0 mm (0.0787 to 0.276 in.) | *d | 120°    |
| *e | Rear Side                           | *f | RH Side |

a. Connect the No. 2 water by-pass hose to the water inlet pipe and slide the hose clip to secure it as shown in the illustration.

**NOTE:** Install so that the paint mark and positioning stopper are securely overlapped.

**NOTE:** Make sure the No. 2 water by-pass hose is securely inserted to the stopper.

## 66. CONNECT NO. 3 WATER BY-PASS HOSE



|    |                                     |    |         |
|----|-------------------------------------|----|---------|
| *a | Paint Mark                          | *b | Stopper |
| *c | 2.0 to 5.0 mm (0.0787 to 0.197 in.) | *d | 60°     |
| *e | Upper Side                          | *f | RH Side |

- a. Connect the No. 3 water by-pass hose to the radiator reserve tank assembly and slide the hose clip to secure it as shown in the illustration.


**NOTE:** Install so that the paint mark and positioning stopper are securely overlapped.

**NOTE:** Make sure the No. 3 water by-pass hose is securely inserted to the stopper.

- b. Attach the clamp

## 67. INSTALL COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY

**NOTE:** To prevent damage to the windshield glass, remove any foreign matter (sand, dust, etc.) from around the contacting surfaces of the cowl top ventilator louver sub-assembly and windshield glass.



## 68. INSTALL COWL TOP VENTILATOR LOUVER RH

## 69. INSTALL COWL TOP VENTILATOR LOUVER LH

## 70. INSTALL HOOD TO COWL TOP SEAL

## 71. INSTALL ENGINE SIDE COVER RH


## 72. INSTALL ENGINE SIDE COVER LH

### 73. INSTALL WINDSHIELD OUTSIDE MOULDING RH

### 74. INSTALL WINDSHIELD OUTSIDE MOULDING LH

### 75. INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY RH

**NOTE:** To prevent damage to the windshield glass, remove any foreign matter (sand, dust, etc.) from around the contacting surfaces of the cowl top ventilator louver sub-assembly and windshield glass.



- a. When reusing the front wiper arm and blade assembly RH:
- A. Clean the wiper arm serrations to remove any burrs, dirt, etc.

**NOTE:** Do not grind down the wiper arm serrations.

- b. Set the automatic stop position by the below procedure.
- A. Turn the ignition switch to ON.
  - B. Operate the windshield wipers while spraying washer fluid onto the windshield glass. Make sure that the windshield wipers function properly and the wipers do not contact the vehicle body.
  - C. Turn the ignition switch off.
- c. Temporarily install the front wiper arm and blade assembly RH with the nut to the position shown in the illustration.


d. Install the front wiper arm and blade assembly RH with the nut to the position shown in the illustration.

**Torque: 26 N·m {265 kgf·cm, 19 ft·lbf}**

**NOTE: Hold the arm hinge by hand when tightening the nut.**

## 76. INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY LH

**NOTE: To prevent damage to the windshield glass, remove any foreign matter (sand, dust, etc.) from around the contacting surfaces of the cowl top ventilator louver sub-assembly and windshield glass.**



e. When reusing the front wiper arm and blade assembly LH:

A. Clean the wiper arm serrations to remove any burrs, dirt, etc.

**NOTE: Do not grind down the wiper arm serrations.**

f. Set the automatic stop position by the below procedure.

A. Turn the ignition switch to ON.

B. Operate the windshield wipers while spraying washer fluid onto the windshield glass. Make sure that the windshield wipers function properly and the wipers do not contact the vehicle body.

C. Turn the ignition switch off.


- g. Temporarily install the front wiper arm and blade assembly LH with the nut to the position shown in the illustration.
- h. Install the front wiper arm and blade assembly LH with the nut to the position shown in the illustration.

**Torque: 26 N·m {265 kgf·cm, 19 ft·lbf}**

**NOTE: Hold the arm hinge by hand when tightening the nut.**

## 77. INSTALL FRONT WIPER ARM HEAD CAP

## 78. INSTALL HOOD SUB-ASSEMBLY



**Torque:**


**for bolt A :**

**17.5 N·m {178 kgf·cm, 13 ft·lbf}**


**for bolt B :**

**13 N·m {133 kgf·cm, 10 ft·lbf}**

**NOTE: Be sure to perform this procedure with several people as the hood sub-assembly is very heavy.**



**79. CONNECT WINDSHIELD WASHER HOSE ASSEMBLY**



**80. INSTALL HOOD INSULATOR**

**81. INSTALL BATTERY**

- e. Install battery
- f. Install battery clamp sub assembly

**Torque: 18.5 N·m {189 kgf·cm, 14 ft·lbf}**

- g. Install No. 2 Battery Carrier Bracket

**Torque: 7.6 N·m {77 kgf·cm, 67 in·lbf}**


- h. Connect cable to positive battery terminal

**Torque: 4.8 N·m {49 kgf·cm, 42 in·lbf}**


- i. Connect cable to negative battery terminal

**Torque: 5.4 N·m {55 kgf·cm, 48 in·lbf}**


**82. INSTALL V-BANK COVER SUB-ASSEMBLY**




**83. INSTALL UPPER RADIATOR SUPPORT SEAL**




**84. INSTALL FRONT FENDER APRON TRIM PACKING  
A**




**85. INSTALL FRONT FENDER APRON TRIM PACKING  
B**






**86. INSTALL FRONT FENDER APRON TRIM PACKING  
C**



**87. INSTALL FRONT FENDER APRON TRIM PACKING  
D**

**88. INSTALL FRONT WHEELS**



|    |                     |    |                     |
|----|---------------------|----|---------------------|
| *A | for 5 Bolt Axle Hub | *B | for 6 Bolt Axle Hub |
|----|---------------------|----|---------------------|

- a. While aligning the wheel assembly with the center of the axle hub, install the axle hub nuts by hand.
- b. Temporarily tighten the axle hub nuts in the order shown in the illustration.
- c. Lower the vehicle then fully tighten the axle hub nuts in the order shown in the illustration.

**Torque: 131 N·m {1336 kgf·cm, 97 ft·lbf}**

## 89. CHARGE AIR CONDITIONING SYSTEM WITH REFRIGERANT (RM100000001ZTOL)


**NOTE:** Charge refrigerant in accordance with the equipment manual.

- a. Perform vacuum purging using a vacuum pump or appropriate equipment.

**NOTE:** Be sure to use a refrigerant recovery unit that is compatible with HFO-1234yf (R1234yf) systems.

- b. Charge the air conditioning system with refrigerant.

**Refrigerant Type: HFO-1234yf (R1234yf)**



|    |                        |    |                            |
|----|------------------------|----|----------------------------|
| *a | Standard Charge Amount | *b | Mean Value in Proper Range |
| *c | Overcharged            | *d | High Pressure              |
| *e | Sub-cool System        | *f | Refrigerant Amount         |
| *g | +/-30 g (+/-1.05 oz)   | -  | -                          |

| COOL BOX     | REFRIGERANT CHARGING AMOUNT      |
|--------------|----------------------------------|
| w/o Cool Box | 920 to 980 g (32.5 to 34.5 oz)   |
| w/ Cool Box  | 1040 to 1100 g (36.7 to 38.8 oz) |

**NOTE:** Do not turn the A/C switch on before charging the air conditioning system with refrigerant. Doing so may cause the compressor to work without refrigerant, resulting in overheating of the compressor. The refrigerant amount should be checked by quantity (weight). The graph above is shown for reference only.

**NOTE:** Ensure that sufficient refrigerant is available to recharge the system when using a refrigerant recovery unit. Refrigerant recovery units are not always able to recover 100% of the refrigerant from an air conditioning system.

## 90. ADD ENGINE COOLANT (RM100000002080B)

### NOTE:

- Do not remove the reserve tank cap or drain cock plug while the engine and radiator assembly are still hot. Pressurized, hot engine coolant and steam may be released and cause serious burns.
  - To prevent injury due to contact with an operating fan and generator V belt or cooling fan, keep your hands and clothing away from the fan and generator V belt and cooling fans when working in the engine compartment with the engine running.
  - Do not substitute plain water for engine coolant.
  - Before adding coolant, turn the A/C switch off.
- a. Remove the reserve tank cap.
  - b. Remove the radiator drain cock and remove the O-ring from the radiator drain cock.
  - c. Inject the specified concentration of coolant through the radiator side drain cock until the radiator is full.

### Specified Capacity: 14.7 liters (15.5 US qts, 12.9 Imp. qts)

- d. Squeeze the No. 1 radiator hose and No. 2 radiator hose several times by hand, and then check the level of the engine coolant.
  - i. If the engine coolant level is low, add engine coolant.
- e. Install a **NEW** O-ring to the radiator drain cock and install the radiator drain cock.
- f. Install the reserve tank cap.

### Torque: 2.0 N·m {20 kgf·cm, 18 in·lbf}

NOTE: Keep the O-ring and O-ring fitting surface free of foreign matter.



**DO NOT START ENGINE UNTIL AFTER INTERCOOLER COOLANT IS ADDED IN STEP 76.**

- g. Bleed air from the cooling system.
  - ii. Warm up the engine until the water inlet with thermostat sub-assembly opens. While the water inlet with thermostat sub-assembly is open, circulate the engine coolant for several minutes.

### NOTE:

- Make sure that the radiator reserve tank assembly still has some engine coolant in it.
  - If the engine coolant temperature gauge indicates an excessive temperature, turn off the engine and let it cool.
  - If there is not enough engine coolant, the engine may overheat or be seriously damaged.
  - If the radiator reserve tank assembly does not have enough engine coolant, perform the following: 1) stop the engine, 2) wait until the engine coolant cools down, and 3) add engine coolant until the radiator reserve tank assembly is filled to the full line.
- iii. Maintain the engine speed at 2500 to 3000 rpm.
  - iv. Squeeze the No. 1 radiator hose and No. 2 radiator hose several times by hand to bleed air.

### NOTE:

- Because the engine, radiator assembly, No. 1 radiator hose and No. 2 radiator hose are extremely hot, do not perform these procedures without wearing protective gloves.
  - Performing these procedures without wearing protective gloves could result in burns.
  - Touching rotating components such as the cooling fan could result in your hand or clothing getting caught and pulled in.
- h. Stop the engine, and wait until the engine coolant cools down.
  - i. After the engine coolant cools down, check that the coolant level is at the F line. If the coolant level is below the F line, add engine coolant to the F line.
  - j. Inspect for coolant leaks.

## 91. ADD INTERCOOLER COOLANT (RM100000002080D)

### NOTE:


- Do not remove the reserve tank cap (for Intercooler) while the coolant (for Intercooler) is still hot. Pressurized, hot coolant and steam may be released and cause serious burns.
- k. When using the GTS:
    - v. Remove the reserve tank cap (for Intercooler).
    - vi. Add engine coolant to the intercooler reserve tank filler opening until it is filled to the F line at shown in the illustration.

**Standard capacity: 3.8 liters (4.0 US qts, 3.3 Imp. qts)**

**NOTE: Never use water as a substitute for coolant.**

- vii. While adding coolant so that the coolant level is kept near the F line in the intercooler reserve tank, activate the electric water pump assembly for approximately 1 minute and then stop pump operation for 1 minute. At that time, check that air bubbles are discharged to the intercooler reserve tank.

### Powertrain > Engine > Active Test



Standard: Repeat this operation approximately 3 times until the sound of the electric water pump assembly gets smaller and no more bubbles are visible from the intercooler reserve tank or the coolant level in the intercooler reserve tank stabilizes. When this condition is reached, this indicates that air is completely bled from the coolant system.

**NOTE: If the intercooler reserve tank is filled excessively with coolant, coolant may spill out when the electric water pump assembly is stopped.**

- viii. When air is completely bled, add coolant up to the F line in the intercooler reserve tank, and install the reserve tank cap (for Intercooler).
- ix. Install the reserve tank cap (For Intercooler)

- x. Start the engine
- xi. In order to operate the electric water pump assembly, maintain the engine speed at 2000 rpm or higher with the shift lever in N or P for 1 minute and then stop operation for 1 minute. Repeat this operation approximately 2 times until the sound of the electric water pump assembly gets smaller and no more bubbles are visible from the intercooler reserve tank or the coolant level in the intercooler reserve tank stabilizes

**NOTE:**

- Performing these procedures without wearing protective gloves could result in burns.
- Be careful as the radiator hoses are hot.
- Keep your hands away from the cooling fan.
- Make sure that the coolant level in the intercooler reserve tank does not drop below the L line when the engine speed is 2000 rpm or higher.
- Immediately after starting the engine, if the intercooler reserve tank runs out of coolant, perform the following: 1) stop the engine, 2) wait until the coolant has cooled down, and 3) pour in coolant until it reaches the F line.

- xii. Stop the engine and wait until the coolant cools down to ambient temperature.
- xiii. Check that the coolant level is between the F and L lines.


1. If the coolant level is lower than the L line, pour coolant of the specified concentration into the intercooler reserve tank until it reaches the F line, and repeat the procedure from steps
2. If the coolant level is above the F line, drain coolant so that the coolant level is between the F and L lines.

- l. Inspect for coolant (for intercooler) leaks.

**92. CHECK ENGINE OIL LEVEL RM10000000200DL**


- a. The oil level should be between the dipstick's low level mark and full level mark. The **NEW** engine comes prefilled with enough oil for shipping (approximately 1 quart) and if necessary, you may add oil. Warm up and stop the engine, and then wait for 5 minutes.

**NOTE:** Do not add engine oil to above the full level mark.




**93. INSTALL OIL PAN PROTECTOR ASSEMBLY (w/ Oil Pan Protector)**

**Torque: 50 N·m {510 kgf·cm, 37 in·lbf}**




**94. INSTALL FRONT TRANSMISSION UNDER COVER ASSEMBLY (w/o Oil Pan Protector)**

**Torque: 50 N·m {510 kgf·cm, 37 in·lbf}**




**95. INSTALL FRAME UNDER COVER ASSEMBLY LH**

Torque: 29 N·m {296 kgf·cm, 21 in·lbf}




**96. REMOVE FRAME UNDER COVER ASSEMBLY RH**

Torque: 29 N·m {296 kgf·cm, 21 in·lbf}



**97. REMOVE NO. 2 ENGINE UNDER COVER ASSEMBLY**

Torque: 29 N·m {296 kgf·cm, 21 in·lbf}



**98. REMOVE NO. 1 ENGINE UNDER COVER ASSEMBLY**

Torque: 29 N·m {296 kgf·cm, 21 in·lbf}



Ensure oil dip stick tube is seated correctly after installing engine. If oil dip stick tube is not completely seated, damage may occur to engine. If you have any issues, please email [quality\\_compliance@toyota.com](mailto:quality_compliance@toyota.com) for further assistance.

a. Restore the vehicle to its original condition.

**◀ VERIFY REPAIR QUALITY ▶**

- Confirm **NEW** engine assembly is properly installed.
- Confirm cooling system is properly bled before test drive.
- Test drive vehicle to ensure engine is installed properly.
- Confirm that no new DTCs were introduced during the repair.
- Confirm the original serial number is registered in the website correctly.
- Confirm the new serial number is registered in the website correctly.
- Confirm fluids are topped off.


If you have any questions regarding this update, please contact your regional representative.

**VII. CRATE USED ENGINE FOR PARTS RECOVERY**

Following the [job aid](#), crate the used engine for parts return.

**VIII. APPENDIX**

**A. CAMPAIGN DESIGNATION DECODER**



**Examples:**

**19LA01 = Launched in 2019, Lexus, Safety Recall Remedy Phase, 1<sup>st</sup> Safety Recall Launched in 2019**

**20LC02 = Launched in 2020, Special Service Campaign, 2<sup>nd</sup> Special Service Campaign Launched in 2020**

**21LE05 = Launched in 2021, Customer Support Program, 5<sup>th</sup> Customer Support Program Launched in 2021**