 <b>HYUNDAI</b>   NEW THINKING. NEW POSSIBILITIES. <b>Technical Service Bulletin</b>		GROUP	NUMBER
		AUTOMATIC TRANSMISSION	12-AT-009-2
		DATE	MODEL
		MAY 2012	Tucson (LM), Santa Fe (CM), Sonata (YF), Elantra (UD/MD), Accent (RB), Azera (TG/HG)
SUBJECT:		ATM INPUT AND OUTPUT SPEED SENSOR DTC P0717, P0721 AND P0722	

*This TSB supersedes bulletin 12-AT-009-1 to correct the OP Times and OP Codes.*

**Description:** Do not replace the transmission for the DTC listed below. Instead, follow the repair procedure and replace the related part.

Applicable Vehicles:	Model Year(s)		Model
	2010 ~		Tucson (LM) & Santa Fe (CM)
	2011 ~		Sonata (YF)/HEV, Elantra (UD/MD) & Azera (TG)
	2012 ~		Accent (RB) & Azera (HG)

#### DTC LIST:

DTC	DESCRIPTION	SENSOR PNC	HARNESS PNC
P0717	Input/Turbine Speed Sensor 'A' Circuit No Signal	46210A	46307
P0721	Output Speed Sensor Circuit Range/Performance		
P0722	Output Speed Sensor Circuit No Signal		

#### PARTS INFORMATION:

MODEL	ENGINE	INPUT & OUTPUT SENSOR	HARNESS
2010~ Tucson (LM)	2.0L	42620-3B620	46307-3B610
2010~ Tucson (LM)	2.4L	42620-3B620	46307-3B610
2010~ Santa Fe (CM)	2.4L	42620-3B620	46307-3B610
2010~ Santa Fe (CM)	3.5L	42620-3B110	46307-3B020
2011~ Sonata Turbo (YF)	2.0L	42620-3B110	46307-3B020
2011~ Sonata (YF)	2.4L	42620-3B600	46307-3B610
2011~ Sonata HEV (YF HEV)	2.4L	42620-3B620	46307-3B610
2011~ Elantra (MD/UD)	1.8L	42620-26000	46307-3B610
2011 Azera (TG)	3.3L/3.8L	42620-3B110	46307-3B020
2012~ Azera (HG)	3.3L	42620-3B100	46307-3B020
2012~ Accent (RB)	1.6L	42620-26010	46307-3B610

Circulate To: Service Manager, Warranty Manager, Service Advisors, Technicians, Fleet Repair


**SUBJECT:** ATM INPUT AND OUTPUT SPEED SENSOR DTC P0717, P0721 & P0722

**WARRANTY INFORMATION:**

MODEL	OP CODE	OPERATION	OP TIME	CAUSAL PART	OP QTY	NATURE CODE	CAUSE CODE
2012~ Accent 1.6L	45644R00	Remove and replace speed sensor and/or valve body harness	1.5	See Parts Catalog	1	N69	C15
2011~ Elantra 1.8L			1.6				
2010~ Santa Fe 2.4L/3.5L			1.6				
2010~ Tucson 2.0L/2.4L			1.6				
2011~ Sonata 2.0L/2.4L			1.6				
2011 Azera 3.3L/3.8L			1.7				
2012~ Azera 3.3L			1.6				
2011~ Sonata HEV 2.4L			1.6				
All	45644RQ0	GDS Operation	0.3				

**SERVICE PROCEDURE:**

1. Using a GDS, check for DTC in the "Automatic Transaxle" menu. **Record the DTC and description.** Delete the DTC.
2. From the GDS, select the following parameters. Drive the vehicle and monitor the sensors.
  - Vehicle and A/T menu.
  - "Current Data"
  - Input speed and output speed sensors.






3. If the sensors show:
  - Continuous and changing output with changes in vehicle speed, the wiring **currently** has no open/short circuits. Go to Step 5.
  - No continuous and changing output, go to Step 4.
4. Visually check the wiring harness between the PCM and transmission for a damaged wire or short circuit to ground. Check for a damaged pin or pin not fully inserted into the connector.
  - If damage exists, repair or replace the ECM control harness and drive the vehicle to confirm the repair.
  - If not, go to Step 5.
5. Refer to the DTC recorded in Step 1 and follow the repair procedure shown below:

DTC	REPAIR PROCEDURE
P0717-Input/Turbine Speed Sensor 'A' Circuit	Go to Step 6 and replace the input/output speed sensor <u>and</u> valve body harness.
P0721-Output Speed Sensor Circuit Range/Performance	
P0722-Output Speed Sensor Circuit No Signal	

6. Remove the battery and battery tray.
7. Remove the undercover below the transmission.
8. Drain the radiator and remove the lower radiator hose from the radiator.  
Drain the ATF.
9. Use a screwdriver to release the tab and remove the solenoid connector on top of the case.

Remove the bolt that secures the connector and push the connector into the transmission.





10. Remove the oil pan bolts and remove the pan.




**CAUTION**

Use rubber hammer to tap the oil pan cover on a corner until the cover is loose.

11. Use a small screwdriver to pry the connector from the oil temperature sensor.




12. Remove three bolts to the solenoid valve connector.






13. Pull the solenoid connector outward and move the connector out of position.




14. Remove the bolt that secures the detent spring and remove the spring.


Torque: 8~11 lb.ft (1.2~1.6 kgf.m)



15. Remove 8 bolts in the order shown and remove the valve body.



16. Use a screwdriver to depress the locking tab and pull outward on the connector to the input and output speed sensor.




17. Remove two bolts that secure the valve body harness to the case.

Pull the connector downward out of the case.

Install a new harness and insert the connector into the case. Attach the retainer and bolt on top of the case as shown in Step 9.

Install the bolts that secure the harness.


Torque: 6~7 lb.ft (0.9~1.0 kgf.m)



18. Remove two bolts that secure the input and output speed sensor and remove the sensor.

Install a new input/output speed sensor in the reverse order of assembly and tighten the bolts to specification.


Torque: 6~7 lb.ft (0.9~1.0 kgf.m)






19. Confirm the O-rings are installed correctly in the case.

Reconnect the input and output speed sensor connector to the harness.




20. Align the manual shaft to the shift lever and install the valve body.



21. Install the valve body bolts and torque the bolts to specification in the order shown.


Toque: 6~7 lb.ft (0.9~1.0 kgf.m)



22. Reconnect the solenoid harness to the solenoids and oil temperature sensor.

Install the bolts to the solenoid harness connector and torque to specification.

Torque: 6~7 lb.ft (0.9~1.0 kgf.m)



23. **STEEL OIL PAN:**


Apply Permatex Ultra Gray Sealer or Hyundai Ultra Gray Gasket Sealer, P/N 00232-19039, to the oil pan and reinstall the pan.

**PLASTIC OIL PAN:**

Install a new gasket to the oil pan and reinstall the pan.

Tighten the bolts to specification.

Torque: 6~7 lb.ft (0.9~1.0 kgf.m)



24. Remove the transaxle fill plug.

Use a funnel to add approximately 5~6 quarts of SPH-IV ATF through the fill plug opening. Reinstall the fill plug.

Attach the GDS to the DLC and select vehicle, A/T menu, Current Data and "Oil Temperature Sensor".

Start the engine and shift to Park. When the ATF is 122°F~140°F (50~60°C), remove the level checking plug. The level is correct when oil flows out of the level checking plug in a thin steady stream.

Collect and dispose of any excess fluid in accordance with local regulations.

Filling and checking of fluid level is done through valve body side cover



Fill Plug shown



Level Checking Plug

ATF TEMPERATURE = 122 ~ 140F (50~60C)  
SHIFT LEVER IN "P" AND ENGINE RUNNING

25. Clear the codes and test drive the vehicle for two drive cycles (two key-on to key-off driving cycles).



26. If the DTC return, perform the following repairs:

DTC	REPAIR PROCEDURE
P0717-Input/Turbine Speed Sensor 'A' Circuit No Signal	<ul style="list-style-type: none"><li>• Repair or replace the control harness between the PCM and the transmission.</li><li>• Test drive the vehicle for two drive cycles. If the DTC return again, replace the PCM.</li></ul>
P0721-Output Speed Sensor Circuit Range/Performance	
P0722-Output Speed Sensor Circuit No Signal	

27. Drive the vehicle to confirm the transmission is operating as designed.