


D/C Cut Fuse Installation During PDS

Service Category General

Section Pre-Delivery Service

Market USA



Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2015	RC F, RC350	

REVISION NOTICE

October 16, 2014 Rev1:

- The entire bulletin has been updated.

Any previous printed versions of this bulletin should be discarded.

Introduction

To minimize battery discharge during transportation and storage, the D/C Cut fuse has been removed at the assembly plant and temporarily stored in the blank space of the relay block in the engine compartment.

During Pre-Delivery Service (PDS), reinstall the D/C Cut fuse into its original location.

Warranty Information


OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	–	–	–	–

D/C Cut Fuse Installation During PDS

Installation Procedure

Remove the D/C Cut fuse from the blank space of the relay block in the engine compartment and install it in the location shown in Figure 1 during Pre-Delivery Service (PDS).

Figure 1.



1	Relay Block
2	Remove This D/C Cut Fuse

3	Install D/C Cut Fuse Here (Original Location)
---	---

NOTE

- RC 350 fuse rating: 30A.
- RC F fuse rating: 20A.
- Removing the D/C Cut fuse cuts OFF power sources relating to the DOME and MPX-B.
- While the vehicle is stored at the dealership, disconnect the negative (-) battery terminal to prevent battery discharge. Refer to Service Bulletin No. [PG001-06](#), "Battery Maintenance for In-Stock Vehicles & Pre-Delivery," for battery maintenance information.