



SP 8-600-003
SERVICE PROGRAM

August, 2014

ATTENTION:

Service Managers / Parts Managers

SUBJECT:

Autocar Xpert HVAC Performance Upgrade

DESCRIPTION OF SERVICE PROGRAM:

This Service Program is one of three different programs providing instructions to upgrade the HVAC on certain Autocar Xpert vehicles. Your vehicle may or may not be affected by this Service Program. Confirm your vehicle's VIN against the list beginning on page 25. If your vehicle's VIN is not present on the list you may want to consult Service Program SP 8-600-001 or SP 8-600-002.

PROGRAM EXPIRES:

August 31, 2015

VEHICLES AFFECTED:

There are 65 affected vehicles with serial numbers in the range 213288 through 216745. Refer to the VIN list beginning on Page 25.

SERVICE RESPONSIBILITY:

Service Programs are performed on eligible vehicles at no charge to the owner until the expiration date listed above.

SERVICE PROGRAM INFORMATION:

Service Programs are product modifications and/or product improvements that Autocar has determined will enhance the operation of the truck. In a continuing effort to inform our customers of potential service issues and avoid unnecessary down time, Autocar has identified the following operation as recommended preventive maintenance. This Service Program should be added to your preventive maintenance and service manuals.

While being committed to continuous product improvement, Autocar is not liable for updating existing chassis after they have been placed in service.

Questions regarding this Service Program should be directed to Autocar Technical Support at 888-218-3611.



SP 8-600-003
SERVICE PROGRAM
August, 2014

REQUIRED PARTS:

- (1) S6004001K003 HVAC Upgrade kit
- (1) A6030018-001 Controller module
- (1) A6000099-001 Capacitor
- (1) A6000098-001 Motor, blower
- (1) A6000100-001 Ground wire
- (1) A8700026-025 25A Fuse, ATO



SP 8-600-003 SERVICE PROGRAM

August, 2014



CAUTION

LOCKOUT/TAGOUT PROCEDURES

Before entering the vehicle or vehicle body, read and follow OSHA regulations concerning entry and working in “CONFINED SPACE” OSHA 1910.146 and “LOCKOUT/TAGOUT” OSHA 1910.147. Follow OSHA regulations while performing any work on the vehicle. The vehicle must be disabled by the following steps before performing any work on the vehicle:

1. Place the transmission in NEUTRAL.
2. Set the parking brake.
3. Shut the engine OFF.
4. Lock cab doors, keep the key in your pocket. Block the wheels before entering the body or performing any work on the vehicle.
5. Turn the battery disconnect switch OFF, if equipped.
6. Completely drain the air from the primary/A system and secondary/B system by opening the drain valves on the air tanks themselves or by using the drain manifold if supplied. When draining the air tanks, do not look into the area where air is draining. Dirt or sludge particles may be expelled in the air stream and can cause eye injury.
7. Place magnetic “DANGER” signs on both cab doors before entering the body or performing any work on the vehicle.
8. Take proper precautions before working under the vehicle. Use ramps approved for the weight of your vehicle, or use floor jacks and stands. Never work under a vehicle supported by jacks alone. Always use jack stands to support the vehicle.



WARNING

Autocar natural gas powered vehicles require specific compliance in the service, storage and refueling procedures.

If you store or dispense Compressed Natural Gas (CNG) or Liquid Natural Gas (LNG), or if you work on CNG or LNG trucks, your location must be fully compliant with applicable codes, regulations and standards, including National Fire Protection Association (NFPA) codes, Society of Automotive Engineers (SAE) standards, American National Standards Institute (ANSI), Natural Gas Vehicle (NGV) standards, the United States Code of Federal Regulations (CFR), and your state and local fire and other applicable codes (including the California Code of Regulations and the Texas Administrative Code, as applicable).

Contact your local fire department for guidance and additional compliance information. Technicians working on Autocar trucks with CNG or LNG engines must be trained in the proper repair of CNG and LNG engines and the safe storage and dispensing of CNG and LNG.



SP 8-600-003

SERVICE PROGRAM

August, 2014

TO OBTAIN PARTS:

Ensure that you have authorization from the customer to perform this work, and send an e-mail to warranty@autocartruck.com which includes the following:

- VIN(s) (or last 6 digits of VIN(s))
- 'Attention To' name
- 'Ship To' address

CLAIMS FOR REIMBURSEMENT:

Submit a claim for reimbursement in accordance with Autocar's Warranty Administration Manual.

CLAIM CODING INFORMATION:

Labor Operation Code Number	Time Allowance SRT	Description
87010-0-03	4.0 HR	HVAC Upgrade

TOOLS REQUIRED:

- 10 mm socket
- Hammer
- Screwdriver
- Poking rod
- Soldering iron
- Black electrical tape

SAFETY NOTICES



WARNING

Allow the vehicle's engine and cooling system to cool to ambient temperature before performing the repair procedure. A hot engine or cooling assembly may cause burns or other personal injury.



WARNING

To prevent eye injury, always wear eye protection when performing vehicle maintenance, service or inspection.



WARNING

Before working on a vehicle, set the parking brake, place the transmission in neutral and block the wheels. Failure to do so can result in unexpected vehicle movement and can cause serious personal injury or death.

SP 8-600-003 SERVICE PROGRAM

August, 2014

HVAC UPGRADE INSTRUCTIONS

Step 1. Remove Lower RH Instrument Panel Trim Panel

1. Remove the three sheet metal screws and set aside for reinstallation (see Figure 1-1).

Note: The fasteners and their quantities as detailed in the following sections may differ slightly depending on age of truck.

2. Remove the trim panel and set aside for reinstallation (see Figure 1-1).




Figure 1-1

Step 2. Remove Lower LH Instrument Panel Trim Panel

1. Remove the five sheet metal screws and set aside for reinstallation (see Figure 2-1).
2. Remove the trim panel and set aside for reinstallation (see Figure 2-1).



Figure 2-1

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 3. Detach Upper Instrument Panel From Outer Support Brackets

1. Remove the bolt/nut assembly on both LH and RH sides of instrument panel and set aside for reinstallation (see Figure 3-1).




Figure 3-1

Step 4. Remove One (Two if equipped) Instrument Clusters

1. Remove the three screw plugs and set aside for reinstallation (see Figure 4-1).
2. Remove the three screws and set aside for reinstallation (see Figure 4-1).
3. With all screws completely removed, pull the lower portion of the cluster outwards (see Figure 4-1).
4. Pull the cluster downward to unhook the upper tabs (see Figure 4-1).




Figure 4-1

SP 8-600-003

SERVICE PROGRAM

August, 2014

5. Using quick-release mechanism on fittings, unhook the green and red airlines from the cluster (see *Figure 4-2*).
6. Disconnect the four electrical connectors from the cluster (see *Figure 4-2*).
7. Remove the instrument cluster and set aside for reinstallation.




Figure 4-2

Step 5. Remove Lower Instrument Panel Skirt

1. Remove the cup holders on either side of the lower instrument panel skirt and set aside for reinstallation (see *Figure 5-1*).
2. Remove the screws securing the lower instrument panel skirt and set aside for reinstallation (see *Figure 5-2*).
3. Remove the lower instrument panel skirt and set aside for reinstallation.




Figure 5-1




Figure 5-2

SP 8-600-003
SERVICE PROGRAM
August, 2014

Step 6. Remove Instrument Panel Middle Bracket Screw

1. Remove the screw and washer and set aside for reinstallation (see *Figure 6-1*).




Figure 6-1

Step 7. Remove Rear Instrument Panel Screws

1. Remove the screws and washers and set aside for reinstallation (see *Figure 7-1*).




Figure 7-1

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 8. Remove Center Console Panel

1. Remove the eight screw caps and set aside for reinstallation (see Figure 8-1).
2. Remove the eight M4 screws and set aside for reinstallation (see Figure 8-1).



Figure 8-1

3. Pull switches out of their slots and break them apart by pushing one down and the other up (see Figure 8-2).




Figure 8-2

4. Push switches through the slots so that the center console panel can be removed (see Figure 8-3).



Figure 8-3

5. Disconnect the transmission shift selector connectors, the mirror switch connectors, the ignition barrel connector, push to start button connector, and the HVAC controller connector and set aside for reinstallation (see Figure 8-4).



Figure 8-4

SP 8-600-003
SERVICE PROGRAM
 August, 2014

6. Remove the gauge panel caps and set aside for reinstallation (see Figure 8-5).

Optional Gauge Locations/Caps




Figure 8-5

7. Disconnect the lighters.



8. Locate the terminals/connectors behind the lighters through the access holes in the center portion of the upper dashboard panel (see Figure 8-6).



Figure 8-6

9. Remove the instrument top panel and set aside for reinstallation.

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 9. Remove Park Brake Valves



In order to remove the main instrument panel, the two park brake valves must be removed (see Figure 9-1).

1. Pull back the rubber grommets and find the yellow handle locating pins (located at the base of the park brake valve yellow handle) (see Figure 9-1).
2. Carefully hammer out the locating pins with a small punch.
3. Remove the yellow handles.
4. Remove the nut clamping the valves to the dashboard and push the valves through into the dashboard and set aside for reinstallation.



Figure 9-1

Step 10. Remove Ducting from the HVAC Case

1. Disconnect the ducting at the HVAC unit end on at all three connection points (see Figure 10-1).



Figure 10-1

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 11. Replace Blower Motor

1. Remove the screw from the HVAC housing and set aside for reinstallation (see Figure 11-1).



Figure 11-1

2. Remove retaining clips securing the head of the HVAC unit along its perimeter and set aside for reinstallation (see Figure 11-2).




Figure 11-2

3. Remove the HVAC unit head (see Figure 11-3).



Figure 11-3

4. Remove the blower motor fan speed control module (see Figure 11-4).




Figure 11-4

SP 8-600-003 SERVICE PROGRAM

August, 2014

5. Remove the three screws which secure the HVAC motor in the housing (see Figure 11-5).




Figure 11-5

6. Remove the motor and discard (see Figure 11-6 and Figure 11-7).

Note: Before the motor can be removed, detach the terminals from the motor power connector so that the wires can be fed through the housing.




Figure 11-6




Figure 11-7

7. Install the new motor (A6000098-001) by performing step 11-1 through step 11-6 in reverse order.

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 12. Install HVAC Capacitor

The new HVAC controller (A6030018-001) requires that a capacitor (A6000099-001) be added to the HVAC harness.

1. Locate connector number 73 (it is located in the area below the LH cup holder in the lower instrument panel skirt which at this point has not been reinstalled – the wires on the female side of the connector are blue, gray, red and purple) (see *Figure 12-1*).



Figure 12-1

2. Splice in the capacitor to the purple and red wires with a soldering iron. Positive (+) to the red wire and Negative (-) or (black electrical tape) to the purple wire. Cable tie capacitor to the HVAC harness (see *Figure 12-2*).




Figure 12-2

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 13. Install Additional Ground Wire

The new blower motor draws a higher current than the discarded unit. Additional grounding is required. This is achieved by adding a ground wire that terminates directly at the cab ground stud in the cab's bulkhead.

1. Splice the new ground wire (A6000100-001) to fan speed control module's lower RH purple wire using a soldering iron (smaller purple wire on RH side of the HVAC housing) (see *Figure 13-1*).
2. The ring terminal on the ground wire must terminate at the RH dashboard mount bracket at the upper mount bolt (see *Figure 13-1*).




Figure 13-1

Step 14. Replace HVAC Circuit's Fuse

1. Locate the LH fuse box behind the LH seat.
2. Remove the 20 Amp fuse from slot F39 (refer to label under fuse bank cover) (see *Figure 14-1*).
3. Install the new 25 Amp fuse (A8700026-025) to location F39 (see *Figure 14-1*).




Figure 14-1

4. Reconnect the ducting at the HVAC unit.
5. Reinstall the instrument panel.

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 15. Reinstall Instrument Panel and Screws Along Windshield

1. Reinstall the instrument panel.
2. Reinstall the screws and washers (see Figure 15-1).

Note: Ensure all the screws have been partially fastened before tightening any of them; use a small screw driver or poking tool to line up the holes in the panel and in the sheet metal.




Figure 15-1

Step 16. Reattach Upper Instrument Panel to Outer Support Brackets

1. Reinstall the bolt/nut assembly on both LH and RH sides of the instrument panel (see Figure 16-1).

Note: The support brackets are slotted – push instrument panel upward while performing step 16-1 to ensure instrument panel is at top of adjustment range.




Figure 16-1

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 17. Reinstall the Park Brake Valves



1. Push the valves through the holes in the dashboard.
2. Clamp the valve to the dashboard using the clamping nut.
3. Push the handles onto the valves.
4. Carefully hammer in the handle locating pins.
5. Pull the rubber grommet over the valve handle's shaft.



Figure 17-1

Step 18. Reconnect the Lighters



1. Locate the lighter harness terminals under the dashboard.
2. Connect the lighter harness connector to the back of the lighter.



Figure 18-1

SP 8-600-003
SERVICE PROGRAM

August, 2014

Step 19. Reinstall Lower RH Instrument Panel Trim Panel

1. Align the lower RH instrument panel trim panel with mounting spring nuts on the upper instrument panel (see Figure 19-1).
2. Reinstall the three sheet metal screws, ensuring they are driven through the spring nuts (see Figure 19-1).




Figure 19-1

Step 20. Reinstall Lower LH Instrument Panel Trim Panel

1. Align the lower LH instrument panel trim panel with mounting spring nuts on the upper instrument panel (see Figure 20-1).
2. Reinstall the three upper sheet metal screws, ensuring they are driven through the spring nuts (see Figure 20-1).
3. Reinstall the lower two sheet metal screws (see Figure 20-1)




Figure 20-1

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 21. Reinstall Upper Instrument Panel Middle Support Bracket Screws

1. Reinstall the screw and washer (see Figure 21-1).




Figure 21-1

Step 22. Reinstall Lower Instrument Panel Skirt

1. Reinstall the five screws securing the lower instrument panel skirt (see Figure 22-1).
2. Reinstall the cup holders and the center storage bin/cover, if equipped (see Figure 22-2).




Figure 22-1




Figure 22-2

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 23. Reinstall the Instrument Cluster

1. Reconnect the four electrical connectors (see *Figure 23-1*).
2. Reconnect the airlines, green to the RH port, red to the LH port (see *Figure 23-1*).




Figure 23-1

6. Reinstall the three screw plugs (see *Figure 23-2*).




Figure 23-2

3. Hook the upper tabs under the upper perimeter of the cluster cut-out in the instrument panel (see *Figure 23-2*).
4. Push the lower portion of the cluster forward, ensuring the cluster bezel locates securely in the cluster cut-out in the instrument panel (see *Figure 23-2*).
5. Reinstall the three screws, ensuring that they are aligned with the spring nuts (see *Figure 23-2*).

SP 8-600-003 SERVICE PROGRAM

August, 2014

Step 24. Install New HVAC Controller



1. Remove the four screws affixing the clamp bracket to the rear of the HVAC controller (see Figure 24-1).




Figure 24-1

2. Remove the clamp bracket (see Figure 24-2).



Figure 24-2

2. Slide the old controller out (see Figure 24-3).



Figure 24-3

3. Install the new controller (A6030018-001) by reversing steps 24-3 to 24-1.

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 25. Reconnect the Center Console Panel Controls

1. Reconnect the transmission shift selector connectors (see *Figure 25-1*).
2. Reconnect the mirror switch (A6220043-001) connectors (see *Figure 25-1*).
3. Reconnect the ignition barrel connector and the HVAC controller (A6030018-001) connector (see *Figure 25-1*).

Step 26. Interior Temp Sensor Location Verification

1. Ensure the interior temperature sensor is located correctly on the upper shroud of the LH steering column.




Figure 25-1

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 27. Test the HVAC System



1. Start the engine and let it warm up.
2. Turn on the HVAC system by pressing the increase fan speed button.
3. Test the fan at all speeds.
4. While fan is at max speed, cycle through the 4 vent modes and ensure air is coming out of all the correct vents: panel, floor, windshield, floor and windshield (allow at least 5 seconds for vent selection valve to adjust between modes).
5. Drop the set temp to 64°F and turn on air-conditioning compressor (press frost symbol button). Ensure air becomes cool.
6. Increase set temp to HI while compressor is still running. Ensure that heater core is able to overcome the cooling effect of the evaporator core.
7. While the set temp is at any setting other than “HI” or “LO”, press the defrost button, and ensure the following occur:
 - Only windshield vents should be open.
 - Fan speed should set to highest setting.
 - Air source should be set to fresh air.
 - Pressing the defrost button again should resume previous settings.
8. Set fan speed to the third speed level and check instrument cluster for stop or check engine lights. If either of these lamps is illuminated, check that capacitor has been installed correctly.

Note: *If at any point the stop or check engine lights illuminate, check that the capacitor has been installed correctly.*

SP 8-600-003

SERVICE PROGRAM

August, 2014

Step 28. Reconnect Switches

1. Route the switches through the slots in the center console panel in their original locations (see *Figure 28-1*).
2. Reassemble the switch banks in the same configuration that they were before breaking apart in step 8-3 (see *Figure 28-1*).
3. Push the switches through the slots in the center console until they snap into place (see *Figure 28-2*).




Figure 28-1



Figure 28-2

Step 29. Reinstall Center Console Panel

1. Reinstall the eight M4 screws (do not tighten until all the screws have been located and the panel aligned correctly) (see *Figure 29-1*).
2. Reinstall the eight screw caps (see *Figure 29-1*).
3. Reinstall gage panel caps (see *Figure 29-1*).
4. Push switches into their locating slots (see *Figure 29-1*).



Figure 29-1

5. HVAC upgrade is complete.