



Countries: AUSTRALIA, BRAZIL, CANADA, COLOMBIA, UNITED STATES, PUERTO RICO, SOUTH AFRICA
Availability: ISIS, FleetSIS
Major System: TRANSMISSION
Current Language: English
Other Languages: [Francais](#), [Español](#),
Viewed: 4252

Document ID: IK1300015
Revision: 5
Created: 11/21/2006
Last Modified: 4/29/2014
Author: Matthew Boyer

[Less Info](#)

Hide Details

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 717	Not Helpful 511
---------------	------------------------	---	----------------------	-----------	----------------------	--------------------	------------------------

Title: Shift Lever Interlock Solenoid for the Allison Transmission Won't Unlock with Brake Pedal Depressed

Applies To: All with Allison 2000 series transmission with parking pawl

NORMAL OPERATION

The Interlock for Shifter with Park Position feature is controlled by the presence of the ignition signal, accessory signal, the service brake applied signal, the transmission in park signal, and if required, the wheelchair lift door switch signal (door closed). The ESC will ground the Park_Position_Unlock_Solenoid signal when **all** of the above ESC signals are present to energize the lock solenoid to unlock the shifter. Park_Position_Unlock_Solenoid is mapped to pin 6 of connector 1600 on MD and connector 1602 pin 25 on Bus.

FAILSAFE OPERATION


If a 639-14A-5-240 code, loss of communication from the transmission ECU, or a 612-14A-1-1 or 612-14A-1-2 code, brake switch out of range low or high, is active the ESC will also ground pin 6 of the 1600 connector energizing the solenoid.

TROUBLESHOOTING


1. Turn on the ignition and apply the park brake. If the Park light illuminates in the EGC the ignition signal is present.
2. Turn on the windshield wipers. If the windshield wipers operate the accessory signal is present.
3. Depress the brake pedal. If the brake lights illuminate the brake switch applied signal is present.
4. Turn on the ignition and place the transmission in Park. Check the PRDNL display in the EGC. If an underscore is under the P the transmission park signal is present.
5. With the ignition on unplug the brake light switch or switches to get an active 612-14A-1-1 code. The shift solenoid will unlock if the solenoid and the wiring for the solenoid are ok.
6. Bus only Check the status of the Bus_wheelchair_lift_door_input signal in DLB. The status must be 1 for the lift door closed if the bus is equipped with this interlock feature.

CIRCUIT DIAGRAMS

Pre-2008 Models - Pins C and D at the shifter are the power and ground for the shift interlock solenoid in the diagram below.



Post-2008 Models - The Body Controller provides a ground to the interlock solenoid on pin E8 of the J4 (1601) connector.



SIGNALS TO WATCH

Pre-2008 Signals

International® Diamond Logic® Builder

Simulating - 1HTWYAHTX7J542849

File Edit View Advanced Logic Tools Diagnostics Help

Select Advanced Logic Features Faults Connectors Signals Center Panel Cluster Messages

ESC Signals Master List Watched Graph

***Session: Shifter Park Interlock Sol**

Signal	Pins	Signal Type	Value	Unit	Status	W...	...
Accessory	1600-2	Digital Input,...	☒	On/Off	0	☐	☐
Ignition	1600-12	Digital Input,...	☒	On/Off	0	☐	☐
Current Gear		J1939 Input	-125	gears	0	☐	☐
Brake Switch Signal	1600-33,4004-33	Digital Input	☒	On/Off	0	☐	☐
Bus wheelchair_lift_door_input	1600-26	Digital Input	☒	On/Off	0	☐	☐
Park_Position_Unlock_Solenoid			☐	On/Off		☐	☐

Post-2008 Signals

International® Diamond Logic® Builder

Simulating - 1HTWNAZT38J665160

File Edit View Advanced Logic Tools Diagnostics Help

Select Advanced Logic Features Faults Connectors Signals Center Panel Cluster Messages

ESC Signals Master List Watched Graph

***Session: Shifter Park Interlock Sol**

Signal	Pins	Signal Type	Value	Unit	Status	W...	...
Accessory		J1939 Output	☒	On/Off	0	☐	☐
Ignition		J1939 Output	☒	On/Off	0	☐	☐
Brake Switch Signal	1602-E14,1602-E15	Digital Input	☒	On/Off	0	☐	☐
Current Gear			-125	gears	0	☐	☐
Bus wheelchair_lift_door_input	1602-F13	Digital Input	☒	On/Off	0	☐	☐
Park_Position_Unlock_Solenoid	1601-E8	Relay Driver 0...	☐	On/Off	0	☐	☐

Hide Details

Feedback Information

Viewed: 4251

Helpful: 717

Not Helpful: 511

No Feedback Found

