



Countries: AUSTRALIA, BAHAMAS, BOLIVIA, BRAZIL, BELIZE, CANADA, CHILE, COLOMBIA, COSTA RICA, DOMINICAN REPUBLIC, ECUADOR, EL SALVADOR, TRINIDAD AND TOBAGO, UNITED STATES, URUGUAY, VENEZUELA, MEXICO, ARUBA, NICARAGUA, PERU, PUERTO RICO, Curaçao, GUATEMALA, GUYANA, HAÏTI, HONDURAS, JAMAICA, NEW ZEALAND, PANAMA

Document ID: IK1900228

Availability: ISIS, FleetISIS

Revision: 5

Major System: ACCESSORIES

Created: 8/18/2014

Current Language: English

Last Modified: 12/16/2014

Other Languages: NONE

Author: Kevin Kochanek

Viewed: 948

[Less Info](#)

Hide Details

Coding Information

| | | | | | | | |
|----------------------|-------------------------------|--|-----------------------------|------------------|-----------------------------|-------------------------|-----------------------------|
| Copy Link | Copy Relative Link | Bookmark View My Bookmarks | Add to Favorites | Print | Provide Feedback | Helpful 8 | Not Helpful 1 |
|----------------------|-------------------------------|--|-----------------------------|------------------|-----------------------------|-------------------------|-----------------------------|

Title: 2010 and Newer Vehicle Air Conditioning Diagnostics (Start Here)

Applies To: Post 2010 NGV

CHANGE LOG

- 12/11/2014 - Added Pre-2010 information to reference dealer to Pre-2010 Resource Center. Adjusted document to make it easier to find in iKnow.
- 12/8/2014 - Formatted article to template standard.
- 11/13/2014 - Added Other documents from HVAC Resource Center
- 11/06/2014 - Added SRT's adjusted format
- 10/28/2014 - Author updated for feedback purposes

DESCRIPTION

This document addresses Air Conditioning issues on the following 2010 to 2014 vehicles with a BCM.

The following procedures will guide the user through : Common Air Conditioning failure areas, diagnostic tools, SRTs, and warranty filing.

For anything Pre-2010: Please go to the Pre-2010 A/C HVAC Resource Center located at : [IK1900156](#).

SYMPTOM(s)

No cold air, not cold enough, or no air flow though vents.

Diagnostic Trouble Code(s) & Dashboard Indicator Light(s):

| SPN | FMI | Description |
|--------|-----|---|
| 2609 | 16 | A/C High Pressure Protection |
| 1079 | 1 | 5 volt sensor supply below normal |
| 3985 | 9 | A/C Control Head Circuit Failed To Communicate With Body Controller |
| 1552 | 2 | A/C Control Head Temperature Mix DM1 |
| 3981 | 2 | A/C Control Head Mode Fault DM1 |
| 3984 | 2 | A/C Control Head Air Inlet DM1 |
| 2058 | 9 | Rear A/C Data Link Communication Failure |
| 2058 | 14 | Rear A/C Data Link Communication Failure |
| 3982 | 2 | A/C Rear Blower Speed Control Switch Error |
| 3983 | 2 | Rear A/C Temperature Control Switch Error |
| 520465 | 2 | A/C Control Head Multiple Motor Faults |

Customer Observations or Concerns:

- Malfunction Indicator Light (MIL)

- No Cab Air Conditioning
- Not blowing cold enough
- No air flow though vents.
- No Rear Air Conditioning
- Inoperative MaxxPro No Idle Air Conditioning System

SPECIAL TOOL(s) / SOFTWARE

| Tool Description | Tool Number | Comments | Instructions |
|---|-------------|---|----------------|
| Robinair Air Conditioning Machine or equivalent | 34988 | Used for recover, Vacuum, and Performance test A/C system | Not Applicable |

SERVICE PARTS INFORMATION

| Kit Description | Part Number | Quantity Required | Notes |
|-----------------|----------------|-------------------|----------------|
| Not Applicable | Not Applicable | Not Applicable | Not Applicable |

Please see links below for parts information as this article covers multiple models.

[Parts Catalog](#)

PROCEDURE OVERVIEW:

| |
|--|
| NOTE: |
| Do not start engine until steps 2-4 have been completed. If the engine has been run recently, allow the vehicle to sit for one hour to allow system pressures to stabilize. |

Before starting to diagnose the problem, it is important to consider the following:

- Are there Air Conditioning related AFC's open?
- Was the vehicle recently in for an Air Conditioning repair in which the system was not properly filled or serviced?
- Have there been recent Air Conditioning repairs and a fault code not cleared?

If the A/C issue is known (blown off hose, visible dye, inoperative blower motor) go directly to the respective steps or iKNow articles listed below. Otherwise, go to step 1.

- [IK1900226 A/C Control Head Issues](#)
- [IK1900225 A/C Mechanical Pressures diagnostics](#)
- [IK1900223 A/C Sensor/ Electronic Issues](#)
- [IK1900198 12V-No Idle HVAC Unit](#)
- [IK1900227 Rear A/C Electrical and Mechanical Diagnostics](#)

DIAGNOSTIC STEPS

| Step | Action | Decision |
|------|---|---|
| 1 | Customer Interview: Review the Repair Order to determine the following: | Yes: cab A/C works correctly but rear not. Go to step 7. |

| | | |
|--|---|---|
| | <ul style="list-style-type: none"> • Have you had the vehicle serviced recently? When and where? Was there an A/C related service performed during that service? • Does issue concern the passenger compartment, the sleeper, or both? • If equipped with a No-Idle system does the issue only happen when utilizing the No-Idle System? | <p>YES: concern is with MaxxPro No-Idle unit: Go to IK1900198</p> <hr/> <p>No: to step 2.</p> |
| <p>Is the problem confined to the rear A/C system while the Cab A/C works correctly?</p> | | |

| Step | Action | Decision |
|------|--|---|
| 2 | <p>Is the problem confined to the operation or performance of the MaxxPro No Idle system?</p> <p>Preliminary checks:</p> <p>Note: Do not start engine until steps 2-4 have been completed. If the engine has been run recently, allow the vehicle to sit for one hour to allow system pressures to stabilize.</p> <p>Perform a visual check of the A/C system to verify that no obvious problems are present. With the engine off, inspect the following items:</p> <ul style="list-style-type: none"> • Compressor and clutch mounting • Compressor clutch coil wiring and connection • Compressor drive belt and belt tensioner • A/C hoses and connections • Condenser mounting • Condenser fins (blockage by debris) • Receiver-drier mounting • Expansion valve mounting • Filter element • Fresh air module drains • Fresh air module mounting and overall condition • Electrical connections to pressure transducer and low pressure switch • Electrical connections to actuators for airflow doors (recirculate, temperature, and mode doors) • Fan speeds and mode door operation <p>Were any issues found?</p> | <p>Yes: Repair as necessary. Restore sys operational condition and operate the A determine if the complaint was correcte</p> <hr/> <p>No: Go to step 3.</p> |

| Step | Action | Decision |
|------|---|--|
| 3 | <p>Diagnostic Trouble Codes:</p> <p>Check for A/C related DTC's:</p> <p>Are any A/C related DTC's found?</p> | <p>Yes: Go to FAULT CODES in IK190020</p> <hr/> <p>No: Go to step 9.</p> |

| Step | Action | Decision | | | | | | | | | | | | | | | | | | |
|---------|---|------------|---------|------------|-------|--------|----|-------|--------|----|-------|---------|----|-------|---------|----|-------|---------|----|--|
| 4 | <p>Static Pressure:</p> <p>NOTE: Have the engine OFF and A/C system at ambient temperature when measuring static pressure. If the engine has been run recently, allow the vehicle to sit for a minimum of one hour to allow system pressures and temperatures to stabilize.</p> <ol style="list-style-type: none"> 1. Inspect high and low side Schrader valves for presence of dye and pooling of oil in valve. 2. Connect gauges to the A/C system and record static pressure readings. 3. Use a temperature probe to determine the ambient temperature within 1 or 2 degrees. Record the measured temperature. 4. Locate the ambient temperature on the chart below and compare the vehicle's static pressure to the chart pressure. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Temp °F</th> <th>Temp °C</th> <th>R134A PSIG</th> </tr> </thead> <tbody> <tr> <td>40 °F</td> <td>4.4 °C</td> <td>35</td> </tr> <tr> <td>45 °F</td> <td>7.2 °C</td> <td>40</td> </tr> <tr> <td>50 °F</td> <td>10.0 °C</td> <td>45</td> </tr> <tr> <td>55 °F</td> <td>12.8 °C</td> <td>51</td> </tr> <tr> <td>60 °F</td> <td>15.6 °C</td> <td>57</td> </tr> </tbody> </table> | Temp °F | Temp °C | R134A PSIG | 40 °F | 4.4 °C | 35 | 45 °F | 7.2 °C | 40 | 50 °F | 10.0 °C | 45 | 55 °F | 12.8 °C | 51 | 60 °F | 15.6 °C | 57 | <p>Yes: Go to step 5.</p> <hr/> <p>No: Go to Air Conditioning Mechanical Pressures Diagnostics IK1900225</p> |
| Temp °F | Temp °C | R134A PSIG | | | | | | | | | | | | | | | | | | |
| 40 °F | 4.4 °C | 35 | | | | | | | | | | | | | | | | | | |
| 45 °F | 7.2 °C | 40 | | | | | | | | | | | | | | | | | | |
| 50 °F | 10.0 °C | 45 | | | | | | | | | | | | | | | | | | |
| 55 °F | 12.8 °C | 51 | | | | | | | | | | | | | | | | | | |
| 60 °F | 15.6 °C | 57 | | | | | | | | | | | | | | | | | | |

| | | |
|--------|---------|-----|
| 65 °F | 18.3 °C | 64 |
| 70 °F | 21.1 °C | 71 |
| 75 °F | 23.9 °C | 78 |
| 80 °F | 26.6 °C | 86 |
| 85 °F | 29.4 °C | 95 |
| 90 °F | 32.2 °C | 104 |
| 95 °F | 35.0 °C | 113 |
| 100 °F | 37.7 °C | 124 |
| 105 °F | 40.5 °C | 134 |
| 110 °F | 43.3 °C | 146 |

Are the A/C pressures in spec?

| Step | Action | Decision |
|------|---|--|
| 5 | <p>Compressor Engagement:</p> <p>Start engine. Turn the A/C on. Verify compressor engagement.</p> <p>Does the compressor engage?</p> | <p>Yes: Go to step 6.</p> <p>No: Go to Air Conditioning Electrical Diagnostics IK1900223</p> |

| Step | Action | Decision | | | | | | | | | | | | | | | | | | | | | | |
|---------------------------------|---|------------|-------|-------------------------|--|-------------------|--|-------------------|--|--------------------------------|--|----------------------------|--|------------------------------|--|---------------------------------|--|----------------------------|--|------------------------------|--|--------------------------------|--|---|
| 6 | <p>Performance Test: Check the System Performance by performing the following steps:</p> <p>A. Park the vehicle so there is no solar loading and no wind.</p> <p>B. Position a thermometer approximately 30 to 60 cm (12-24 inches) in front of the vehicle grille.</p> <p>C. Engage the engine cooling fan (unless viscous fan drive).</p> <p>D. Close the hood, being careful not to damage the equipment.</p> <p>E. Insert a thermometer into the passenger side, left instrument panel vent. Do not allow the thermometer to touch the sides of the duct. Insert a second thermometer into the lower passenger bunk vent</p> <p>F. Start the engine and raise the idle speed to 1500 rpm.</p> <p>G. Open windows and close both cab doors.</p> <p>H. Set the mode control to: NORM A/C; Highest blower speed; Coldest cooling temperature.</p> <p>I. Operate the system for five minutes, or until gauge readings settle.</p> <p>J. Record the following data:</p> <table border="1" style="width: 100%;"> <thead> <tr> <th>Test Point</th> <th>Value</th> </tr> </thead> <tbody> <tr><td>Ambient Air Temperature</td><td></td></tr> <tr><td>Relative Humidity</td><td></td></tr> <tr><td>Cab Air duct Temp</td><td></td></tr> <tr><td>Low-Side psi @ 1500 RPM</td><td></td></tr> <tr><td>Compressor on (cut-in PSI)</td><td></td></tr> <tr><td>Compressor off (cut-out PSI)</td><td></td></tr> <tr><td>High-Side psi @ 1500 RPM</td><td></td></tr> <tr><td>Compressor on (cut-in PSI)</td><td></td></tr> <tr><td>Compressor off (cut-out PSI)</td><td></td></tr> <tr><td>Lower Passenger bunk vent temp</td><td></td></tr> </tbody> </table> <p>K. Compare gauge readings, vent temperature, ambient temperature, and humidity to the appropriate HVAC System Pressure Test Chart below.</p> <p>Does the Cab and rear HVAC operate correctly?</p> | Test Point | Value | Ambient Air Temperature | | Relative Humidity | | Cab Air duct Temp | | Low-Side psi @ 1500 RPM | | Compressor on (cut-in PSI) | | Compressor off (cut-out PSI) | | High-Side psi @ 1500 RPM | | Compressor on (cut-in PSI) | | Compressor off (cut-out PSI) | | Lower Passenger bunk vent temp | | <p>Yes: System is operating correctly. Discuss concern with customer.</p> <p>No: gauge readings are out of specification. Go to Air Conditioning Mechanical Pressures Diagnostics IK1900225</p> <p>No: gauge readings are correct but cab temperature is out of specification: Go to Air Conditioning Control Head Diagnostics IK1900226</p> |
| Test Point | Value | | | | | | | | | | | | | | | | | | | | | | | |
| Ambient Air Temperature | | | | | | | | | | | | | | | | | | | | | | | | |
| Relative Humidity | | | | | | | | | | | | | | | | | | | | | | | | |
| Cab Air duct Temp | | | | | | | | | | | | | | | | | | | | | | | | |
| Low-Side psi @ 1500 RPM | | | | | | | | | | | | | | | | | | | | | | | | |
| Compressor on (cut-in PSI) | | | | | | | | | | | | | | | | | | | | | | | | |
| Compressor off (cut-out PSI) | | | | | | | | | | | | | | | | | | | | | | | | |
| High-Side psi @ 1500 RPM | | | | | | | | | | | | | | | | | | | | | | | | |
| Compressor on (cut-in PSI) | | | | | | | | | | | | | | | | | | | | | | | | |
| Compressor off (cut-out PSI) | | | | | | | | | | | | | | | | | | | | | | | | |
| Lower Passenger bunk vent temp | | | | | | | | | | | | | | | | | | | | | | | | |

| Step | Action | Decision |
|------|------------------------------|---|
| 7 | <p>Rear A/C Test:</p> | <p>Yes: rear HVAC system operates correctly.</p> |

