TECHNICAL BULLETIN LTB00916NAS3 01 NOV 2016



© Jaguar Land Rover North America, LLC

NOTE: The information in Technical Bulletins is intended for use by trained, professional Technicians with the knowledge, tools, and equipment required to do the job properly and safely. It informs these Technicians of conditions that may occur on some vehicles, or provides information that could assist in proper vehicle service. The procedures should not be performed by 'do-it-yourselfers'. If you are not a Retailer, do not assume that a condition described affects your vehicle. Contact an authorized Land Rover service facility to determine whether this bulletin applies to a specific vehicle.

This reissue replaces all previous versions. Please destroy all previous versions.

	Changes are highlighted in gray		
SECTION: 303-01			
Intake Camshaft Variable Cam Timing Actuator - Component Failure			
AFFECTED VEHICLE RANGE:			
t (LC) 2015 Onwards 503863 Onwards Halewood	GTDi 2.0L Petrol		
Yoque (LV) 2012 Onwards 000447 Onwards Halewood	GTDi 2.0L Petrol		
2013-2015 311358-439912 Halewood	GTDi 2.0L Petrol		
	Aft Variable Car ICLE RANGE: (LC) 2015 Onwards 503863 Onwards Halewood Yoque (LV) 2012 Onwards 000447 Onwards Halewood 2013-2015 311358-439912	-O1 aft Variable Cam Timing Actuator - Com AICLE RANGE: t (LC) 2015 Onwards 503863 Onwards 503863 Onwards Halewood Coque (LV) 2012 Onwards 000447 Onwards 000447 Onwards Halewood 2013-2015 311358-439912 GTDi 2.0L Petrol	-O1 aft Variable Cam Timing Actuator - Component Failure AICLE RANGE: t (LC) 2015 Onwards 503863 Onwards 503863 Onwards GTDi 2.0L Petrol Halewood roque (LV) 2012 Onwards 000447 Onwards 000447 Onwards GTDi 2.0L Petrol Halewood 2013-2015 311358-439912 GTDi 2.0L Petrol

<u>MARKETS:</u>

NAS

CONDITION SUMMARY:

Situation: A rattle noise may be evident from the engine compartment and/or the Malfunction Indicator Lamp (MIL) is illuminated. The Diagnostic Trouble Code (DTC) that may be logged include P0016, P0017, P0026, or P0341.

Cause: This may be caused by the 'stopper' in the intake camshaft Variable Cam Timing (VCT) actuator becoming detached, leading to the VCT actuator not functioning.

Action: Should a customer express this concern, follow the Service Instruction below.

PARTS:


LR085467

Intake camshaft VCT actuator (LR)

<u> TOOLS:</u>


Alignment Tool, Crankshaft Position Sensor JLR-303-1521

1



COMPONENT LOCATION


1. Intake camshaft Variable Camshaft Timing (VCT) actuator location



SERVICE INFORMATION:


1. **ONOTE:** This Service Information is to prevent misdiagnosis.

The exhaust camshaft Variable Camshaft Timing (VCT) actuator unit (shown in blue) has restricted movement when turned. The intake camshaft VCT unit (shown in green) has a less restricted movement when turned.



SERVICE INSTRUCTION:

- 1. Remove the camshaft cover (see TOPIx Workshop Manual section 303-01A / 303-01B: Engine GTDi 2.0L Petrol Valve Cover).
- **2.** Inspect the Variable Camshaft Timing (VCT) actuator.
 - If the VCT actuator is noisy but the 'stopper' is in place, go to Step 3.
 - if the 'stopper' is not in place in the VCT actuator, go to Step 4.




E186694



Fully rotate the camshaft anti-clockwise (1) and then attempt to rotate the camshaft clockwise (2).

- If the camshaft rotates freely in both directions, the VCT actuator is NOT functioning correctly; go to Step 4.
- If no clockwise movement was possible without also rotating the engine, the VCT actuator is functioning correctly.
 - Reverse the removal procedure.



4. Refer to intake camshaft VCT actuator (see TOPIx Workshop Manual section 303-01A / 303-01B: Engine - GTDi 2.0L Petrol - Variable Camshaft Timing Actuator).