



# HYUNDAI

## Technical Service Bulletin

GROUP <b>AUTOMATIC TRANSMISSION</b>	NUMBER <b>17-AT-006</b>
DATE <b>SEPTEMBER, 2017</b>	MODEL <b>SONATA (LFA) 2.0T</b>

**SUBJECT:** AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300, P074800, P075300, P075800, P076300, P076800, P077300 & P270900

**Description:** The 2018 Sonata (LFA) 2.0T is equipped with an 8-speed transmission.

Do not replace the transmission for any of the solenoid DTC listed below. Instead, follow the Service Procedure on Page 2 and replace the related part.

<b>Applicable Vehicles:</b>	2018~ Sonata (LFA) 2.0T
-----------------------------	-------------------------

### Parts Information:

Refer to the PNC in the parts catalog to order the correct solenoid part number.

MODEL	DTC	PART	PNC	PART NUMBER
2018~ Sonata (LFA) 2.0T	P074100	Torque converter clutch system	46202A	46313-3B***
	P074300	Torque converter clutch circuit	46202A	46313-3B***
	P074800	Pressure control solenoid (PC)	46313A	46313-3B***
	P075300	Shift solenoid A (UD)	46313C	46313-3B***
	P075800	Shift solenoid B (46)	46313B	46313-4G***
	P076300	Shift solenoid C (37R)	46313B	46313-4G***
	P076800	Shift solenoid D (OD&LR)	46313C	46313-4G***
	P077300	Shift solenoid E (28)	46313B	46313-4G***
	P270900	Shift control solenoid valve F (SSA)	46313D	46313-3B***
ALL		Valve body internal harness	46307	46307-4G***
		Plastic oil pan gasket	45282E	45283-4G***

### Warranty Information:

MODEL	OP CODE	OPERATION	OP TIME	CAUSAL PART	NATURE CODE	CAUSE CODE
2018~ Sonata (LFA) 2.0L	45775R00	Solenoid replacement	Refer to WEBLTS for current LTS time	Refer to parts catalog	I3A	ZZ3
	45775RQ0	GDS Operation	0.3			

**SUBJECT:**

AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300,  
P074800, P075300, P075800, P076300, P076800, P077300 & P270900

**SERVICE PROCEDURE:**

1. Attach a GDS and select **DTC Analysis** and **A/T** menu. Record the DTC and description. Delete the DTC.
2. From the GDS home screen, select **Data Analysis** and **A/T** menu and the solenoid parameters shown below. If the solenoids show:
  - Continuous and changing output while driving, the wiring **currently** has no open/short circuits. Go to Step 4.
  - No continuous and changing output, go to Step 3.

The screenshot shows the GDS Data Analysis interface for a SONATA(LFA)/2018/G 2.0 T-G.. Transmission. The screen displays a table of sensor data with the following columns: Sensor Name(30), Value, Unit, and Link Up. The data is as follows:

Sensor Name(30)	Value	Unit	Link Up
Shift Control Solenoid Valve (UD/C)	920	mA	
Shift Control Solenoid Valve (46/C)	15	mA	
Shift Control Solenoid Valve (OD&LR)	55	mA	
Shift Control Solenoid Valve (28/B)	50	mA	
Shift Control Solenoid Valve (37R/C)	10	mA	
Pressure Control Solenoid Valve (LP)	665	mA	
ON/OFF Solenoid A (SS-A)	ON	-	
Torque Converter Clutch Solenoid Valve	40	mA	


3. Visually check the wiring harness between the PCM and transmission for a damaged wire or open/short circuit. Check for a damaged pin or pin not fully inserted into the connector.
  - If damage exists, repair or replace the ECM control harness and drive the vehicle to confirm the repair.
  - If no damage or open/short circuit is found, go to Step 4.
4. Refer to the DTC recorded in Step 1 and follow the repair procedure shown below:

DTC		REPAIR PROCEDURE
P074100	Torque converter clutch system	Go to Step 5 and replace the related solenoid <u>and</u> valve body harness.
P074300	Torque converter (T/C)	
P074800	Pressure control solenoid (P/C)	
P075300	Shift solenoid A (UD)	
P075800	Shift solenoid B (46)	
P076300	Shift solenoid C (37R)	
P076800	Shift solenoid D (OD&LR)	
P077300	Shift solenoid E (28)	
P270900	Shift solenoid F (SSA)	

5. Record the preset radio stations.  
Remove the battery and battery tray.
6. Remove the undercover below the transmission.  
Lift the vehicle on a hoist.
7. If necessary to access the solenoids, drain the radiator and remove the lower radiator hose from the radiator.  
Drain the ATF.
8. Disconnect the harness from the transmission.

Remove the bolt that secures the tab and push the harness connector into the transmission.


Disconnect the vent hose on the top of the oil pan.



9. Remove 14 oil pan bolts and remove the pan.

**CAUTION**


Use a rubber hammer to tap the oil pan cover on a corner until the cover is loose.






10. Remove 6 bolts to the harness and 1 bolt to the oil temperature sensor.

Pull the harness outward and move the harness out of position.



11. Remove the bolt that secures the detent spring and remove the spring.

**Torque: 8~11 lb.ft (1.2~1.5 kgf.m/10~13 N.m)**




12. Remove 9 valve body bolts in order from the outermost bolts to the innermost bolts.

Remove the valve body.

**CAUTION**

Place the valve body on a clean paper towel. Placing the valve body on a rag may cause lint to enter the valve body.



**SUBJECT:**AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300,  
P074800, P075300, P075800, P076300, P076800, P077300 & P270900

13. Pull the gray tab up and then press the tab to disconnect the harness from the input speed sensor.


Remove two bolts and remove the input speed sensor.

Remove the harness and install a new harness.

Reinstall the input speed sensor and torque the bolts to specification.


**Torque: 7~9 lb.ft (1.0~1.2 kgf. m/10~12 N.m)**

Reconnect the input speed sensor.



14. Refer to the DTC recorded in Step 1 and replace the related solenoid.


DTC	SOLENOID	
P074100	TC	TC solenoid
P074300	TC	TC solenoid
P074800	PC	Pressure control
P075300	UD	Shift solenoid A (UD)
P075800	46	Shift solenoid B (46)
P076300	37R	Shift solenoid C (37R)
P076800	OD&LR	Shift solenoid D (OD&LR)
P077300	28	Shift solenoid E (28)
P270900	SSA	Shift solenoid F (SSA)



15. **For 28, 46 and 37R solenoids:**

- Remove two bolts to the upper solenoid support. Remove the support.
- Use a magnet to remove the pin for the solenoid to be replaced.
- Remove the solenoid and install a new solenoid.
- Reinstall the pin.
- Reinstall the support and tighten to specification.




**Torque: 7~9 lb.ft (1.0~1.2 kgf. m/10~12 N.m)**





**SUBJECT:**AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300,  
P074800, P075300, P075800, P076300, P076800, P077300 & P270900**16. For UD, OD&LR, SSA, TC and PC solenoids:**


- Use a 5mm hex socket and remove 3 Allen bolts that secure the solenoid support. Remove the support.
- Remove the solenoid and install a new solenoid.
- Reinstall the support and tighten the Allen bolts.

**17. Confirm two O-rings are installed correctly in the case.****18. Align the manual shaft to the shift lever and install the valve body.**

**SUBJECT:**AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300,  
P074800, P075300, P075800, P076300, P076800, P077300 & P270900


19. Install the valve body bolts and torque the bolts in order from the innermost bolts to the outermost bolts.

**Torque: 7~9 lb.ft (1.0~1.2 kgf. m/10~12 N.m)**



20. Reinstall the bolt that secures the detent spring and tighten the bolt to specification.


**Torque: 8~11 lb.ft (1.2~1.5 kgf.m/10~13 N.m)**



21. Reconnect the solenoid harness to the solenoids and install the temperature sensor.

Install 6 bolts to the harness and 1 bolt to the oil temperature sensor and torque to specification.

**Torque: 7~9 lb.ft (1.0~1.2 kgf.m/10~12 N.m)**






**SUBJECT:**AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300,  
P074800, P075300, P075800, P076300, P076800, P077300 & P270900

22. Install a new gasket to the oil pan and reinstall the pan.

Install 14 bolts to the pan and tighten the bolts to specification.

**Torque: 6~7 lb.ft (0.9~1.0 kgf.m/8~9 N.m)**



23. Add ethylene glycol engine coolant to the radiator and check the level according to the appropriate shop manual, "Engine" Section.
24. Reconnect the battery.  
Input the radio stations recorded in Step 5.


25. Remove the transaxle fill plug.

Use a funnel to add approximately 5~6 quarts of SP4-M ATF through the fill plug opening. Reinstall the fill plug.

Attach the GDS and select **Data Analysis, A/T menu** and **Oil Temperature Sensor**.

Start the engine and shift to Park. When the ATF is 122°F~140°F (50~60°C), remove the level checking plug. The level is correct when oil flows out of the level checking plug in a thin steady stream.

Collect and dispose of any excess fluid in accordance with local regulations.





**SUBJECT:**AUTOMATIC TRANSAXLE SOLENOID DTC P074100, P074300,  
P074800, P075300, P075800, P076300, P076800, P077300 & P270900

26. Clear the DTC and test drive the vehicle for two key-on/key-off driving cycles, including 1-2-3-4-5-6-7-8 upshifts and 8-7-6-5-4-3-2-1 downshifts. If the DTC returns, perform the following repairs.

DTC	REPAIR PROCEDURE
P074100	Replace the transmission
P074300	
P074800	
P075300	
P075800	Replace the control wiring harness between the PCM and transmission.
P076300	<ul style="list-style-type: none"> <li>• If the solenoid DTC does not return, return the vehicle to the customer.</li> </ul>
P076800	<ul style="list-style-type: none"> <li>• If the solenoid DTC returns again, replace the PCM.</li> </ul>
P077300	
P270900	
P074100	
P074300	

27. Clear the DTC in the Blue Link system per instructions of TSB 12-BE-005-2.
28. Drive the vehicle to confirm the transmission is operating as designed.