

Countries: CANADA, UNITED STATES Document ID: IK0800549 ISIS, FleetISIS, Body Builder, IsSIR Revision: Availability: Major System: ELECTRICAL SYSTEM Created: 8/30/2017 Current Language: English Last Modified: 10/24/2017 Other Languages: NONE Amber Chapman Author:

506

Less Info

Coding Information Copy Relative Link Add to Favorites Provide Feedback Copy Link Bookmark Print Helpful Not Helpful **...** 00 œ

Viewed.

Title: LT Ultrashift 1321-14 Missing Wire for Crank Signal Feedback

Applies To: LT Ultrashift

CHANGE LOG

Please refer to the change log text box below for recent changes to this article:

10/24/2017 - Corrected typo

10/23/2017 - Added images 2-6 to help clarify installation of the new wire

08/31/2017 - Initial Article Release

DESCRIPTION

This document will guide the user through adding circuit AF17C to address the 1321-14 fault setting in the Eaton Automated Transmission Module. Source Address 3.

SYMPTOM(s)

Diagnostic Trouble Code(s) & Dashboard Indicator Light(s):

DTC/Light	Description
SPN 1321 FMI 14	Engine Starter Solenoid Lockout Relay Driver Circuit

Customer Observations or Concerns:

The missing wire will not cause a customer complaint.

SPECIAL TOOL(s) / SOFTWARE

Tool Description	Tool Number	Comments	Instructions
Tool, Terminal Crimping	ZTSE4181		

Tools Resource Center

SERVICE PARTS INFORMATION

Parts Catalog - Click Here


Part Description	Part Number	Quantity Required	Notes
Terminal, Cable EDU Module Female	2003343C1	11	Package has quantity of 10 terminals


REPAIR STEP(s)

Reference LT / RH Technician Manual (Service and Diagnostic)

Refer to Figure 1. On IP Harness, use 18 gauge wiring to splice into the wire that is going to 1702-16 and add wire 1702-21. Connector 1702 is a 42 pin connector and it is mounted near the wiper bracket in the engine compartment.

 $\label{thm:local_local_selection} \text{Use } \underline{\text{IK0800269 - Proper Wire Repair}} \text{ to find the proper butt connector and heat shrink tubing part numbers}$









 Crimping tool ZTSE4181 or equivalent should be used to ensure a quality crimp is achieved






Figure 5: Locking tabs inside connector body



 Locking tab for the terminal. When inserting the terminal from the rear of the connector you must push forward until an audible click is heard. The click indicates the terminal is fully seated and locked. You should not be able to pull the terminal back out fo the connector.

Figure 6: Terminal installation complete



WARRANTY INFORMATION

Warranty Claim Coding:

Refer to the Warranty Coding Manual for Group and Noun Codes.

Standard Repair Time(s):

Refer to the **SRT Manual** for Repair Times

OTHER RESOURCES

Master Service Information Site



Copyright © 2017 Navistar, Inc.