



Mack Models

Mack Model LEU , LR , MRU - TerraPro , TE - TerraPro , AN - Anthem , CHU - Pinnacle, Axle back , CXU - Pinnacle, Axle front , GR - Granite , GU - Granite , PI - Pinnacle , TD - Titan

Volvo Models

Volvo Model VN1 , VN2 , VNL , VNM , VNR , VNX , VAH , VHD , VT

**** SOLUTION ****

Title Hood Insulation Separating From Hood; Additional Insulation Installation Instructions

Cause Hood Insulation coming detached from the hood.

Solution**Installation instruction:**

1. Buff the hood surface area that will contact the insulation pressure sensitive adhesive (psa) with a clean rag. Wipe the surface thoroughly dry and ensure there is no remaining residue.
2. Visually check the surface. If the surface has oil or grease then use a 50/50 mixture of isopropyl alcohol & water or 3M™ Prep Solvent-70 cleaner to remove oils or grease.
3. Set the insulation in place on the hood.
4. Peel off the paper backing from the insulation and attach the insulation to the back of the hood with the adhesive side facing the hood. Apply enough pressure to ensure good surface contact within 10 minutes of removing the backing.
5. **Using a roller, roll over the entire surface of the insulation, pushing the roller firmly into the insulation. The insulation needs to experience an approximate 15 psi (100 kpa) pressure to ensure proper adhesion to the hood surface.**

Function Group

Function Group 821 engine hood, cover with assembly parts

Customer effect

Main customer effect visual appearance

Conditions

Vehicle operating mode when driving , when stationary

Frequency of occurrence of problem random

Location of problem at front

Administration

Author A241298

Dealer ID A241298

Last modified by RU4469V

Creation date 12-12-2018 22:12

Date of last update 01-02-2019 20:02

Status Published
