L-SB-0021-19 April 22, 2019



Audio Update Phase 3 (Pioneer)

Service

Category Audio/Visual/Telematics

Section Audio/Video Market USA



Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2019	ES300H, ES350, NX300, NX300H, RC F, RC300, RC350, UX200, UX250H	

Introduction

Some 2019 model year Lexus vehicles with a Pioneer audio (version earlier than 1007) may exhibit one or more of the following condition(s).

- Delayed mute operation during hands-free operation
- XM "No Signal" message displayed
- Spanish translation correction
- Voice Recognition is not canceled when receiving a call during VR operation
- Music information does not appear
- Automatic navigation re-routing does not occur
- Update message does not appear via DCM
- Cursor missing after pushing the Map button

Updated software is now available to address these conditions and add Amazon Alexa connectivity with iOS devices. Follow the Software Update Procedure in this bulletin to install the latest software version.

L-SB-0021-19 April 22, 2019 Page 2 of 6

Audio Update Phase 3 (Pioneer)

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
EL1910	Software Update	0.3	86140-33A91 86140-06B01 86140-76360 86140-78510 86140-24460 86140-24261	87	74

APPLICABLE WARRANTY

- This repair is covered under the Lexus Basic Warranty. This warranty is in effect for 48 months or 50,000 miles, whichever occurs first, from the vehicle's in-service date.
- Warranty application is limited to occurrence of the specified condition described in this bulletin.

Software Update Information

MULTIMEDIA TYPE	MODEL	COMPONENT	APPLICABLE FILE ON THE USB DRIVE	
Pioneer Without Navigation With 8-in. Screen	ES		<u>17LDL1NA-EB13 1007.kwi</u>	
Pioneer Without Navigation	UX		17LDL1NA-EB04 1007.kwi	
With 7-in. Screen	RC	DCU	17LDL1NA-EB07 1007.kwi	
Pioneer Without Navigation	NX		17LDL1NA-EB0B 1007.kwi	
With 10.3-in. Screen	RC F		17LDL1NA-EB0C 1007.kwi	

MULTIMEDIA SOFTWARE FILE DOWNLOAD

The multimedia software update files may be downloaded directly from this Service Bulletin by clicking on the file names in the table above. Once downloaded, the files may be extracted (unzipped) from the zip file and saved directly to a blank USB flash drive.

For USB flash drive requirements and download instructions, refer to TIS – Diagnostics – Reprogramming – Reference Documents – Multimedia Software Download Instructions.

Software Update Procedure

- 1. Confirm the software version.
 - A. Start the engine. The Lexus emblem will display on the radio screen.

Figure 1.



B. Wait for the display to switch to the Caution screen, then select Continue.

Figure 2.



- C. Connect the USB flash drive to the USB port.
- D. Press the Menu button, then select Setup.

Figure 3.



Software Update Procedure (continued)

E. Scroll to and select Software Update.

Figure 4.



- F. Confirm the current audio version. Is the current audio version earlier than 1007?
 - YES Continue to step 2.
 - NO This bulletin does NOT apply.
 Continue diagnosis using the applicable Repair Manual.

Figure 5.



- 2. Update the software version.
 - A. Select Update Software.

Figure 6.



Software Update Procedure (continued)


B. Review the Software Update Detail and select OK.

Figure 7.



C. Confirm the Terms of Service and select Agree.

Figure 8.



D. Select Yes.

Figure 9.



Software Update Procedure (continued)

E. While installing the NEW software, do NOT turn off the engine.

Figure 10.



F. When prompted, turn the engine OFF and ON to complete the update.

Figure 11.



G. Confirm the current software version has been updated to 1007 on the Software Update screen.

Figure 12.

