

Service Category

ory Drivetrain

Section Drive Shaft/Propeller Shaft

Market USA



Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2016 - 2019	Tacoma	VDS(s): CZ5AN, GZ5AN, SZ5AN Engine(s): 2GR Drive Type(s): 4WD Transmission(s): 6AT
		Handingsion(3). UAT

REVISION NOTICE

May 20, 2019 Rev2:

Applicability has been updated to include 2018 – 2019 model year Tacoma vehicles.

September 1, 2017 Rev1:

- Applicability has been updated to include 2017 model year Tacoma vehicles.
- The Introduction, Production Change Information, and Repair Procedure sections have been updated.

Any previous printed versions of this bulletin should be discarded.

Introduction

Some 2016 – 2019 model year Tacoma vehicles equipped with an automatic transmission may exhibit a vibration felt in the seat, floorboard, and/or steering wheel between 10 – 30 mph, caused by a driveline vibration under deceleration. Follow the Repair Procedure in this bulletin to address this condition.

NOTE

- This Service Bulletin ONLY applies to 4WD models equipped with 6AT. Do NOT use the spring part number found in the Service Bulletin for ANY manual transmission vehicles or PreRunner models. This could lead to NEW, currently nonexistent issues.
- If the vehicle is installed with an aftermarket suspension/body lift or leveling kit, this Service Bulletin does NOT apply.

Production Change Information

- This bulletin applies to all 2016 2019 model year Tacoma vehicles NOT equipped with the TRD Off-Road package option.
- This Bulletin applies to 2016 model year Tacoma vehicles equipped with the TRD Off-Road package option produced **BEFORE** the Production Change Effective VINs shown below.

CAB TYPE	PRODUCTION CHANGE EFFECTIVE VIN	
	5TFGZ5AN#GX040536	
Double	3TMGZ5AN#GM039554	
Double	5TFCZ5AN#GX040121	
	3TMCZ5AN#GM039538	
Access	5TFSZ5AN#GX017523	

NOTE

ALL TRD Off-Road package vehicles produced AFTER the effective VIN change use the same springs in production as the countermeasure part numbers listed in this Service Bulletin. Do NOT follow this Service Bulletin for TRD Off-Road equipped vehicles produced AFTER production change effective VINs provided in the production change information table.

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
SU1903	Install Steering Wheel Damper and Measure Joint Angle	1.1 (Damper = 0.6) (Measure Angles = 0.5)	45816-60030 48210-04700		
SU1904	Install Steering Wheel Damper, Measure Joint Angle, and R & R Leaf Springs	2.1	48210-04810 48210-04710 48220-04340 48220-04450 48220-04350	9B	57

APPLICABLE WARRANTY

- This repair is covered under the Toyota Basic Warranty. This warranty is in effect for 36 months or 36,000 miles, whichever occurs first, from the vehicle's in-service date.
- Warranty application is limited to occurrence of the specified condition described in this bulletin.



Parts Information

CAB TYPE	PART NUMBER		PART NAME	QTY
CABITPE	PREVIOUS	NEW	FANI IVAIVIL	
Double	48210-04700 48210-04810 48210-04710	48210-04840	Spring Assy, RR RH	1
Double	48220-04340 48220-04450 48220-04350	48220-04480	Spring Assy, RR LH	1
Access	48210-04700 48210-04810 48210-04710	48210-04830	Spring Assy, RR RH	1
Access	48220-04340 48220-04450 48220-04350	48220-04470	Spring Assy, RR LH	1
All	All 45713-35040		Damper, Steering Shake	1

Required Tools & Equipment

SPECIAL SERVICE TOOLS (SST)	PART NUMBER	QTY
Digital Angle Gauge*	<u>01815-00102</u>	1

^{*}Essential SST.

NOTE

Additional SSTs may be ordered by calling 1-800-933-8335.



Repair Procedure

- Confirm the vibration condition exists under the following conditions.
 - Coast down or during braking
 - Speeds between 10 30 mph

NOTE

- Some level of driveline vibration is normal in ALL vehicles.
- The following method can be used to confirm if this bulletin applies to the vehicle.
 - 1. Remove the rear driveshaft.
 - 2. Shift into 4WD HI.
 - 3. Test-drive the vehicle.

Does the vehicle exhibit a vibration under the conditions described above?

- YES Continue to step 2.
- NO This bulletin does NOT apply. Continue diagnosis using the applicable Repair Manual.
- 2. Remove the steering wheel pad.

CAUTION

Wait at LEAST 90 seconds AFTER disconnecting the cable from the negative (-) battery terminal to disable the SRS system.

Refer to the TIS, applicable model and model year Repair Manual:

• <u>2016</u> / <u>2017</u> / <u>2018</u> / <u>2019</u> Tacoma:


Vehicle Interior – Supplemental Restraint Systems – "Supplemental Restraint Systems: Steering Pad: Removal"



Repair Procedure (continued)

3. Remove the steering wheel switch wire harness retainer bracket (ONLY for vehicles with steering wheel mounted switches).

Figure 1.



1 Steering Wheel Switch Wire Harness Retainer Bracket

4. Install the steering wheel damper with two NEW screws in the locations shown.

Torque: 2.35 N*m (24 kgf*cm, 20.8 in*lbf)


NOTICE

When disconnecting ANY airbag connector, take care not to damage the airbag wire harness.

NOTE

Secure the steering wheel switch wires to the steering wheel damper bracket hooks as shown.

Figure 2.



1	Damper
2	Steering Wheel Switch Wire Harness
3	Dam per Bracket Wire Retainer Hook
4	Screw
5	Driver Side Airbag Wire Harness



Repair Procedure (continued)

5. Install the steering wheel pad.

Refer to TIS, applicable model and model year Repair Manual:

• 2016 / 2017 / 2018 / 2019 Tacoma:

Vehicle Interior – Supplemental Restraint Systems – "Supplemental Restraint Systems: Steering Pad: Installation"


6. Raise the vehicle using a drive-on hoist or wheel alignment rack.

NOTE

Vehicle suspension MUST be at ride height.


- 7. Verify which flange type the vehicle is equipped with.
 - Large flange (Figure 3) Continue to step 8.
 - Small flange (Figure 4) Go to step 9.

Figure 3.



1	Up
2	Front
3	Pinion Flange

Figure 4.



1	Up
2	Front
3	Pinion Flange

Repair Procedure (continued)

8. Measure the pinion flange angle (F/A) – Large Flange Type.

NOTE


Make sure to wipe off the area BEFORE taking the pinion flange measurement.

- A. Place the digital angle gauge against the flange surface.
 - (1) Ensure the digital angle gauge is firmly against the flange to obtain an accurate pinion flange angle as shown in Figure 5.

Figure 5.



Figure 6.



1	Up
2	Passenger Side of Vehicle
3	Pinion Flange

(2) Record the pinion flange angle (F/A).

Figure 7.






Repair Procedure (continued)

- 9. Measure the pinion flange angle (F/A) **Small Flange Type**.
 - A. Remove the propeller shaft.

Refer to TIS, applicable model and model year Repair Manual:

- 2016 2019 Tacoma: Engine/Hybrid System - Propeller Shaft - "Propeller Shaft: Propeller Shaft Assembly (for 4WD): Removal"
- B. Place the digital angle gauge against the flange surface. Ensure the digital angle gauge is firmly against the flange to obtain an accurate pinion flange angle as shown.

Figure 8.





Repair Procedure (continued)

10. Measure the propeller shaft to pinion joint angle (J/A).


NOTE

ALL measurements MUST be taken from the passenger side of vehicle facing the driver side. Refer to Figure 9 to ensure that the angles measured have the correct positive (+) or negative (-) values assigned.

- An arrow pointing up indicates a positive (+) angle. In the example on the left, the angle measured is a positive 1.15 (+1.15).
- An arrow pointing down indicates a negative (–) angle. In the example on the right, the angle measured is a negative 0.95 (–0.95).

Figure 9.





1 Up Arrow (Positive)

2 Down Arrow (Negative)



Repair Procedure (continued)

- 11. Measure the propeller shaft angle (P/A).
 - A. Rotate the pinion flange (as shown in Figure 10) to the correct position (as shown in Figure 11).

Figure 10.



1	90°
2	Up



Repair Procedure (continued)

B. Use the digital angle gauge and measure the angle of the rear section of the two-piece propeller shaft.

Ensure the digital angle gauge is placed along the centerline of the propeller shaft as shown in Figure 11.


Figure 11. CORRECT Placement of Digital Angle Gauge



Figure 12. INCORRECT Placement of Digital Angle Gauge



Figure 13.





Repair Procedure (continued)

C. Record the propeller shaft angle (P/A).

Table 1. Joint Angle Worksheet (Pinion Flange Angle Minus Propeller Shaft Angle = Joint Angle)


PINION FLANGE ANGLE	-	PROPELLER SHAFT ANGLE	=	JOINT ANGLE
F/A	_	P/A	=	J/A
	_		=	

NOTE

Joint angle (J/A) can be a negative (-) value.

- 12. Verify if the vehicle is equipped with standard or firm ride suspension. Look up the factory option codes (accessories) in vehicle history on TIS. Does the vehicle have option codes CW, OF, OC, PT, or PY?
 - **YES** The vehicle has firm ride suspension.
 - **NO** The vehicle has standard suspension.
- 13. Verify the vehicle's model code (Katashiki). The model code can be found on the Vehicle Identification Label in the driver door jamb as shown.

Figure 14.



Repair Procedure (continued)

14. After the joint angle, spring type, and model code have been verified, refer to the table below to determine if the joint angle is in specification.

Is the joint angle in specification?

- **YES** This bulletin does NOT apply. Continue diagnosis using the applicable Repair Manual.
- NO Continue to step 15.

Table 2.

MODEL CODE	CABTYPE	GRADE	TYPE	JOINT ANGLE RANGE SPECIFICATION
GRN305L-PRTLHA	- Double	Limited	Firm	+1.41° to +3.41°
GRINSUSE-FIXTERIA		Limited	Standard	+1.38° to +3.38°
GRN305L-PRTSHA		Any	Firm	+1.41° to +3.41°
GRNSUSL-FRISHA			Standard	+1.38° to +3.38°
	Access	NOT Off-Road Package	Firm	+1.7° to +3.7°
GRN305L-CRTSHA		Off Road Package		-0.6° to +1.4°
		NOT Off-Road Package	Standard	+1.67° to +3.67°

Repair Procedure (continued)

15. Replace the leaf spring using the part information in the following table:

Table 3.

MODEL CODE	CABTYPE	GRADE	LH PART NUMBER	RH PART NUMBER
GRN305L-PRTLHA	Double	Limited	48220-04480	48210-04840
GRN305L-PRTSHA		Any		
GRN305L-CRTSHA	Access	NOT Off-Road Package	48220-04470	48210-04830
		Off-Road Package		
		NOT Off-Road Package		

NOTE

When tightening the U-bolt nuts, make sure to set to the following torque:


Torque: 60 N*m (610 kgf*cm, 44 ft*lbf)

Refer to TIS, applicable model and model year Repair Manual:

2016 – 2019 Tacoma:
 Suspension – Rear Suspension –
 "Suspension: Rear Leaf Spring:
 Removal / Installation"

Figure 15.

December 6, 2016



NOTE

Fasteners for shocks and leaf spring bushings should be tightened. Then, torque for these joints should be set while the vehicle is on the ground.

16. Test-drive the vehicle between 15 – 25 mph and confirm the level of vibration has improved under deceleration or acceleration.