

**** SOLUTION ****

Title	Mack Chassis - Equipped With An Automated Manual Transmission Model D or F (mDrive, AMT-D, AMT-F) - Transmission Oil Leakage From Transmission Input Shaft Seal Or Output Shaft Seal - US10 And Newer Emissions, Common Model Years 2010 And Newer
-------	--

Mack Models

Mack Model	AN - Anthem , CHU - Pinnacle, Axle back , CXU - Pinnacle, Axle front , GU - Granite , TD - Titan
------------	--

Emission Standard

Emission Standard	US10 , US10+OBD13 , US14+OBD13 , US14+OBD15 , US14+OBD16 , US17+OBD16 , US17+OBD18
-------------------	--

Engine family

Engine family	MP7 , MP8 , MP10
---------------	------------------

Transmission

Transmission	AMT-F , AMT-D , AMT-F
--------------	-----------------------

**** SOLUTION ****

Cause	<p>Accumulation of debris in the left side vent ports of the transmission main case (corrosion, road salt, dirt, etc) may result in oil leaks present at the transmission input and output shaft seals.</p> <p>The vent ports allow air exhausted from the shift solenoids and pistons to exit the main case. It also allows for equalization of internal and external pressures, as heat generated from operation will cause pressure in the case to increase. For the AMT-F this is the only vent for the TECU and gearcase.</p> <p>Blockage of these ports allows pressure to build to a point that it forces oil past the input and output shaft seals. In extreme cases, the pressure buildup can be high enough that operation can be affected. Excessive internal pressure caused by blocked vents may result in slow or sluggish gear shifts.</p>
-------	--

Solution**When diagnosing and repairing a shaft seal leak:**

1. Check the vent ports on the upper left side of the the main gearbox housing for any sort of blockage or obstruction.



Clogged vent ports

2. Clean out any debris that is observed during the inspection. (see inspection and cleaning below)
3. Check the transmission oil level in the gearbox.
 - **If the lube level is excessively low:** Proceed to the next section.
 - **If the lube level is at an acceptable level:** Fill the transmission oil to the correct level and check operation.

For excessively low transmission oil levels, or customer report of noise from the transmission:

1. The transmission will need to be inspected for internal damage. Removal may be required for proper inspection.

Inspection and cleaning

Due to the location of the vent ports it is very difficult, in most applications, to see the vents. An inspection mirror and flashlight can be used to see if there is a buildup of roadsalt or other debris in the ports.

If the ports are clogging then use a small screwdriver or similar tool to break up the deposits in the ports.

Clean and remove the upper oil fill plug from the main case on the right side of the gearbox.

<<<<<Insert picture of plug locations here>>>>>

Wrap a clean rag around an air nozzle and blow air into the case. Use proper eye protection. A complete seal is not needed. All you want to do is create enough pressure to force the debris from the vents on the left side of the case.

NA_Sister solutions

[K11907301](#)

Solution visibility

Dealer distribution

Function(s)/component(s) affected

Function affected

Input Shaft , Output Shaft , Lubrication

Function Group

Function Group	43 gearbox
Customer effect	
Main customer effect	fluid
Noise	whine
Fluid problem	leak , level incorrect
Fluid implicated	Transmission Oil
Visual appearance	leaking
Conditions	
Vehicle operating mode	when driving
Frequency of occurrence of problem	random
Location of problem	underneath cab
Administration	
Author	RU4469V
Dealer ID	RU4469V
Last modified by	UT9268H
Creation date	20-06-2018 20:06
Date of last update	27-08-2019 20:08
Review date	01-07-2019 00:07
Status	To be published
NA_Reviewer	UT9268H
NA_Author_Group	GTT