



Technical Service Bulletin

SUBJECT:		No:	TSB-20-52A-001
UPDATES TO DISASSEMBLY OF FRONT SEAT ASSEMBLY - SMR		DATE:	February 2020
		MODEL:	2011-2019 Outlander Sport/RVR
CIRCULATE TO:	<input type="checkbox"/> GENERAL MANAGER	<input checked="" type="checkbox"/> PARTS MANAGER	<input checked="" type="checkbox"/> TECHNICIAN
<input checked="" type="checkbox"/> SERVICE ADVISOR	<input checked="" type="checkbox"/> SERVICE MANAGER	<input type="checkbox"/> WARRANTY PROCESSOR	<input type="checkbox"/> SALES MANAGER

PURPOSE

This TSB updates the Interior & Supplemental Restraint (SRS) section of the affected Service Manuals to update the disassembly procedure of the front seat assembly with the additional parts below:

- Seat heater harness
- Front seat hinge protector
- Slide sensor harness

AFFECTED VEHICLES

- 2011 - 2019 Outlander Sport/RVR

AFFECTED SERVICE MANUALS


- 2011 - 2019 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS)



Please make the indicated changes below to the 2011 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>

M1522001501998



<<A>>

Disassembly steps

1. Seat heater switch
2. Front seat heater switch cover
3. Height adjuster lever cap <Vehicles with height adjustment>
4. Height adjuster lever <Vehicles with height adjustment>
5. Reclining adjuster lever
6. Side shield cover
7. Inner seat belt
8. Hinge cover
9. Front seatback assembly
10. Hog ring


<>

Disassembly steps (Continued)

11. Headrest guide
 12. Front seatback cover
 13. Front seatback pad
 14. Front seatback frame
 15. Front seat cushion assembly
 16. Hog ring
 17. Front seat cushion cover
 18. Front seat cushion pad
 19. Side shield cover inner
 20. Reclining adjuster cover
 21. Front seat slide adjuster side cover
 22. Front seat cushion frame
- <Added> 21-1. Front seat hinge protector

AC905408AB

<VEHICLES WITH POWER SEAT>



ACA00368AB

Disassembly steps

1. Seat heater switch
2. Front seat heater switch cover
3. Inner seat belt
4. Front seat hinge cover
5. Front seat slide adjuster knob
6. Front seat reclining adjuster knob
7. Front seat side shield cover
8. Front power seat switch
9. Front power seat switch garnish
10. Front seat hook
11. Front seat slide adjuster side cover

<>

Disassembly steps (Continued)

12. Front power seat motor cover
13. Front seat slide adjuster side cover
14. Front seat back assembly
15. Headrest guide
16. Hog ring
17. Front seatback cover
18. Front seatback pad
19. Front seatback frame
20. Front seat cushion assembly
21. Hog ring
22. Front seat cushion cover


Disassembly steps (Continued)

- 23. Front seat cushion pad
 - 24. Front seat reclining adjuster inner cover
 - 25. Front seat side shield cover inner
 - 26. Front seat reclining adjuster cover
 - 27. Front power seat harness
 - 28. Front seat hook
 - 29. Front seat cushion frame
- <Added>
27-1. Slide sensor harness
- 28-1. Front seat hinge protector
<Added>

DISASSEMBLY SERVICE POINTS


<<A>> HEIGHT ADJUSTER CAP REMOVAL

Use special tool MB990784 as shown to remove the height adjuster lever cap.



<> HEADRESTRAINT GUIDE REMOVAL


Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.



INSPECTION <VEHICLES WITH POWER SEAT>

M1522005500470


Connect the (+) terminal of the battery to the power seat connector terminal No.2 and the (-) terminal to terminal No.1, and check that the power seat works normally.



Please make the indicated changes below to the 2012 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>

M1522001501998



- <<A>>
- Disassembly steps**
1. Seat heater switch
 2. Front seat heater switch cover
 3. Height adjuster lever cap <Vehicles with height adjustment>
 4. Height adjuster lever <Vehicles with height adjustment>
 5. Reclining adjuster lever
 6. Side shield cover
 7. Inner seat belt
 8. Hinge cover
 9. Front seatback assembly


- <>
- Disassembly steps (Continued)**
10. Hog ring
 11. Headrest guide
 12. Front seatback cover
 13. Front seatback pad
 14. Front seatback frame
 15. Front seat cushion assembly
 16. Hog ring
 17. Front seat cushion cover
 18. Front seat cushion pad
 19. Side shield cover inner
 20. Reclining adjuster cover

AC905408AB

Disassembly steps (Continued)

- 21. Front seat slide adjuster side cover ← **21-1. Front seat hinge protector** <Added>
- 22. Front seat cushion frame

<VEHICLES WITH POWER SEAT>



ACA00368AB

Disassembly steps

1. Seat heater switch
2. Front seat heater switch cover
3. Inner seat belt
4. Front seat hinge cover
5. Front seat slide adjuster knob
6. Front seat reclining adjuster knob

Disassembly steps (Continued)

7. Front seat side shield cover
8. Front power seat switch
9. Front power seat switch garnish
10. Front seat hook
11. Front seat slide adjuster side cover
12. Front power seat motor cover
13. Front seat slide adjuster side cover

Disassembly steps (Continued)

<>


- 14. Front seat back assembly
- 15. Headrest guide
- 16. Hog ring
- 17. Front seatback cover
- 18. Front seatback pad
- 19. Front seatback frame
- 20. Front seat cushion assembly
- 21. Hog ring
- 22. Front seat cushion cover
- 23. Front seat cushion pad
- 24. Front seat reclining adjuster inner cover
- 25. Front seat side shield cover inner
- 26. Front seat reclining adjuster cover
- 27. Front power seat harness
- 28. Front seat hook
- 29. Front seat cushion frame

<Added>

27-1. Slide sensor harness

28-1. Front seat hinge protector


<Added>



DISASSEMBLY SERVICE POINTS


<<A>> HEIGHT ADJUSTER CAP REMOVAL

Use special tool MB990784 as shown to remove the height adjuster lever cap.



<> HEADRESTRAINT GUIDE REMOVAL


Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.



Please make the indicated changes below to the 2013 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>

M1522001501998



Disassembly steps

1. Seat heater switch
2. Front seat heater switch cover
3. Height adjuster lever cap <Vehicles with height adjustment>
4. Height adjuster lever <Vehicles with height adjustment>
5. Reclining adjuster lever
6. Side shield cover
7. Inner seat belt
8. Hinge cover
9. Front seatback assembly

<<A>>

<>

Disassembly steps (Continued)


10. Hog ring
11. Headrest guide
12. Front seatback cover
13. Front seatback pad
14. Front seatback frame
15. Front seat cushion assembly
16. Hog ring
17. Front seat cushion cover
18. Front seat cushion pad
19. Side shield cover inner
20. Reclining adjuster cover



Disassembly steps (Continued)

- > 21. Front seat slide adjuster side cover <Added>
- > 22. Front seat cushion frame < 21-1. Front seat hinge protector

<VEHICLES WITH POWER SEAT>



ACA00368AB

Disassembly steps

1. Seat heater switch
2. Front seat heater switch cover
3. Inner seat belt
4. Front seat hinge cover
5. Front seat slide adjuster knob
6. Front seat reclining adjuster knob

Disassembly steps (Continued)

7. Front seat side shield cover
8. Front power seat switch
9. Front power seat switch garnish
10. Front seat hook
11. Front seat slide adjuster side cover
12. Front power seat motor cover
13. Front seat slide adjuster side cover

Disassembly steps (Continued)

<>

- 14. Front seat back assembly
- 15. Headrest guide
- 16. Hog ring
- 17. Front seatback cover
- 18. Front seatback pad
- 19. Front seatback frame
- 20. Front seat cushion assembly
- 21. Hog ring
- 22. Front seat cushion cover
- 23. Front seat cushion pad
- 24. Front seat reclining adjuster inner cover
- 25. Front seat side shield cover inner
- 26. Front seat reclining adjuster cover
- 27. Front power seat harness
- 28. Front seat hook
- 29. Front seat cushion frame

<Added>

- 27-1. Seat heater harness
- 27-2. Slide sensor harness


- 28-1. Front seat hinge protector

<Added>

DISASSEMBLY SERVICE POINTS


<<A>> HEIGHT ADJUSTER CAP REMOVAL

Use special tool MB990784 as shown to remove the height adjuster lever cap.



<> HEADRESTRAINT GUIDE REMOVAL


Peel off the front seatback cover and pad to access the head-restraint guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.



Please make the indicated changes below to the 2014 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>

M1522001501998



<<A>>

- Disassembly steps**
1. Seat heater switch
 2. Front seat heater switch cover
 3. Height adjuster lever cap <Vehicles with height adjustment>
 4. Height adjuster lever <Vehicles with height adjustment>
 5. Reclining adjuster lever
 6. Side shield cover
 7. Inner seat belt
 8. Hinge cover
 9. Front seatback assembly

<>

- Disassembly steps (Continued)**
10. Hog ring
 11. Headrest guide
 12. Front seatback cover
 13. Front seatback pad
 14. Front seatback frame
 15. Front seat cushion assembly
 16. Hog ring
 17. Front seat cushion cover
 18. Front seat cushion pad
 19. Side shield cover inner
 20. Reclining adjuster cover


AC905408AB

Disassembly steps (Continued)

- 21. Front seat slide adjuster side cover
- 22. Front seat cushion frame

21-1. Front seat hinge protector
 <Added>

<VEHICLES WITH POWER SEAT>



ACA00368AB

Disassembly steps

- 1. Seat heater switch
- 2. Front seat heater switch cover
- 3. Inner seat belt
- 4. Front seat hinge cover
- 5. Front seat slide adjuster knob
- 6. Front seat reclining adjuster knob

Disassembly steps (Continued)

- 7. Front seat side shield cover
- 8. Front power seat switch
- 9. Front power seat switch garnish
- 10. Front seat hook
- 11. Front seat slide adjuster side cover
- 12. Front power seat motor cover

Disassembly steps (Continued)

<>

- 13. Front seat slide adjuster side cover
- 14. Front seat back assembly
- 15. Headrest guide
- 16. Hog ring
- 17. Front seatback cover
- 18. Front seatback pad
- 19. Front seatback frame
- 20. Front seat cushion assembly
- 21. Hog ring
- 22. Front seat cushion cover

Disassembly steps (Continued)

- 23. Front seat cushion pad
- 24. Front seat reclining adjuster inner cover
- 25. Front seat side shield cover inner
- 26. Front seat reclining adjuster cover
- 27. Front power seat harness
- 28. Front seat hook
- 29. Front seat cushion frame

<Added>

28-1. Front seat hinge protector


<Added>

27-1. Seat heater harness
 27-2. Slide sensor harness

DISASSEMBLY SERVICE POINTS


<<A>> HEIGHT ADJUSTER CAP REMOVAL

Use special tool MB990784 as shown to remove the height adjuster lever cap.



<> HEADRESTRAINT GUIDE REMOVAL


Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.



INSPECTION <VEHICLES WITH POWER SEAT>

M1522005500470


Connect the (+) terminal of the battery to the power seat connector terminal No.2 and the (-) terminal to terminal No.1, and check that the power seat works normally.



Please make the indicated changes below to the 2015 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>


M1522001502452



- <<A>>
- Disassembly steps**
1. Height adjuster lever cap <Vehicles with height adjustment>
 2. Height adjuster lever <Vehicles with height adjustment>
 3. Reclining adjuster lever
 4. Side shield cover
 5. Inner seat belt
 6. Hinge cover
 7. Front seatback assembly
 8. Hog ring
 9. Headrest assembly
- <>

- ACE00955 AB
- Disassembly steps (Continued)**
10. Front seatback cover
 11. Front seatback pad
 12. Front seatback frame
 13. Front seat cushion assembly
 14. Hog ring
 15. Front seat cushion cover
 16. Front seat cushion pad
 17. Side shield cover inner
 18. Reclining adjuster cover
 19. Front seat slide adjuster side cover
 20. Front seat cushion frame
- <Added>
 19-1. Front seat hinge protector
- <Added>
 18-1. Slide sensor harness

<VEHICLES WITH POWER SEAT>



ACE00956AB

Disassembly steps

1. Inner seat belt
2. Front seat hinge cover
3. Front seat slide adjuster knob
4. Front seat reclining adjuster knob
5. Front seat side shield cover
6. Front power seat switch
7. Front power seat switch garnish
8. Front seat hook
9. Front seat slide adjuster side cover
10. Front power seat motor cover

<>

Disassembly steps (Continued)

11. Front seat slide adjuster side cover
12. Front seat back assembly
13. Headrest guide
14. Hog ring
15. Front seatback cover
16. Front seatback pad
17. Front seatback frame
18. Front seat cushion assembly
19. Hog ring
20. Front seat cushion cover
21. Front seat cushion pad

Disassembly steps (Continued)


- 22. Front seat reclining adjuster inner cover
- 23. Front seat side shield cover inner
- 24. Front seat reclining adjuster cover
- 25. Front power seat harness
- 26. Front seat hook
- 27. Front seat cushion frame

<Added>
 25-1. Slide sensor harness
 26-1. Front seat hinge protector
 <Added>

DISASSEMBLY SERVICE POINTS


<<A>> HEIGHT ADJUSTER LEVER CAP REMOVAL

Use special tool MB990784 as shown to remove the height adjuster lever cap.



<> HEADRESTRAINT GUIDE REMOVAL


Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.



INSPECTION <VEHICLES WITH POWER SEAT>

M1522005500470


Connect the (+) terminal of the battery to the power seat connector terminal No.2 and the (-) terminal to terminal No.1, and check that the power seat works normally.



Please make the indicated changes below to the 2016 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>

M1522001502452




- <<A>>
- Disassembly steps**
1. Height adjuster lever cap <Vehicles with height adjustment>
 2. Height adjuster lever <Vehicles with height adjustment>
 3. Reclining adjuster lever
 4. Side shield cover
 5. Inner seat belt
 6. Hinge cover
 7. Front seatback assembly
 8. Hog ring
 9. Headrest assembly
- <>

- Disassembly steps (Continued)**
10. Front seatback cover
 11. Front seatback pad
 12. Front seatback frame
 13. Front seat cushion assembly
 14. Hog ring
 15. Front seat cushion cover
 16. Front seat cushion pad
 17. Side shield cover inner
 18. Reclining adjuster cover
 19. Front seat slide adjuster side cover
 20. Front seat cushion frame
- <Added> 19-1. Front seat hinge protector

ACE00955AB

<VEHICLES WITH POWER SEAT>



Disassembly steps

1. Inner seat belt
2. Front seat hinge cover
3. Front seat slide adjuster knob
4. Front seat reclining adjuster knob
5. Front seat side shield cover
6. Front power seat switch
7. Front power seat switch garnish
8. Front seat hook
9. Front seat slide adjuster side cover
10. Front power seat motor cover

<>

Disassembly steps (Continued)

11. Front seat slide adjuster side cover
12. Front seat back assembly
13. Headrest guide
14. Hog ring
15. Front seatback cover
16. Front seatback pad
17. Front seatback frame
18. Front seat cushion assembly
19. Hog ring
20. Front seat cushion cover

ACE00956AB

Disassembly steps (Continued)


- 21. Front seat cushion pad
- 22. Front seat reclining adjuster inner cover
- 23. Front seat side shield cover inner
- 24. Front seat reclining adjuster cover
- 25. Front power seat harness
- 26. Front seat hook
- 27. Front seat cushion frame

<Added>

25-1. Slide sensor harness

26-1. Front seat hinge protector


<Added>



DISASSEMBLY SERVICE POINTS


<<A>> HEIGHT ADJUSTER LEVER CAP REMOVAL

Use special tool MB990784 as shown to remove the height adjuster lever cap.



<> HEADRESTRAINT GUIDE REMOVAL


Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.



INSPECTION <VEHICLES WITH POWER SEAT>

M1522005500470


Connect the (+) terminal of the battery to the power seat connector terminal No.2 and the (-) terminal to terminal No.1, and check that the power seat works normally.



Please make the indicated changes below to the 2017 - 2018 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:

DISASSEMBLY AND REASSEMBLY
<VEHICLES WITH STANDARD SEAT>

M1522001502452



<<A>>

Disassembly steps

1. Height adjuster lever cap <Vehicles with height adjustment>
2. Height adjuster lever <Vehicles with height adjustment>
3. Reclining adjuster lever
4. Side shield cover
5. Inner seat belt
6. Hinge cover
7. Front seatback assembly
8. Hog ring
9. Headrest assembly

<>

Disassembly steps (Continued)


10. Front seatback cover
11. Front seatback pad
12. Front seatback frame
13. Front seat cushion assembly
14. Hog ring
15. Front seat cushion cover
16. Front seat cushion pad
17. Side shield cover inner
18. Reclining adjuster cover
19. Front seat slide adjuster side cover
20. Front seat cushion frame

<Added> 19-1. Front seat hinge protector

<Added>
 18-1. Slide sensor harness

ACE00955 AB

<VEHICLES WITH POWER SEAT>



- Disassembly steps**
1. Inner seat belt
 2. Front seat hinge cover
 3. Front seat slide adjuster knob
 4. Front seat reclining adjuster knob
 5. Front seat side shield cover
 6. Front power seat switch
 7. Front power seat switch garnish
 8. Front seat hook
 9. Front seat slide adjuster side cover
 10. Front power seat motor cover

<>

- Disassembly steps (Continued)**
11. Front seat slide adjuster side cover
 12. Front seat back assembly
 13. Headrest guide
 14. Hog ring
 15. Front seatback cover
 16. Front seatback pad
 17. Front seatback frame
 18. Front seat cushion assembly
 19. Hog ring
 20. Front seat cushion cover
 21. Front seat cushion pad

ACE00956AB

Disassembly steps (Continued)

- 22. Front seat reclining adjuster inner cover
- 23. Front seat side shield cover inner
- 24. Front seat reclining adjuster cover
- 25. Front power seat harness
- 26. Front seat hook
- 27. Front seat cushion frame

<Added>


25-1. Slide sensor harness

26-1. Front seat hinge protector

<Added>


DISASSEMBLY SERVICE POINTS

<<A>> HEIGHT ADJUSTER LEVER CAP REMOVAL



Use special tool MB990784 as shown to remove the height adjuster lever cap.

<> HEADRESTRAINT GUIDE REMOVAL




Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.

INSPECTION <VEHICLES WITH POWER SEAT>

M1522005500470

Connect the (+) terminal of the battery to the power seat connector terminal No.2 and the (-) terminal to terminal No.1, and check that the power seat works normally.



Please make the indicated changes below to the 2019 Outlander Sport/RVR Service Manual, Group 52-Interior & Supplemental Restraint (SRS) -> 52A-Interior -> Seat Assembly -> Front Seat Assembly -> Disassembly and Reassembly:


DISASSEMBLY AND REASSEMBLY

M1522001502894

CAUTION

- Always replace the front seat cushion assembly together with the occupant classification-ECU.<Passenger's side>
- When replacing the front seat cushion assembly, be careful not to apply static electricity to it.<Passenger's side>
- The front seat cushion assembly must not be damped with any liquid or steam.<Passenger's side>

<VEHICLES WITH STANDARD SEAT>



Disassembly steps

<<A>>

1. Height adjuster lever cap
<Vehicles with height adjustment>
2. Height adjuster lever
<Vehicles with height adjustment>
3. Reclining adjuster lever
4. Side shield cover
5. Inner seat belt
6. Hinge cover
7. Front seatback assembly
8. Hog ring
9. Headrest guide
10. Front seatback cover

<>

Disassembly steps (Continued)


11. Front seatback pad
12. Front seatback frame
13. Front seat cushion assembly
14. Hog ring <Driver's side>
15. Front seat cushion cover
<Driver's side>
16. Front seat cushion pad
<Driver's side>
17. Side shield cover inner
18. Reclining adjuster cover
19. Front seat slide adjuster side cover
20. Front seat cushion frame

<Added>


18-1. Slide sensor harness

19-1. Front seat hinge protector

<Added>



<VEHICLES WITH POWER SEAT>



ACE00956AB

Disassembly steps

1. Inner seat belt
2. Front seat hinge cover
3. Front seat slide adjuster knob
4. Front seat reclining adjuster knob
5. Front seat side shield cover
6. Front power seat switch
7. Front power seat switch garnish
8. Front seat hook
9. Front seat slide adjuster side cover
10. Front power seat motor cover

<>

Disassembly steps (Continued)

11. Front seat slide adjuster side cover
12. Front seat back assembly
13. Headrest guide
14. Hog ring
15. Front seatback cover
16. Front seatback pad
17. Front seatback frame
18. Front seat cushion assembly
19. Hog ring

Disassembly steps (Continued)


- 20. Front seat cushion cover
- 21. Front seat cushion pad
- 22. Front seat reclining adjuster inner cover
- 23. Front seat side shield cover inner
- 24. Front seat reclining adjuster cover
- 25. Front power seat harness
- 26. Front seat hook
- 27. Front seat cushion frame

<Added>
 25-1. Slide sensor harness

26-1. Front seat hinge protector
 <Added>


DISASSEMBLY SERVICE POINTS

<<A>> HEIGHT ADJUSTER LEVER CAP REMOVAL



Use special tool MB990784 as shown to remove the height adjuster lever cap.


<> HEADRESTRAINT GUIDE REMOVAL



Peel off the front seatback cover and pad to access the headrest guides. Pull off the guides upwards while pushing the tabs (arrows) as shown.

INSPECTION <VEHICLES WITH POWER SEAT>

M1522005500470



Connect the (+) terminal of the battery to the power seat connector terminal No.2 and the (-) terminal to terminal No.1, and check that the power seat works normally.