



Mack Chassis - Models GU / GR - Constant Correction To Center



> Internal Content

GU/GR, CHU, CXU, AN Constant Correction To Center

Often times perceived as riding on a cam lobe and having to correct the steering wheel back to center or not holding a true line.


Vehicle Checks

(CHECKS MUST BE PERFORMED 1ST)

- Tire design and pressure.
 - All tire pressures should be reduced to 80lbs.-90lbs. and vehicle driven, bobtail, as a test.
 - Tire damage, uneven or extreme tread wear or mismatched tires/sizes.
 - High tread block tires (ex. Bridgestone 426EL) may ride on the center sip of the tire causing the truck to drive from the 'rear' causing a need to constantly correct with the steering wheel.
- If vehicle has a 5th wheel, is it lubed properly, does wandering only happen with a trailer?
- Basic alignment specs i.e. toe, thrust line and caster.
- Turning torque at the steering wheel nut, depending on surface area tested on, tires pressures, etc. avg. 60-75in lbs. or less.
 - Diagnosis can be completed by breaking the system into smaller sections (upper vs. lower, etc.).
- Looseness or binding in the following components:
 - Steering wheel or steering column
 - U-joints or slip joints in upper steering system
 - Steering gear (diagnose per manufacturer's specifications i.e. flow/pressure)
 - Pitman arm
 - Draglink ends and adjustment areas
 - Kingpins/bushings
 - Tie rod ends
 - Spindles
 - Wheel bearings
 - Lug nuts
 - Springs/spring hanger brackets
 - Front and rear axles and u-bolts
 - Steering box mounting, miss mounting may result in distortion of gear

GU Alternate Cab Wall Boot

- For GU vehicles produced **prior** to 1st week of January 2017. A change of the upper steering column happened in November of 2014 (4mm shorter). With this change we believe an interference may be present with the column boot on the cab wall. This may create undue pressure on the column shaft as it comes out of the cab wall.



- Pressure from the boot may be applied to the steering column shaft restricting it from turning freely. To check, disconnect upper steering shaft at base of column shaft. Remove boot (there may be a noticeable movement upward of the shaft). Reassemble steering shaft to steering column and test drive. If problem is resolved replace boot with 84723313 (Introduced into production 2017w01). Test drive after boot replacement to ensure problem is resolved before returning truck to customer.

GU / GR Without Assist Gear - Alternate Steering Gear/Shaft Configuration


- An e-service case to Reliability must be submitted with results of previous checks prior to installation of gear and shaft.

Live UI On non-assist gear trucks we have a steering gear from Sheppard with a 90° miter box on top. This can be used with an Anthem 1

piece steering shaft.

- Sheppard steering gear part # 8148-SD110PAE3.
 - Steering shaft 84703023 x 1.
 - Screw 25106380 x 2.
 - Nut 25098472 x 2.
-
- Follow Impact service procedures for gear and shaft replacement.
 - Clearance to any component must be a minimum of 1".
 - Pillow block bearing bracket may be left in place and trimmed off or not.
 - Slightly stiffer steering may result. May improve as components wear in.
 - Use [84734967](#) as the causal part in the claim.





 Tags

[k28501552](#)

[axle back](#)

[constant correction to center](#)

Related links and attachments

No content available

 **Feedback**

[Give feedback](#)

to help improve the content of this article

 Live UI

