GLOBAL SAFETY FIELD INVESTIGATIONS DCS6149 URGENT - DISTRIBUTE IMMEDIATELY

Date: April 27, 2022

Subject: N222360010 - Customer Satisfaction Program Dinghy Towing Owner Manual Incorrect Instructions

Models: 2022 Chevrolet Traverse

To: All General Motors Dealers

General Motors is releasing Customer Satisfaction Program N222360010 today. The total number of U.S. vehicles involved is approximately 35,794. Please see the attached bulletin for details.

Customer Letter Mailing

The customer letter mailing will begin on mid-May 2022.

Global Warranty Management (GWM)

The Required Field Action section on the Investigate Vehicle History (IVH) screen will be updated April 28, 2022, or sooner. A list of involved vehicles in dealer new inventory is attached to this message. Please hold all warranty transactions until IVH has been updated.

END OF MESSAGE GLOBAL SAFETY FIELD INVESTIGATIONS

N222360010 - Dinghy Towing Owner Manual Incorrect Instructions



Release Date: April 2022

Revision: 00

Attention: This program is in effect until May 31, 2024.

		Model Year			
Make	Model	From	То	RPO	Description
Chevrolet	Traverse	2022	2022		

Involved vehicles are marked "open" on the Investigate Vehicle History screen in GM Global Warranty Management system. This site should always be checked to confirm vehicle involvement prior to beginning any required inspections and/or repairs.

Co	ondition	ition Certain 2022 model year Chevrolet Traverse vehicles, may have incorrect instructions in the Owner	
		Manual stating the vehicle cannot be dinghy towed.	
Co	Correction Dealers will print and insert the revised Owner Manual page(s).		

Parts

There are no parts required for this remedy.

Warranty Information

Labor			Trans.	Net
Operation	Description	Time	Туре	ltem
9106281	Print and insert revised page(s) in the Owner Manual	0.1	ZFAT	N/A

Service Procedure

- 1. Print the appropriate language owner manual insert(s) for your service area. (See examples below).
 - a. For US: English version.
 - b. For Caribbean: English v2.
 - c. For CA: English & French versions.
 - d. For MX: Spanish version.
- 2. Locate the owner manual.
- 3. Insert revised page(s) in the Owner Manual.

N222360010 – Dinghy Towing Owner Manual Incorrect Instructions

gm

English – US and Canada

Insert to the 2022 Chevrolet Traverse Owner's Manual

This information replaces the dinghy towing Caution Caution sub-heading information under Recreational Do not tow a vehicle with the front drive If the vehicle is towed without Vehicle Towing found in the Vehicle Care wheels on the ground if one of the front performing each of the steps listed under Section of the owner's manual. tires is a compact spare tire. Towing with "Dinghy Towing," the automatic **Dinghy Towing** transmission could be damaged. Be sure two different tire sizes on the front of the vehicle can cause severe damage to to follow all steps of the dinghy towing Run the ignition of a vehicle that is being dinghy towed in the beginning of each day, the transmission. procedure prior to and after towing the and at each fuel stop for about five minutes vehicle to ensure proper lubrication of transmission To dinghy tow: components. 1. Position the front of the vehicle being Caution towed-with all four wheels on the Caution ground-behind the towing vehicle. If 105 km/h (65 mph) is exceeded while Too much or too little fluid can damage towing the vehicle, it could be damaged. 2. Secure it to the towing vehicle. the transmission. Be sure that the Never exceed 105 km/h (65 mph) while 3. Put the vehicle in N (Neutral). transmission fluid is at the proper level towing the vehicle. 4. Shut engine off (vehicle will remain in before towing with all four wheels on the accessory mode). ground. Once the destination is reached: 5. Disconnect the negative (-) terminal 1. Shift the vehicle to P (Park). connector from the 12-volt battery. 2. Reconnect the negative (-) terminal 6. Close the hood of the vehicle. connector to the 12-volt battery. 3. Start the engine and let it idle for more than three minutes before driving the vehicle.

°2022 General Motors LLC. All Rights Reserved.

6049303

Insert to the 2022 Chevrolet Traverse Owner's Manual

This information replaces the dinghy towing sub-heading information under Recreational Vehicle Towing found in the Vehicle Care Section of the owner's manual.

Dinghy Towing

English v2 – Carribean

Part No. 87835469

Run the ignition of a vehicle that is being dinghy towed in the beginning of each day, and at each fuel stop for about five minutes to ensure proper lubrication of transmission components.

Caution

Too much or too little fluid can damage the transmission. Be sure that the transmission fluid is at the proper level before towing with all four wheels on the ground.



Litho in U.S.A. Part No. 22CHEVTRAVINS1_ENCARIB

Caution

Do not tow a vehicle with the front drive wheels on the ground if one of the front tires is a compact spare tire. Towing with two different tire sizes on the front of the vehicle can cause severe damage to the transmission.

To dinghy tow:

- Position the front of the vehicle being towed—with all four wheels on the ground—behind the towing vehicle.
- 2. Secure it to the towing vehicle.
- 3. Put the vehicle in N (Neutral).
- Shut engine off (vehicle will remain in accessory mode).
- Disconnect the negative (-) terminal connector from the 12-volt battery.
- 6. Close the hood of the vehicle.

Caution

If the vehicle is towed without performing each of the steps listed under "Dinghy Towing," the automatic transmission could be damaged. Be sure to follow all steps of the dinghy towing procedure prior to and after towing the vehicle.

Caution

If 105 km/h (65 mph) is exceeded while towing the vehicle, it could be damaged. Never exceed 105 km/h (65 mph) while towing the vehicle.

Once the destination is reached:

- 1. Shift the vehicle to P (Park).
- Reconnect the negative (-) terminal connector to the 12-volt battery.
- Start the engine and let it idle for more than three minutes before driving the vehicle.

°2022 General Motors LLC. All Rights Reserved.

N222360010 – Dinghy Towing Owner Manual Incorrect Instructions

Spanish - Mexico

del sub-encabezado Arrastre en remolque			
bajo Remolque de vehículo recreativo que se encuentra en la sección Cuidado del vehículo del manual del propietario.	No remolque un vehículo con las ruedas delanteras en la tierra si alguna de las llantas delanteras es una llanta de	Si el vehículo se remolca sin realizar los pasos listados en "Arrastre en remolque", se podría dañar la transmisión	
Arrastre en remolque	refacción compacta. El remolque de llantas de dos tamaños distintos en el	automática. Asegúrese de seguir todos los pasos del procedimiento de remolque de	
Opere la ignición de un vehículo que se va a arrastrar en remolque al inicio de cada día, y	frente del vehículo puede provocar daño severo a la transmisión.	lancha inflable antes y después de remolcar el vehículo.	
en cada paro para combustible durante aproximadamente cinco minutos para asegurar la lubricación adecuada de los	Para el arrastre con remolque: 1. Coloque el frente del vehículo que se va	Precaución	
componentes de la transmisión.	 consider et mette de vehiculo de remolque. a remolcar, con las cuatro ruedas en el suelo, detrás del vehículo de remolque. Ponga el vehículo en N (Neutral). Apague el motor (el vehículo permanecerá en modo de accesorios). Desconecte el conector de la terminal negativa (⁻) de la batería de 12 voltios. Cierre el cofre del vehículo. 	Si se exceden los 105 km/h (65 mph)	
Precaución		cuando remolque el vehículo, podría dañarse. Nunca exceda los 105 km/h	
Si el líquido es excesivo o insuficiente, la		(65 mph) cuando remolque el vehículo.	
transmisión puede sufrir daños. Asegúrese de que el líquido de la transmisión esté en el nivel adecuado antes de remolcar el vehículo con las cuatro ruedas en contacto con el suelo.		Una vez que se llegue al destino: 1. Cambie el vehículo a P (estacionamiento) 2. Vuelva a conectar el conector de la terminal negativa (-) a la batería de 12 voltios.	
	o, ciene el cone del venicalo.	 Arranque el motor y permita su funcionamiento en marcha sin 	
		desplazamiento durante más de tres minutos antes de conducir el vehículo.	

6049305

Supplément au guide du propriétaire de Chevrolet Traverse 2022

Attention (Suite)

sur ses quatre roues, vérifier, et ajuster, le cas échéant, le niveau du liquide de la boite.

Attention

Ne pas remorquer le véhicule avec les roues avant au sol si l'une de ces roues est une roue de secours compacte. Le fait de remorquer un véhicule dont les roues avant sont de taille différente risque d'endommager sérieusement la boite de vitesses.

Pour remorquer avec une barre de remorquage :

- 1. Placer l'avant du véhicule remorqué, avec les quatre roues au sol, derrière le véhicule qui le tracte.
- 2. Le fixer au véhicule qui le tracte.
- 3. Sélectionner le point mort (N).

- 4. Couper le moteur (le véhicule reste en mode d'alimentation des accessoires).
- 5. Débrancher la cosse négative (-) de la borne de batterie 12 volts.
- 6. Fermer le capot du véhicule.

Attention

Si le véhicule est remorqué sans effectuer toutes les étapes décrites dans la rubrique « Remorquage pneumatique », la boîte de vitesses automatique peut être endommagée. S'assurer de suivre toutes les étapes de la procédure de remorquage pneumatique du début à la fin.

Attention

Si vous dépassez 105 km/h (65 mi/h) pendant le remorquage de votre véhicule, il pourrait subir des dégâts. Ne jamais dépasser 105 km/h (65 mi/h) lors du remorquage de votre véhicule.

°2022 General Motors LLC. Tous droits réservés.

French – Canada



Cette information remplace le remorquage pneumatique informations dans la section de remorquage récréatif, dans Entretien du véhicule, dans le guide du propriétaire.

Remorquage pneumatique

Mettre le contact d'un véhicule qui est remorqué à plat sur les quatre roues, au début de chaque jour et lors de chaque remplissage de carburant, pendant environ cinq minutes, afin d'assurer la lubrification correcte des composants de boite de vitesses.

Attention

Un niveau de liquide trop élevé ou trop bas risque d'endommager la boite de vitesse. Avant de remorquer le véhicule (Suite)



Imprimé aux États-Unis Numéro de pièce 87835469

N222360010 – Dinghy Towing Owner Manual Incorrect Instructions



2

Un	ne fois à destination :	
1.	Mettre la boîte de vitesses en position de stationnement (P).	
2.	Rebrancher la cosse négative (-) sur la batterie 12 volts.	
3.	batterie 12 volts. Faire démarrer le moteur et le laisser tourner au ralenti pendant plus de trois minutes avant de rouler.	

6054758

Dealer Responsibility

All new, used, GM Certified Used, courtesy transportation vehicles, dealer shuttle vehicles, etc. in dealers' possession and subject to this program <u>must</u> be held and inspected/repaired per the service procedure of this bulletin <u>before</u> customers take possession of these vehicles. Involved vehicles must be held and not delivered to customers, dealer-traded, released to auction, used for demonstration, or any other purpose.

All GM Certified Used vehicles currently in the dealers' inventory within the Certified Pre-Owned Inventory System (CPOIS) will be de-certified and must be held and remedied per the service procedure in this bulletin. Upon submitting an accepted/paid warranty transaction in the Global Warranty Management (GWM) system, the vehicle can be re-certified for sale within the CPOIS system, or once again be used in the CTP program.

Dealers are to service all vehicles subject to this program at no charge to customers, regardless of mileage, age of vehicle, or ownership, from this time forward.

Customers who have recently purchased vehicles sold from your vehicle inventory, and for which there is no customer information indicated on the dealer listing, are to be contacted by the dealer. Arrangements are to be made to make the required correction according to the instructions contained in this bulletin. A copy of the customer letter is provided in this bulletin for your use in contacting customers. Recall follow-up cards should not be used for this purpose, since the customer may not as yet have received the notification letter.

In summary, whenever a vehicle subject to this field action enters your vehicle inventory you must take the steps necessary to ensure the program correction has been made before selling the vehicle. In addition, for vehicles entering your facility for service, you are required to ensure the customer is aware of the open field action and make every reasonable effort to implement the program correction as set forth in this bulletin prior to releasing the vehicle.

Dealer Reports

For dealers with involved vehicles, a listing has been prepared and will be available through GM GlobalConnect Maxis Field Action Reports or sent directly to export dealers. The Inventory tab of the dealer reports will contain VINs that apply to this field action. This information is intended to assist dealers with the **PROMPT COMPLETION** of these vehicles. The Customer In-Service tab will contain customer names and addresses from Motor Vehicle Registration Records. The use of such motor vehicle registration data for any purpose other than follow-up necessary to complete this field action may be a violation of law in several states.

N222360010 - Dinghy Towing Owner Manual Incorrect Instructions



Customer Notification

USA & Canada - General Motors will notify customers of this program on their vehicle (see copy of customer letter included with this bulletin).

Export - Letters will be sent to known owners of record located within areas covered by the US National Traffic and Motor Vehicle Safety Act. For owners outside these areas, dealers should notify customers using the attached sample letter.

GM bulletins are intended for use by professional technicians, NOT a "do-it-yourselfer". They are written to inform these technicians of conditions that may occur on some vehicles, or to provide information that could assist in the proper service of a vehicle. Properly trained technicians have the tools, equipment, safety instructions, and know-how to do a job properly and safely. If a condition is described, <u>DONOT</u> assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. See your dealer for information on whether your vehicle may benefit from the information.



We Support Voluntary Technician Certification N222360010 – Dinghy Towing Owner Manual Incorrect Instructions



May 2022

This notice applies to your vehicle, VIN:

Dear General Motors Customer:

We have learned that your 2022 model year Chevrolet Traverse may have incorrect instructions in the owner manual stating the vehicle cannot be dinghy towed.

Your satisfaction with your Chevrolet Traverse is very important to us, so we are announcing a program to correct this issue.

What We Will Do: A replacement owner manual insert, describing the correct Dinghy towing procedure is included with this letter.

What You Should Do: Find the enclosed replacement owner manual insert. Add the insert to the vehicle owner manual and keep them with your vehicle for future reference.

If you have any questions or concerns that your dealer is unable to resolve, please contact the appropriate Customer Assistance Center at the number listed below.

For the hearing or speech impaired, please contact our Customer Assistance Center using the Telecommunication Relay Service by dialing 711 then providing the appropriate Customer Assistance Center number for your vehicle.

Division	Number	Text Telephones (TTY)	
Chevrolet	1-800-222-1020	711 / 1-800-833-2438	
Puerto Rico – English	1-866-467-9700		
Puerto Rico – Español	1-866-467-9700		
Virgin Islands	1-866-467-9700		

We truly appreciate you taking the time to update your owner manual as we know your time is valuable. We want you to know that we will do our best, throughout your ownership experience, to ensure that your Chevrolet Traverse vehicle provides you many miles of enjoyable driving.

Neelie O'Connor Global Executive Director Customer Experience Operations

Enclosure N222360010