



# Technical Service Bulletin

SUBJECT: <b>ADDITION OF SERVICE PROCEDURE DESCRIPTION FOR HEADLIGHT AIMING AND EXHAUST GAS TEMPERATURE SENSOR – SERVICE MANUAL REVISION</b>			No: <b>TSB-23-11-003</b>
			DATE: <b>May 2023</b>
			MODEL: <b>2022 Outlander</b>
<b>CIRCULATE TO:</b>	<input type="checkbox"/> GENERAL MANAGER	<input checked="" type="checkbox"/> PARTS MANAGER	<input checked="" type="checkbox"/> TECHNICIAN
<input checked="" type="checkbox"/> SERVICE ADVISOR	<input checked="" type="checkbox"/> SERVICE MANAGER	<input checked="" type="checkbox"/> WARRANTY PROCESSOR	<input type="checkbox"/> SALES MANAGER

## PURPOSE

This TSB provides description information for the service procedure in the applicable Service Manual sections.

## AFFECTED VEHICLES

2022 Outlander

## AFFECTED SERVICE MANUAL

- 2022 Outlander Service Manual, Groups 11, 13 and 54

## PROCEDURE

Please use the following chart as a guide to replace the indicated pages in the affected Service Manual, Group 11, Engine > Engine Mechanical, Group 13 Engine > Engine Control System and Group 54 Chassis Electrical > Headlight.




Copyright 2023, Mitsubishi Motors North America, Inc.

The information contained in this bulletin is subject to change. For the latest version of this document, go to the Mitsubishi Dealer Link, MEDIC, or the Mitsubishi Service Information website ([www.mitsubishitechinfo.com](http://www.mitsubishitechinfo.com)).

## &lt;OUTLANDER&gt;

Applicable manual	Pub. No.	Applicable title	Content
2022 OUTLANDER Service manual	MSCD-330B-2022 (Volume 1)	CHASSIS ELECTRICAL └ 54A CHASSIS ELECTRICAL └ HEADLIGHT └SERVICE SPECIFICATIONS	Attached sheet 2
		CHASSIS ELECTRICAL └ 54A CHASSIS ELECTRICAL └ HEADLIGHT └ ON-VEHICLE SERVICE └ HEADLIGHT AIMING	Attached sheet 3
	MSCD-330B-2022 (Volume 2)	ENGINE └ ENGINE MECHANICAL └ REMOVAL AND INSTALLATION └ EXHAUST MANIFOLD AND THREE WAY CATALYST └ Exploded View	Attached sheet 4
		ENGINE └ ENGINE MECHANICAL └ REMOVAL AND INSTALLATION └ EXHAUST MANIFOLD AND THREE WAY CATALYST └ Removal and Installation	Attached sheet 5
		Added below "ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ SYSTEM DESCRIPTION └ COMPONENT PARTS └ Engine Oil Pressure Control Solenoid Valve"	Attached sheet 6
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ SYSTEM DESCRIPTION └ SYSTEM └ ENGINE CONTROL SYSTEM └ System Description	Attached sheet 7
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ SYSTEM DESCRIPTION └ SYSTEM └ ENGINE CONTROL SYSTEM └ System Description	Attached sheet 8
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ ECU DIAGNOSIS INFORMATION └ ECM └ DTC Inspection Priority Chart	Attached sheet 9
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ ECU DIAGNOSIS INFORMATION └ ECM └ DTC Index	Attached sheet 10
		Added below "ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ DTC/CIRCUIT DIAGNOSIS └ P0533 A/C REFRIGERANT PRESSURE SENSOR"	Attached sheet 11

**<OUTLANDER>**

Applicable manual	Pub. No.	Applicable title	Content
2022 OUTLANDER Service manual  <div style="border: 1px solid blue; padding: 2px; display: inline-block; margin-top: 20px;">DTC/CIRCUIT DIAGNOSIS</div>  	MSCD-330B-2022 (Volume 2)	Added below "ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ <del>ECU DIAGNOSIS INFORMATION</del> └ <del>ECM</del> └ P2018 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR"	Attached sheet 12
		Added above "ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ <del>ECU DIAGNOSIS INFORMATION</del> └ <del>ECM</del> └ P2096 A/F SENSOR 1"	Attached sheet 13
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ SYMPTOM DIAGNOSIS └ ENGINE CONTROL SYSTEM └ Symptom Table	Attached sheet 14
2023 OUTLANDER Service manual	MSCD-030B-2023	ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ ECU DIAGNOSIS INFORMATION └ ECM └ DTC Inspection Priority Chart	Attached sheet 15
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ ECU DIAGNOSIS INFORMATION └ ECM └ DTC Index	Attached sheet 16
		Added below "ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ <del>ECU DIAGNOSIS INFORMATION</del> └ <del>ECM</del> └ P2018 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR"	Attached sheet 12
		ENGINE └ ENGINE CONTROL SYSTEM └ PR25DD └ SYMPTOM DIAGNOSIS └ ENGINE CONTROL SYSTEM └ Symptom Table	Attached sheet 17
		DRIVER CONTROLS └ EXTERIOR LIGHTING SYSTEM └ LED HEADLAMP └ PERIODIC MAINTENANCE └ HEADLAMP AIMING ADJUSTMENT └ Specifications	Attached sheet 18
		DRIVER CONTROLS └ EXTERIOR LIGHTING SYSTEM └ LED HEADLAMP └ PERIODIC MAINTENANCE └ HEADLAMP AIMING ADJUSTMENT └ Headlight Aiming	Attached sheet 19

CHASSIS ELECTRICAL  
HEADLIGHT

54A-5

HEADLIGHT

SERVICE SPECIFICATIONS

M15401002A0576

Item	<Incorrect>		Standard value	Limit
Headlight aiming [at 7.62 m (25.0 ft)]	Low-beam	Vertical direction	Horizontal line (H) ± 50.5 mm (± 2.0 in) (± 0.38 degrees angle)	-
		Horizontal direction	± 133.3 mm (± 5.2 in) (± 1 degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)	-
Headlight intensity cd (at high-beam)			-	40,000 or more {when a screen is set 18.3 m (60 ft) ahead of the vehicle}

PRECAUTIONS ON HOW TO USE THE HEADLIGHT ASSEMBLY

Be careful with the following items as resin lenses are used in the headlight assembly.

- Don't illuminate the headlight for three minutes or more when the headlight is covered with scratch protector.
- Don't tape the outer lens.
- Don't scratch the outer lens surface with a sharp edged special tool.

ON-VEHICLE SERVICE

HEADLIGHT AIMING

M15401005A0168

PRE-AIMING INSTRUCTION (LOW-BEAM)

Inspect for badly rusted or faulty headlight assemblies.

1. These conditions must be corrected before a satisfactory adjustment can be made.
2. Inspect tire inflation, and adjust if it is necessary.
3. If the fuel tank is not full, place a weight in the trunk of the vehicle to simulate weight of a full tank [3 kg (6.6 pounds) per gallon].
4. There should be no other load in the vehicle other than driver or substituted weight of approximately 68 kg (150 pounds) placed in driver's position.
5. Change the vehicle posture, and then operate the actuator of headlight levelling unit once.
6. Thoroughly clean the headlight lenses.

<Correct>

Headlight aiming [at 7.62 m (25.0 ft)]	Low-beam	Vertical direction	Entry type	Horizontal line (H) ± 50.5 mm (± 2.0 in) (± 0.38 degrees angle)	-
			Premium type	Vertical direction Horizontal line (H) ± 50.5 mm, ± 0 mm (± 2.0 in, - 0 in) (+ 0.38 degrees angle, - 0 degrees angle)	-
		Horizontal direction		± 133.3 mm (± 5.2 in) (± 1 degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)	-

Horizontal direction  
<Correct>  
A

( <Added>  
A

± 133.0 mm <Correct>  
A

- 0 mm <Correct>  
A

TSB Revision

## CHASSIS ELECTRICAL HEADLIGHT




54A-7

### HEADLIGHT ADJUSTMENT (LOW-BEAM)

#### **⚠ CAUTION**

- Do not cover a headlight for more than three minutes to prevent the plastic headlight lens deformation.
- Be sure to adjust the aiming adjustment screw in the tightening direction.

1. The low-beam headlight should project on the screen upper edge of the beam (cut-off).
2. When adjusting the vertical direction side, insert the screwdriver from the service hole near the headlight assembly mounting bolts.



3. Turn the adjusting screws to achieve the specified low-beam cut-off location on the aiming screen.

&lt;Added&gt;

&lt;Entry type&gt;

Standard value:


(Vertical direction) Horizontal line (H)  $\pm 50.5$  mm ( $\pm 2.0$  in) ( $\pm 0.38$  degrees angle)

(Horizontal direction):  $\pm 133.0$  mm ( $\pm 5.2$  in) ( $\pm 1$  degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)

NOTE: High-beam pattern should be correct when the low-beams are adjusted properly.

Attached sheet 3(2/2)

&lt;Added&gt;

**<Premium type>****Standard value:**

**(Vertical direction) Horizontal line (H) + 50.5 mm, - 0 mm(+ 2.0 in, - 0 in) (+ 0.38 degrees angle, - 0 degrees angle)**

**(Horizontal direction): ± 133.0 mm (± 5.2 in) (± 1 degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)**


NOTE: High-beam pattern should be correct when the low-beams are adjusted properly.

EXHAUST MANIFOLD AND THREE WAY CATALYST

Exploded View

<Incorrect>

SEC. 147•208•226



CF1009NVA00USA


①	Air fuel ratio sensor 1	②	Exhaust manifold and three way catalyst cover	③	Exhaust manifold and three way catalyst assembly
④	Exhaust manifold and three way catalyst assembly bracket	⑤	Gasket	⑥	Stud bolt

	: N·m (kg·m, ft·lb)
	: N·m (kg·m, in·lb)
	: Always replace after every disassembly.
	: Indicates that the part is connected at points with same symbol in actual vehicle.

<Correct>

Attached sheet 4(2/2)

SEC. 147•208•226



DF3000Y5AA00USA

①	Exhaust gas temperature sensor<AWD>	②	Air fuel ratio sensor 1	③	Exhaust manifold and three way catalyst cover
④	Exhaust manifold and three way catalyst assembly	⑤	Exhaust manifold and three way catalyst assembly bracket	⑥	Gasket
⑦	Stud bolt				




Removal and Installation

REMOVAL

2WD models

- 1.Remove the engine cover.(With engine cover models) Refer to Removal and Installation.ENGINE COVER
- 2.Disconnect the air fuel ratio sensor 1 harness connector.
- 3.Remove the air fuel ratio sensor 1 using heated oxygen sensor wrench [SST: KV10117100] if necessary.
- 4.Remove the engine under cover. Refer to ENGINE UNDER COVER.
- 5.Remove the exhaust front tube. Refer to EXHAUST SYSTEM.
- 6.Remove the exhaust manifold and three way catalyst bracket.
- 7.Remove the EGR inlet tube heat insulator. Refer to EGR SYSTEM.
- 8.Remove the EGR inlet tube mounting bolt, exhaust manifold and three way catalyst side. Refer to EGR SYSTEM.
- 9.Remove the exhaust manifold and three way catalyst cover.
- 10.Loosen the exhaust manifold and three way catalyst nuts in the reverse order as shown.



CF1009NWAA00USA


- 11.Remove the exhaust manifold and three way catalyst assembly and gasket.

AWD models

- 1.Remove the engine cover (with engine cover models). Refer to Removal and Installation.ENGINE COVER
- 2.Disconnect the air fuel ratio sensor 1 harness connector.
- 3.Remove the air fuel ratio sensor 1 using heated oxygen sensor wrench [SST: KV10117100] if necessary.
- 4.Remove the engine under cover. Refer to ENGINE UNDER COVER.
- 5.Remove the exhaust front tube. Refer to EXHAUST SYSTEM.
- 6.Remove rear propeller shaft. Refer to REAR PROPELLER SHAFT.
- 7.Remove the exhaust manifold and three way catalyst bracket.
- 8.Remove the EGR inlet tube heat insulator. Refer to EGR SYSTEM.
- 9.Remove the EGR inlet tube mounting bolt, exhaust manifold and three way catalyst side. Refer to EGR SYSTEM.
- 10.Remove the exhaust manifold and three way catalyst cover.
- 11.Loosen the exhaust manifold and three way catalyst nuts in the reverse order as shown.

2-1. Disconnect the exhaust gas temperature harness connector.  
 2-2. Remove the exhaust gas temperature sensor.

<Added>



CF1009NWAA00USA

- 12.Remove the exhaust manifold and three way catalyst assembly and gasket.


INSTALLATION

Exhaust Manifold and Three Way Catalyst

1.Install studs in cylinder head and exhaust manifold and three way catalyst if removed. Then tighten to specification.

CAUTION: Do not reuse stud bolts.

2.Install the exhaust manifold and three way catalyst and gasket. Then tighten the nuts to specification in the numerical order shown.




CF1009NWAA00USA

[Torque wrench icon] : 41.65 N·m (4.2 kg·m, 31 ft·lb)

CAUTION: Do not reuse gasket. Do not reuse nuts.

3.Then tighten the nuts to specification in the numerical order shown again.



CF1009NWAA00USA

[Torque wrench icon] : 41.65 N·m (4.2 kg·m, 31 ft·lb)

4.Install exhaust manifold and three way catalyst cover and bolts.

CAUTION: Do not reuse bolts.

5.Install the air fuel ratio sensor 1 using heated oxygen sensor wrench [SST: KV10117100] if removed and tighten to specification.

CAUTION: Be careful not to damage air fuel ratio sensor 1. Discard any air fuel ratio sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; replace with a new one. Do not over-tighten the air fuel ratio sensor 1. Doing so may cause damage to the air fuel ratio sensor 1, resulting in a malfunction and the MIL coming on.

<Added>


6.Install the exhaust gas temperature sensor to the specified torque.

CAUTION: Be careful not to damage exhaust gas temperature sensor. Discard any exhaust gas temperature sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; replace with a new one. Do not over-tighten the exhaust gas temperature sensor. Doing so may cause damage to the exhaust gas temperature sensor, resulting in a malfunction and the MIL coming on.

&lt;Added&gt;


## Exhaust Gas Temperature Sensor

Exhaust gas temperature sensor (EGT sensor) is installed exhaust manifold. Exhaustgas temperature sensor uses a thermistor which is sensitive to the change intertemperature. Electrical resistance of the thermistor decreases in response to thetemperature rises.



&lt;Reference data&gt;

DF3000YWAA00USA




DF3000YWAA00US

Fluid temperature [°C (°F)]	Voltage (V)	Resistance (kΩ)
100 (212)	4.74	18.25
200 (392)	4.00	4.00
400 (752)	1.96	0.64
600 (1112)	0.85	0.20

ENGINE CONTROL SYSTEM


<Incorrect>



CF1009WPAA00USA

<Correct>

Attached sheet 7(2/2)



DF1009WPAB00USA

## ENGINE CONTROL SYSTEM

51

Component parts	Function
Accelerator pedal position sensor	<u>COMPONENT PARTS</u>
Air fuel ratio (A/F) sensor 1	<u>COMPONENT PARTS</u>
ASCD steering switch	<u>COMPONENT PARTS</u>
ACC steering switch	
Cooling fan	<u>COMPONENT PARTS</u>
Crankshaft position sensor	<u>COMPONENT PARTS</u>
ECM	<u>COMPONENT PARTS</u>
EGR system	<u>EGR SYSTEM.</u>
EGR volume control valve	<u>COMPONENT PARTS</u>
Electric intake valve timing control actuator	<u>COMPONENT PARTS</u>
Electric intake valve timing control module	<u>COMPONENT PARTS</u>
Electric throttle control actuator	<u>COMPONENT PARTS</u>
Engine coolant temperature sensor	<u>COMPONENT PARTS</u>
Engine oil pressure sensor	<u>COMPONENT PARTS</u>
Engine oil pressure control solenoid valve	<u>COMPONENT PARTS</u>
Engine oil pressure control system	Warning Light/Indicator Light <u>WARNING/INDICATOR/CHIME LIST</u>
Engine oil temperature sensor	<u>COMPONENT PARTS</u>
EVAP canister	<u>COMPONENT PARTS</u>
EVAP canister purge volume control solenoid valve	<u>COMPONENT PARTS</u>
EVAP canister vent control valve	<u>COMPONENT PARTS.</u>
EVAP control system pressure sensor	<u>COMPONENT PARTS</u>
Exhaust camshaft position sensor	<u>COMPONENT PARTS.</u>
Exhaust valve timing control solenoid valve	<u>COMPONENT PARTS</u>
Exhaust valve timing intermediate lock control solenoid valve	<u>COMPONENT PARTS</u>
Fuel injector	<u>COMPONENT PARTS</u>
Fuel level sensor unit and fuel pump	Fuel Level Sensor Unit And Fuel Pump <u>COMPONENT PARTS.</u>
Fuel pressure control	<u>FUEL PRESSURE CONTROL</u>
Fuel rail pressure sensor	<u>COMPONENT PARTS</u>
Fuel tank temperature sensor	<u>COMPONENT PARTS</u>
Heated oxygen sensor 2	<u>COMPONENT PARTS</u>
High pressure fuel pump	<u>COMPONENT PARTS</u>
Ignition coil with power transistor	<u>COMPONENT PARTS</u>
Intake camshaft position sensor	<u>COMPONENT PARTS</u>
Intake manifold runner control valve	<u>COMPONENT PARTS</u>
Intake manifold tuning valve	<u>COMPONENT PARTS</u>
Knock sensor	<u>COMPONENT PARTS</u>
Malfunction indicator light (MIL)	Malfunction Indicator Light (MIL) <u>WARNING LAMPS/INDICATOR LAMPS(Full TFT meter)</u> Malfunction Indicator Light (MIL) <u>WARNING LAMPS/INDICATOR LAMPS(7 inch information display)</u>
Manifold absolute pressure sensor	<u>COMPONENT PARTS</u>
Mass air flow sensor (With intake air temperature sensor)	<u>COMPONENT PARTS</u>
Power generation voltage variable control system	<u>POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM</u>
Refrigerant pressure sensor	<u>COMPONENT PARTS</u>
Stop light switch	Stop Light Switch <u>COMPONENT PARTS</u>

&lt;Added&gt;

Exhaust gas temperature sensor

Attached sheet 6

## Fail Safe

Refer to Fail-safeENGINE CONTROL SYSTEM.

## DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC	Detected items
1	C053C	Wheel speed sensor
	P0101, P0102, P0103	Mass air flow sensor
	P0106	Manifold absolute pressure sensor
	P0107, P0108, P2227	Atmospheric pressure sensor
	P0111, P0112, P0113, P0127	Intake air temperature sensor
	P0116, P0117, P0118, P0125	Engine coolant temperature sensor
	P0122, P0123, P0222, P0223, P1225, P1226, P2135	Throttle position sensor
	P0128	Thermostat function
	P0181, P0182, P0183	Fuel tank temperature sensor
	P0191, P0192, P0193, P119A, P119B, P119C, P119D, P119E	Fuel rail pressure sensor
	P0196, P0197, P0198	Engine oil temperature sensor
	P025A, P025C, P025D	Fuel pump relay
	P026B, P2B96	Injection system
	P0326, P0327, P0328, P032B, P032C, P032D	Knock sensor
	P0315, P0335, P2617, P2618, P2619	Crankshaft position sensor
	P0340, P0365, P2614, P2615, P2616	Camshaft position sensor
	P044A, P044B, P044C, P044D, P044E	EGR volume control valve position sensor
	P0460, P0461, P0462, P0463	Fuel level sensor
	P0500, P0501, P2159	Vehicle speed sensor
	P0520, P0522, P0523, P0524	Engine oil pressure sensor
	P0531, P0532, P0533	Refrigerant pressure sensor
	P0604, P0605, P0606, P0607, P060A, P060B, P060C, P061B, P062B, P062D, P062F, P1603, P2610	ECM
	P0641, P34C8	Electric intake valve timing control module
	P06B0, P06B3, P06E6	Sensor power supply
	P06DA, P06DB, P06DC	Engine oil pressure control solenoid valve
	P0850	Transmission range switch
	P1197	Out of gas
	P155B	Energy management control
	P155D, P155E, P155F	Generator
	P161D, P161E, P161F	Immobilizer
	P2014, P2015, P2016, P2017, P2018	Intake manifold runner control valve position sensor
	P2121, P2122, P2123, P2126, P2127, P2128, P2138	Accelerator pedal position sensor
	U0101, U0122, U012E, U0146, U0155, U042F	CAN communication line
U0284, U1040	Engine communication line	
U1050, U1051	LIN communication line	
U1327, U2118, U2148, U214A, U214E, U214F, U2150, U2152, U215B, U2165, U2176, U2241, U2248, U2252, U2259, U226B, U2276, U2384	MAC key	

&lt;Added&gt;

P0544, P0545, P0546, P2080, P2081

Exhaust gas temperature sensor

## ENGINE CONTROL SYSTEM

129

DTC *1			Items (M.U.T.-III SE screen terms)	SRT code	Trip	MIL	Permanent DTC group *3	Reference page
M.U.T.-III SE	GST *2							
P0531	00	P0531	REFRIGERANT PRESS SENSOR A	—	2	×	A + B	<a href="#">P0531 A/C REFRIGERANT PRESSURE SENSOR</a>
P0532	00	P0532	REFRIGERANT PRESS SENSOR A	—	2	×	A + B	<a href="#">P0532 A/C REFRIGERANT PRESSURE SENSOR</a>
P0533	00	P0533	REFRIGERANT PRESS SENSOR A	—	2	×	A + B	<a href="#">P0533 A/C REFRIGERANT PRESSURE SENSOR</a>
P054A	00	P054A	Cold start B camshaft position bank 1	×	2	×	A	<a href="#">P054A CAMSHAFT POSITION BANK 1</a>
P054B	00	P054B	Cold start B camshaft position bank 1	×	2	×	A	<a href="#">P054B CAMSHAFT POSITION BANK 1</a>
P059F	00	P059F	ACTIVE GRILLE AIR SHUTTER A	—	2	×	A + B	<a href="#">P059F ACTIVE GRILLE SHUTTER</a>
P05EC	00	P05EC	COLD START CONTROL	—	2	×	A + B	<a href="#">P05EC COLD START CONTROL</a>
P0604	00	P0604	ECM	—	1	×	A + B	<a href="#">P0604 ECM</a>
P0605	00	P0605	ECM	—	1	×	A + B	<a href="#">P0605 ECM</a>
P0606	00	P0606	CONTROL MODULE	—	1 or 2	×	A + B or —	<a href="#">P0606 ECM</a>
P0607	00	P0607	ECM	—	1 or 2	×	A + B	<a href="#">P0607 ECM</a>
P060A	00	P060A	CONTROL MODULE	—	1	×	A + B	<a href="#">P060A ECM</a>
P060B	00	P060B	CONTROL MODULE	—	1	×	A + B	<a href="#">P060B ECM</a>
P060C	00	P060C	Control module	—	1	×	A + B	<a href="#">P060C ECM</a>
P061B	00	P061B	Internal control module	—	1	×	A + B	<a href="#">P061B ECM</a>
P062B	00	P062B	ECM	—	2	×	A + B	<a href="#">P062B ECM</a>
P062D	00	P062D	Fuel injector driver bank 1	—	2	×	A + B	<a href="#">P062D FUEL INJECTOR DRIVER BANK 1</a>
P062F	00	P062F	CONTROL MODULE	—	1 or 2	×	A + B	<a href="#">P062F ECM</a>
P0641	00	P0641	Sensor reference voltage A	—	2	×	A + B	<a href="#">P0641 SENSOR POWER SUPPLY</a>
P064D	00	P064D	Internal Control Module O2 Sensor Processor Performance (bank 1)	—	2	×	A + B	<a href="#">P064D ECM</a>
P0660	00	P0660	INT Manifold Tuning Valve Control B1	—	2	—	—	<a href="#">P0660 INTAKE MANIFOLD TUNING VALVE</a>
P0661	00	P0661	INT Manifold Tuning Valve Control B1	—	2	—	—	<a href="#">P0661 INTAKE MANIFOLD TUNING VALVE</a>
P0662	00	P0662	INT Manifold Tuning Valve Control B1	—	2	—	—	<a href="#">P0662 INTAKE MANIFOLD TUNING VALVE</a>
P06B0	11	P06B1	Sensor Power Supply A	—	1	×	A + B	<a href="#">P06B0 SENSOR POWER SUPPLY A</a>
	12	P06B2	Sensor Power Supply A	—	1	×	A + B	
P06B3	11	P06B4	Sensor Power Supply B	—	1	×	A + B	<a href="#">P06B3 SENSOR POWER SUPPLY B</a>
	12	P06B5	Sensor Power Supply B	—	1	×	A + B	
P06DA	00	P06DA	ENGINE OIL PRESSURE CONTROL	—	2	—	—	<a href="#">P06DA ENGINE OIL PRESSURE CONTROL SOLENOID VALVE</a>
P06DB	00	P06DB	ENGINE OIL PRESSURE CONTROL	—	2	—	—	<a href="#">P06DB ENGINE OIL PRESSURE CONTROL SOLENOID VALVE</a>
P06DC	00	P06DC	Engine oil pressure control	—	2	—	—	<a href="#">P06DC ENGINE OIL PRESSURE CONTROL SOLENOID VALVE</a>
P06E6	11	P06E7	Internal control module	—	1	×	A + B	<a href="#">P06E6 INTERNAL CONTROL MODULE</a>
	12	P06E8	Internal control module	—	1	×	A + B	
P0850	00	P0850	P-N POS SW/CIRCUIT	—	2	×	A + B	<a href="#">P0850 PNP SWITCH</a>

&lt;Added&gt;

P0544	00	P0544	EXHAUST GAS TEMP SENSOR 1 B1	-	2	X	B	Attached sheet 11(1/10)
P0545	00	P0545	EXHAUST GAS TEMP SENSOR 1 B1	-	2	X	B	Attached sheet 11(4/10)
P0546	00	P0546	EXHAUST GAS TEMP SENSOR 1 B1	-	2	X	B	Attached sheet 11(7/10)



## ENGINE CONTROL SYSTEM

131

DTC *1			Items (M.U.T.-III SE screen terms)	SRT code	Trip	MIL	Permanent DTC group *3	Reference page
M.U.T.-III SE	GST *2							
P1805	00	P1805	BRAKE SW/CIRCUIT	—	1	—	—	<a href="#">P1805 BRAKE SWITCH</a>
P1A10	00	P1A10	ECM initial learning Incomplete	—	2	—	—	<a href="#">P1A10 ECM INITIAL LEARNING INCOMPLETE</a>
P2004	00	P2004	SWIRL CONT/V (B1)	—	2	×	A + B	<a href="#">P2004 INTAKE MANIFOLD RUNNER CONTROL VALVE</a>
P2008	00	P2008	SWIRL CONT/V (B1)	—	2	×	A + B	<a href="#">P2008 INTAKE MANIFOLD RUNNER CONTROL VALVE</a>
P2009	00	P2009	Intake manifold runner control	—	2	×	A + B	<a href="#">P2009 INTAKE MANIFOLD RUNNER CONTROL VALVE</a>
P2010	00	P2010	Intake manifold runner control	—	2	×	A + B	<a href="#">P2010 INTAKE MANIFOLD RUNNER CONTROL VALVE</a>
P2014	00	P2014	SWIRL CONT SEN/SW	—	2	×	A + B	<a href="#">P2014 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR</a>
P2015	00	P2015	Intake manifold runner posi sen/sw B1	—	2	×	A + B	<a href="#">P2015 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR</a>
P2016	00	P2016	IN/MANIFOLD RUNNER POS SEN B1	—	2	×	A + B	<a href="#">P2016 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR</a>
P2017	00	P2017	IN/MANIFOLD RUNNER POS SEN B1	—	2	×	A + B	<a href="#">P2017 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR</a>
P2018	00	P2018	IN/MANIFOLD RUNNER POS SEN B1	—	2	×	A + B	<a href="#">P2018 INTAKE MANIFOLD RUNNER CONTROL VALVE POSITION SENSOR</a>
P2096	00	P2096	POST CATALYST FUEL TRIM SYS B1	×	2	×	A	<a href="#">P2096 A/F SENSOR 1</a>
P2097	00	P2097	POST CATALYST FUEL TRIM SYS B1	×	2	×	A	<a href="#">P2097 A/F SENSOR 1</a>
P2100	00	P2100	ETC MOT PWR-B1	—	1	×	A + B	<a href="#">P2100 THROTTLE CONTROL MOTOR</a>
P2101	00	P2101	ETC FNCTN/CIRC-B1	—	1	×	A + B	<a href="#">P2101 ELECTRIC THROTTLE CONTROL FUNCTION</a>
P2103	00	P2103	ETC MOT PWR-B1	—	1	×	A + B	<a href="#">P2103 THROTTLE CONTROL MOTOR</a>
P2119	00	P2119	ETC ACTR-B1	—	1	× or —	A + B or —	<a href="#">P2119 ELECTRIC THROTTLE CONTROL ACTUATOR</a>
P2121	00	P2121	Throttle/pedal position sen/sw D	—	1	×	A + B	<a href="#">P2121 APP SENSOR</a>
P2122	00	P2122	APP SEN 1/CIRC	—	1	×	A + B	<a href="#">P2122 APP SENSOR</a>
P2123	00	P2123	APP SEN 1/CIRC	—	1	×	A + B	<a href="#">P2123 APP SENSOR</a>
P2126	00	P2126	Throttle/pedal position sen/sw E	—	1	×	A + B	<a href="#">P2126 APP SENSOR</a>
P2127	00	P2127	APP SEN 2/CIRC	—	1	×	A + B	<a href="#">P2127 APP SENSOR</a>
P2128	00	P2128	APP SEN 2/CIRC	—	1	×	A + B	<a href="#">P2128 APP SENSOR</a>
P2135	00	P2135	TP SENSOR-B1	—	1	×	A + B	<a href="#">P2135 TP SENSOR</a>
P2138	00	P2138	APP SENSOR	—	1	×	A + B	<a href="#">P2138 APP SENSOR</a>
P2159	00	P2159	VEHICLE SPEED SEN B	—	2	×	A + B	<a href="#">P2159 VEHICLE SPEED SENSOR</a>
P219A	00	P219A	AIR FUEL RATIO IMBALANCE B1	×	2	×	A	<a href="#">P219A AIR FUEL RATIO</a>
P2227	00	P2227	Barometric pressure sensor A	—	2	×	A + B	<a href="#">P2227 BAROMETRIC PRESSURE SENSOR</a>
P2237	00	P2237	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">P2237 A/F SENSOR</a>
P2238	00	P2238	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">P2238 AIR FUEL RATIO SENSOR</a>

&lt;Added&gt;

P2080	00	P2080	EXHAUST GAS TEMP SENSOR 1 B1	-	2	×	B	Attached sheet 12(1/4)
P2081	00	P2081	EXHAUST GAS TEMP SENSOR 1 B1	-	2	×	B	Attached sheet 13(1/4)

&lt;Added&gt;

## DTC/CIRCUIT DIAGNOSIS

## P0544 EXHAUST GAS TEMPERATURE SENSOR

## DTC Description

## DTC DETECTION LOGIC

DTC		M.U.T.-III SE screen terms (Trouble diagnosis content)	DTC detection condition	
P0544	00	EXHAUST GAS TEMPERATURE SENSOR 1 B1 (Exhaust gas temperature sensor circuit bank 1 sensor 1)	Diagnosis condition	Ignition switch ON
			Signal (terminal)	Exhaust gas temperature sensor signal
			Threshold	ECM detects that a voltage signal from exhaust gas temperature sensor is less than 0.025 V.
			Diagnosis delay time	5 seconds or more

## POSSIBLE CAUSE

- Harness or connectors  
(Exhaust gas temperature sensor circuit is open.)
- Exhaust gas temperature sensor

## FAIL-SAFE

Not applicable

## DTC Confirmation Procedure

## 1. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

## TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V.

&gt;&gt;

GO TO 2

&lt;Added&gt;

## 2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >>

Proceed to .

NO >>

To check malfunction symptom before repair: Refer to Intermittent Incident.

NO >>

Confirmation after repair: INSPECTION END


## DTC Diagnosis Procedure

### 1. CHECK EXHAUST GAS TEMPERATURE SENSOR

 With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "EXHAUST GAS TEMP SEN 1 B1" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.
3. Start engine and warm it up to normal operating temperature.
4. Check that "EXHAUST GAS TEMP SEN 1 B1" indication as follows.

Monitor item	Condition	Value
EXHAUST GAS TEMP SEN 1 B1	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1,290 – 2,940 mV

 Without M.U.T.-III SE

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM harness connector terminals as follows.

ECM			Condition	Voltage
Connector	+	-		
	Terminal			
B-11	12	34	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1.29 – 2.94 V

Is the inspection result normal?

YES >>

GO TO 2

.

NO >>

Replace exhaust gas temperature sensor. Refer to Exploded View. .

&lt;Added&gt;

## 2. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect exhaust gas temperature sensor harness connector.
3. Turn ignition switch ON.
4. Check the voltage between exhaust gas temperature sensor harness connector terminal and ground.

+		-	Voltage (Approx.)
Exhaust gas temperature sensor			
Connector	Terminal		
B-46	1	Ground	5 V

Is the inspection result normal?

YES >>

GO TO 3

.

NO >>

GO TO 4

.

## 3. CHECK EXHAUST GAS TEMPERATURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	2	B-11	34	Existed

4. Also check harness for short to power.

Is the inspection result normal?

YES >>

Check intermittent incident. Refer to Intermittent Incident.

NO >>

Repair or replace error-detected parts.

## 4. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	1	B-11	12	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >>

Perform the trouble diagnosis for ECM power supply circuit. Refer to Diagnosis Procedure.

NO >>

Repair or replace error-detected parts.

&lt;Added&gt;

## P0545 EXHAUST GAS TEMPERETURE SENSOR

**DTC Description****DTC DETECTION LOGIC**

DTC		M.U.T.-III SE screen terms (Trouble diagnosis content)	DTC detection condition	
P0545	00	EXHAUST GAS TEMPESENSOR 1 B1 (Exhaust gas temperature sensor circuit low bank 1sensor 1)	Diagnosis condition	Ignition switch ON
			Signal (terminal)	Exhaust gas temperature sensor signal
			Threshold	ECM detects that a voltage signal from exhaust gas temperature sensor is less than 0.209 V.
			Diagnosis delay time	5 seconds or more

**POSSIBLE CAUSE**

- Harness or connectors  
(Exhaust gas temperature sensor circuit is shorted.)
- Exhaust gas temperature sensor

**FAIL-SAFE**

Not applicable

**DTC Confirmation Procedure****1. PRECONDITIONING**

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11 V.

&gt;&gt;

[GO TO 2](#)

&lt;Added&gt;

## 2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait at least 5 seconds.
2. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >>

Proceed to .

NO >>

To check malfunction symptom before repair: Refer to Intermittent Incident.

NO >>

Confirmation after repair: INSPECTION END

## DTC Diagnosis Procedure

### 1. CHECK EXHAUST GAS TEMPERATURE SENSOR



With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "EXHAUST GAS TEMP SEN 1 B1" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.
3. Start engine and warm it up to normal operating temperature.
4. Check that "EXHAUST GAS TEMP SEN 1 B1" indication as follows.

Monitor item	Condition	Value
EXHAUST GAS TEMP SEN 1 B1	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1,290 – 2,940 mV



Without M.U.T.-III SE

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM harness connector terminals as follows.

Connector	ECM		Condition	Voltage
	+	-		
	Terminal			
B-11	12	34	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1.29 – 2.94 V

Is the inspection result normal?

YES >>

GO TO 2

.

NO >>

Replace exhaust gas temperature sensor. Refer to Exploded View. .

&lt;Added&gt;

## 2. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect exhaust gas temperature sensor harness connector.
3. Turn ignition switch ON.
4. Check the voltage between exhaust gas temperature sensor harness connector terminal and ground.

+		-	Voltage (Approx.)
Exhaust gas temperature sensor			
Connector	Terminal		
B-46	1	Ground	5 V

Is the inspection result normal?

YES >>

GO TO 3

.

NO >>

GO TO 4

.

## 3. CHECK EXHAUST GAS TEMPERATURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	2	B-11	34	Existed

4. Also check harness for short to power.

Is the inspection result normal?

YES >>

Check intermittent incident. Refer to Intermittent Incident.

NO >>

Repair or replace error-detected parts.

## 4. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	1	B-11	12	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >>

Perform the trouble diagnosis for ECM power supply circuit. Refer to Diagnosis Procedure.

NO >>

Repair or replace error-detected parts.

&lt;Added&gt;

## P0546 EXHAUST GAS TEMPERATURE SENSOR

**DTC Description****DTC DETECTION LOGIC**

DTC		M.U.T.-III SE screen terms (Trouble diagnosis content)	DTC detection condition	
P0546	00	EXHAUST GAS TEMPSSENSOR 1 B1  (Exhaust gas temperature sensor circuit high bank 1 sensor 1)	Diagnosis condition	-
			Signal (terminal)	Exhaust gas temperature sensor signal
			Threshold	ECM detects that a voltage signal from exhaust gas temperature sensor is more than 4.84 V.
			Diagnosis delay time	5 seconds or more

**POSSIBLE CAUSE**

- Harness or connectors  
(Exhaust gas temperature sensor circuit is open.)
- Exhaust gas temperature sensor

**FAIL-SAFE**

Not applicable

**DTC Confirmation Procedure****1. PRECONDITIONING-1**

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.


1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

&gt;&gt;

GO TO 2**2. PRECONDITIONING-2**

 With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "COOLANT TEMP/S" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III.
3. Check the following conditions:

COOLANT TEMP/S	More than -30°C (-22°F)
----------------	----------------------------

 With GST

Follow the procedure "With M.U.T.-III SE" above.



<Added>

Is the condition satisfied?

YES >>

GO TO 4

.

NO >>

GO TO 3

.

### 3. PRECONDITIONING-3

---



With M.U.T.-III SE

1. Start the engine until the following condition is satisfied.

COOLANT TEMP/S	More than -30°C (-22°F)
-------------------	----------------------------

2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.



With GST

Follow the procedure "With M.U.T.-III SE" above.

>>

GO TO 4

.

&lt;Added&gt;

**4. PERFORM DTC CONFIRMATION PROCEDURE**

1. Shift the selector lever to P range.
2. Start engine and let it idle for at least 20 seconds.
3. Depress the accelerator pedal for 5 seconds or more.

**NOTE:**

**Do not release the accelerator pedal during DTC confirmation procedure.**

4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >>

Proceed to .

NO >>

To check malfunction symptom before repair: Refer to Intermittent Incident.

NO >>

Confirmation after repair: INSPECTION END

**DTC Diagnosis Procedure****1. CHECK FUNCTION OF FUEL INJECTOR**

With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "EXHAUST GAS TEMP SEN 1 B1" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.
3. Start engine and warm it up to normal operating temperature.
4. Check that "EXHAUST GAS TEMP SEN 1 B1" indication as follows.

Monitor item	Condition	Value
EXHAUST GAS TEMP SEN 1 B1	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1,290 – 2,940 mV



Without M.U.T.-III SE

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM harness connector terminals as follows.

ECM			Condition	Voltage
Connector	+	-		
	Terminal			
B-11	12	34	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1.29 – 2.94 V

Is the inspection result normal?

YES >>

GO TO 2

.

NO >>

Replace exhaust gas temperature sensor. Refer to Exploded View. .

&lt;Added&gt;

## 2. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect exhaust gas temperature sensor harness connector.
3. Turn ignition switch ON.
4. Check the voltage between exhaust gas temperature sensor harness connector terminal and ground.

+		-	Voltage (Approx.)
Exhaust gas temperature sensor			
Connector	Terminal		
B-46	1	Ground	5 V

Is the inspection result normal?

YES >>

GO TO 3

.

NO >>

GO TO 4

.

## 3. CHECK EXHAUST GAS TEMPERATURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	2	B-11	34	Existed

4. Also check harness for short to power.

Is the inspection result normal?

YES >>

Check intermittent incident. Refer to Intermittent Incident.

NO >>

Repair or replace error-detected parts.

## 4. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	1	B-11	12	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >>

Perform the trouble diagnosis for ECM power supply circuit. Refer to Diagnosis Procedure.

NO >>

Repair or replace error-detected parts.

&lt;Added&gt;

## P2080 EXHAUST GAS TEMPERATURE SENSOR

## DTC Description

## DTC DETECTION LOGIC

DTC		M.U.T.-III SE screen terms (Trouble diagnosis content)	DTC detection condition	
P2080	00	EXHAUST GAS TEMPESENSOR 1 B1 (Exhaust gas temperature sensor 1 circuit range/performance)	Diagnosis condition	–
			Signal (terminal)	Exhaust gas temperature sensor signal
			Threshold	<ul style="list-style-type: none"> <li>The difference between estimated exhaust gas temperature calculated by ECM and temperature sent from exhaust gas temperature sensor is approx. 100°C (212°F) or more</li> <li>The difference between exhaust gas temperature sent from exhaU1st gas temperature calculated by ECM is approx. 100°C (212°F) or more</li> </ul>
			Diagnosis delay time	20 seconds or more

## POSSIBLE CAUSE

- Exhaust gas leaks
- Exhaust gas temperature sensor

## FAIL-SAFE

Not applicable

&lt;Added&gt;

## DTC Confirmation Procedure

### 1. CHECK DTC PRIORITY

- DTC P2080 is displayed with DTCs related to following items, first perform the trouble diagnosis of DTCs.
  - Crankshaft position sensor
  - Misfire
  - Fuel system
  - A/F sensor 1
  - A/F sensor 1 heater
  - Mass air flow sensor
  - Engine coolant temperature sensor
  - Intake air temperature sensor
  - Vehicle speed sensor
- DTC P2080 is displayed DTC P0544, P0545, P0546 or P2081, first perform the trouble diagnosis for DTC P0544, P0545, P0546 or P2081.

Is applicable DTC detected?

YES >>

Perform applicable DTC. Refer to .

NO >>

GO TO 2

### 2. PRECONDITIONING

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at 10 seconds before conducting the next test.

TEST CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

>>

GO TO 3

### 3. PERFORM DTC CONFIRMATION PROCEDURE

 With M.U.T.-III SE

1. Start the engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.
3. Maintain the following conditions for at least 120 consecutive seconds.



**NOTE:**

Keep the accelerator pedal as steady as possible during cruising.

**CAUTION:**

Always drive vehicle in safe manner and obey all traffic laws.

Items	Conditions
COOLANT TEMP/S	More than 65°C (149°F)
INT/A TEMP SE	<ul style="list-style-type: none"> <li>• More than 0°C (32°F)</li> <li>• More than 50°C (122°F)</li> </ul>
VHCL SPEED SE	90 - 100 km/h (56 - 62 MPH)

4. Check 1st trip DTC.

 With GST

Follow the procedure "With M.U.T.-III SE" above.

&lt;Added&gt;

Is 1st trip DTC detected?

YES &gt;&gt;

Proceed to .

NO &gt;&gt;

The malfunction symptom before repair: Refer to

NO &gt;&gt;

Confirmation after repair: INSPECTION END

## DTC Diagnosis Procedure

### 1. CHECK DTC PRIORITY

- DTC P2080 is displayed with DTCs related to following items, first perform the trouble diagnosis of DTCs.
  - Crankshaft position sensor
  - Misfire
  - Fuel system
  - A/F sensor 1
  - A/F sensor 1 heater
  - Mass air flow sensor
  - Engine coolant temperature sensor
  - Intake air temperature sensor
  - Vehicle speed sensor
- DTC P2080 is displayed DTC P0544, P0545, P0546 or P2081, first perform the trouble diagnosis for DTC P0544, P0545, P0546 or P2081.

Is applicable DTC detected?

YES &gt;&gt;

Perform applicable DTC. Refer to .

NO &gt;&gt;

GO TO 2.

### 2. PERFORM DTC CONFIRMATION PROCEDURE



With M.U.T.-III SE

1. Start the engine and warm it up to normal operating temperature.
2. Select "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.

Is the inspection result normal?

YES &gt;&gt;


GO TO 3.

NO &gt;&gt;

Repair or replace error-detected parts.


<Added>

**3. CHECK EXHAUST GAS TEMPERATURE SENSOR**

 With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "EXHAUST GAS TEMP SEN 1 B1" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.
3. Check that "EXHAUST GAS TEMP SEN 1 B1" indication as follows.

Monitor item	Condition	Value
EXHAUST GAS TEMP SEN 1 B1	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1.05 – 4.00 V

 Without M.U.T.-III SE

1. Warm engine up to normal operating temperature.
2. Check that voltage between ECM harness connector terminals as follows.

ECM			Condition	Voltage
Connector	+	-		
		Terminal		
B-11	12	34	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1.05 – 4.00 V

Is the inspection result normal?

YES >>

INSPECTION END

NO >>

Replace exhaust gas temperature sensor. Refer to Exploded View. .

&lt;Added&gt;

## P2081 EXHAUST GAS TEMPERETURE SENSOR

**DTC Description****DTC DETECTION LOGIC**

DTC		M.U.T.-III SE screen terms (Trouble diagnosis content)	DTC detection condition	
P2081	00	EXHAUST GAS TEMPESENSOR 1 B1 (Exhaust gas temperature sensor circuit intermittent bank 1 sensor 1)	Diagnosis condition	–
			Signal (terminal)	Exhaust gas temperature sensor signal
			Threshold	ECM detects that a voltage signal from exhaust gas temperature sensor is 4.84 V or more.
			Diagnosis delay time	5 seconds or more

**POSSIBLE CAUSE**

- Harness or connectors  
(Exhaust gas temperature sensor circuit is open.)
- Exhaust gas temperature sensor

**FAIL-SAFE**

Not applicable

**DTC Confirmation Procedure****1. PRECONDITIONING-1**

If DTC Confirmation Procedure has been previously conducted, always perform the following procedure before conducting the next test.

1. Turn ignition switch OFF and wait at least 10 seconds.
2. Turn ignition switch ON.
3. Turn ignition switch OFF and wait at least 10 seconds.

**TESTING CONDITION:**

Before performing the following procedure, confirm that battery voltage is more than 11 V at idle.

&gt;&gt;

GO TO 2**2. PRECONDITIONING-2**

 With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "COOLANT TEMP/S" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III.
3. Check the following conditions:

COOLANT TEMP/S	More than –30°C (–22°F)
-------------------	----------------------------

 With GST

Follow the procedure "With M.U.T.-III SE" above.



&lt;Added&gt;

Is the condition satisfied?

YES >>

GO TO 4

.

NO >>

GO TO 3

.

### 3. PRECONDITIONING-3

---



With M.U.T.-III SE

1. Start the engine until the following condition is satisfied.

COOLANT TEMP/S	More than -30°C (-22°F)
-------------------	----------------------------

2. Turn ignition switch OFF and wait at least 10 seconds.
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 10 seconds.



With GST

Follow the procedure "With M.U.T.-III SE" above.

>>

GO TO 4

.

<Added>

#### 4. PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to P range.
2. Start engine and let it idle for at least 20 seconds.
3. Depress the accelerator pedal for 5 seconds or more.



**NOTE:**

**Do not release the accelerator pedal during DTC confirmation procedure.**

4. Check 1st trip DTC.

Is 1st trip DTC detected?

YES >>

Proceed to .

NO >>

To check malfunction symptom before repair: Refer to Intermittent Incident.

NO >>

Confirmation after repair: INSPECTION END

### DTC Diagnosis Procedure

#### 1. CHECK FUNCTION OF FUEL INJECTOR



With M.U.T.-III SE

1. Turn ignition switch ON.
2. Select "EXHAUST GAS TEMP SEN 1 B1" in "DATA MONITOR" mode of "ENGINE" using M.U.T.-III SE.
3. Start engine and warm it up to normal operating temperature.
4. Check that "EXHAUST GAS TEMP SEN 1 B1" indication as follows.

Monitor item	Condition	Value
EXHAUST GAS TEMP SEN 1 B1	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1,290 – 2,940 mV



Without M.U.T.-III SE

1. Start engine and warm it up to normal operating temperature.
2. Check that voltage between ECM harness connector terminals as follows.

ECM			Condition	Voltage
Connector	+	-		
		Terminal		
B-11	12	34	<ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	1.29 – 2.94 V

Is the inspection result normal?

YES >>

GO TO 2

.

NO >>

Replace exhaust gas temperature sensor. Refer to Exploded View. .

&lt;Added&gt;

## 2. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect exhaust gas temperature sensor harness connector.
3. Turn ignition switch ON.
4. Check the voltage between exhaust gas temperature sensor harness connector terminal and ground.

+		-	Voltage (Approx.)
Exhaust gas temperature sensor			
Connector	Terminal		
B-46	1	Ground	5 V

Is the inspection result normal?

YES >>

GO TO 3

.

NO >>

GO TO 4

.

## 3. CHECK EXHAUST GAS TEMPERATURE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	2	B-11	34	Existed

4. Also check harness for short to power.

Is the inspection result normal?

YES >>

Check intermittent incident. Refer to Intermittent Incident.

NO >>

Repair or replace error-detected parts.

## 4. CHECK EXHAUST GAS TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between exhaust gas temperature sensor harness connector and ECM harness connector.

+		-		Continuity
Exhaust gas temperature sensor		ECM		
Connector	Terminal	Connector	Terminal	
B-46	1	B-11	12	Existed

4. Also check harness for short to ground and short to power.

Is the inspection result normal?

YES >>

Perform the trouble diagnosis for ECM power supply circuit. Refer to Diagnosis Procedure.

NO >>

Repair or replace error-detected parts.

	SYMPTOM													Reference page
	HARD/NO START/RES TART (EXCP.HA)	ENGIN ESTALL	HESITATION/SURGIN G/F LAT SPO T	SPARKKNOCK/D NATION	LACK OF POWER/P OOR ACCEL ERATION	HIGH IDL E/LOW IDL E	ROUGH IDL E/H UN TING	IDLING VIB RATION	SLOW/NO RET URN TO IDL E	OVERHEATS/WAT ER TEM PER ATURE HIGH	EXCESSIVE FUE L CONSU MPTION	EXCESSIVE OIL CON SU MPTION	BATTERY DEAD (UN DER CHARGE )	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Electric Intake valve timing control module circuit			3		3	3								Diagnosis Procedure <a href="#">POWER SUPPLY AND GROUND CIRCUIT</a> , DTC Description <a href="#">U012E CAN COMMUNICATION</a> , DTC Description <a href="#">U042F CAN COMMUNICATION</a> , DTC Description <a href="#">P2614 INTAKE CAMSHAFT POSITION SENSOR</a> , DTC Description <a href="#">P2615 INTAKE CAMSHAFT POSITION SENSOR</a> , DTC Description <a href="#">P2616 INTAKE CAMSHAFT POSITION SENSOR</a> , DTC Description <a href="#">P2616 INTAKE CAMSHAFT POSITION SENSOR</a> , DTC Description <a href="#">P2618 CRANKSHAFT POSITION SENSOR</a> , DTC Description <a href="#">P2619 CRANKSHAFT POSITION SENSOR</a> , DTC Description <a href="#">P34C8 ELECTRIC INTAKE VALVE TIMING CONTROL MODULE</a>
Electric intake valve timing control actuator circuit					3									DTC Description <a href="#">P34AC ELECTRIC INTAKE VALVE TIMING CONTROL ACTUATOR</a> , DTC Description <a href="#">P34AD ELECTRIC INTAKE VALVE TIMING CONTROL ACTUATOR</a> , DTC Description <a href="#">P34AE ELECTRIC INTAKE VALVE TIMING CONTROL POSITION SENSOR</a> , DTC Description <a href="#">P34AE ELECTRIC INTAKE VALVE TIMING CONTROL POSITION SENSOR</a>
Exhaust valve timing intermediate lock control solenoid valve circuit														DTC Description <a href="#">P052A INTAKE VALVE TIMING CONTROL</a> , DTC Description <a href="#">P052B INTAKE VALVE TIMING CONTROL</a>
Exhaust camshaft position sensor circuit	5	5	5	5	5			5	5			5		DTC Description <a href="#">P0365 EXHAUST CAMSHAFT POSITION SENSOR</a>
PNP signal circuit			3		3			3	3			3		Inspection <a href="#">P0850 PNP SWITCH</a>
Refrigerant pressure sensor circuit		2					3			3		4		Inspection <a href="#">REFRIGERANT PRESSURE SENSOR</a>
Electrical load signal circuit								3						<a href="#">ELECTRICAL LOAD SIGNAL</a>

Attached sheet 14(2/2)

<Added>

Exhaust gas temperature sensor											5			ENGINE CONTROL SYSTEM - PR25DD - DTC/CIRCUIT DIAGNOSIS - P0544 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P0545 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P0546 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P2080 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P2081 EXHAUST GAS TEMPERATURE SENSOR - DTC Description
--------------------------------	--	--	--	--	--	--	--	--	--	--	---	--	--	---

## DTC Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC	Detected items
1	C053C	Wheel speed sensor
	P0101, P0102, P0103	Mass air flow sensor
	P0106	Manifold absolute pressure sensor
	P0107, P0108, P2227	Atmospheric pressure sensor
	P0111, P0112, P0113, P0127	Intake air temperature sensor
	P0116, P0117, P0118, P0125	Engine coolant temperature sensor
	P0122, P0123, P0222, P0223, P1225, P1226, P2135	Throttle position sensor
	P0128	Thermostat function
	P0181, P0182, P0183	Fuel tank temperature sensor
	P0191, P0192, P0193, P119A, P119B, P119C, P119D, P119E	Fuel rail pressure sensor
	P0196, P0197, P0198	Engine oil temperature sensor
	P025A, P025C, P025D	Fuel pump relay
	P026B, P2B96	Injection system
	P0326, P0327, P0328, P032B, P032C, P032D	Knock sensor
	P0315, P0335, P2617, P2618, P2619	Crankshaft position sensor
	P0340, P0365, P2614, P2615, P2616	Camshaft position sensor
	P044A, P044B, P044C, P044D, P044E	EGR volume control valve position sensor
	P0460, P0461, P0462, P0463	Fuel level sensor
	P0500, P0501, P2159	Vehicle speed sensor
	P0520, P0522, P0523, P0524	Engine oil pressure sensor
	P0531, P0532, P0533, <span style="border: 1px solid red; padding: 2px;">P2080</span> , <span style="color: red;">&lt;Added&gt;</span>	Refrigerant pressure sensor
	P0544, P0545, P0546, <del>P2081</del>	Exhaust gas temperature sensor
	P0604, P0605, P0606, P0607, P060A, P060B, P060C, P061B, P062B, P062D, P062F, P1603, P2610	ECM
	P0641, P34C8	Electric intake valve timing control module
	P06B0, P06B3, P06E6	Sensor power supply
	P06DA, P06DB, P06DC	Engine oil pressure control solenoid valve
	P0850	Transmission range switch
	P1197	Out of gas*
	P155B	Energy management control
	P155D, P155E, P155F	Generator
	P161D, P161E, P161F	Immobilizer
	P2014, P2015, P2016, P2017, P2018	Intake manifold runner control valve position sensor
	P2121, P2122, P2123, P2126, P2127, P2128, P2138	Accelerator pedal position sensor
	U0101, U0122, U012E, U0146, U0155, U042F	CAN communication line
	U0284, U1040	Engine communication line
	U1050, U1051	LIN communication line
	U1327, U2118, U2148, U214A, U214E, U214F, U2150, U2152, U215B, U2165, U2176, U2241, U2248, U2252, U2259, U226B, U2276, U2384	MAC key

## ENGINE CONTROL SYSTEM

125

DTC *1		Items (M.U.T.-III SE screen terms)	SRT code	Trip	MIL	Permanent DTC group *3	Reference page	
M.U.T.-III SE	GST *2							
P1574	00	P1574	ASCD VHL SPD SEN	—	1	—	<a href="#">DTC Description</a>	
P1575	00	P1575	BRAKE SW	—	2	×	A + B	<a href="#">DTC Description</a>
P159F	00	P159F	ACTIVE GRILLE AIR SHUTTER A	—	2	—	—	<a href="#">DTC Description</a>
P1603	00	P1603	CONTROL MODULE	—	2	—	—	<a href="#">DTC Description</a>
P161D	00	P161D	IMMOBILIZER	—	2	—	—	<a href="#">DTC Description</a>
P161E	00	P161E	IMMOBILIZER	—	2	—	—	—
P161F	00	P161F	IMMOBILIZER	—	2	—	—	<a href="#">DTC Description</a>
P1800	00	P1800	VIA S/V CIRCB1	—	2	—	—	<a href="#">DTC Description</a>
P1805	00	P1805	BRAKE SW/CIRCUIT	—	1	—	—	<a href="#">DTC Description</a>
P1A10	00	P1A10	ECM initial learning Incomplete	—	2	—	—	<a href="#">DTC Description</a>
P2004	00	P2004	SWIRL CONT/V (B1)	—	2	×	A + B	<a href="#">DTC Description</a>
P2008	00	P2008	SWIRL CONT/V (B1)	—	2	×	A + B	<a href="#">DTC Description</a>
P2009	00	P2009	Intake manifold runner control	—	2	×	A + B	<a href="#">DTC Description</a>
P2010	00	P2010	Intake manifold runner control	—	2	×	A + B	<a href="#">DTC Description</a>
P2014	00	P2014	SWIRL CONT SEN/SW	—	2	×	A + B	<a href="#">DTC Description</a>
P2015	00	P2015	Intake manifold runner posi sen/sw B1	—	2	×	A + B	<a href="#">DTC Description</a>
P2016	00	P2016	IN/MANIFOLD RUNNER POS SEN B1	—	2	×	A + B	<a href="#">DTC Description</a>
P2017	00	P2017	IN/MANIFOLD RUNNER POS SEN B1	—	2	×	A + B	<a href="#">DTC Description</a>
P2018	00	P2018	IN/MANIFOLD RUNNER POS SEN B1	—	2	×	A + B	<a href="#">DTC Description</a>
P2081	00	P2081	EXHAUST GAS TEMP SENSOR 1 B1	—	2	×	B	<a href="#">DTC Description</a>
P2096	00	P2096	POST CATALYST FUEL TRIM SYS B1	×	2	×	A	<a href="#">DTC Description</a>
P2097	00	P2097	POST CATALYST FUEL TRIM SYS B1	×	2	×	A	<a href="#">DTC Description</a>
P2100	00	P2100	ETC MOT PWR-B1	—	1	×	A + B	<a href="#">DTC Description</a>
P2101	00	P2101	ETC FNCTN/CIRC-B1	—	1	×	A + B	<a href="#">DTC Description</a>
P2103	00	P2103	ETC MOT PWR-B1	—	1	×	A + B	<a href="#">DTC Description</a>
P2119	00	P2119	ETC ACTR-B1	—	1	× or —	A + B or —	<a href="#">DTC Description</a>
P2121	00	P2121	Throttle/pedal position sen/sw D	—	1	×	A + B	<a href="#">DTC Description</a>
P2122	00	P2122	APP SEN 1/CIRC	—	1	×	A + B	<a href="#">DTC Description</a>
P2123	00	P2123	APP SEN 1/CIRC	—	1	×	A + B	<a href="#">DTC Description</a>
P2126	00	P2126	Throttle/pedal position sen/sw E	—	1	×	A + B	<a href="#">DTC Description</a>
P2127	00	P2127	APP SEN 2/CIRC	—	1	×	A + B	<a href="#">DTC Description</a>
P2128	00	P2128	APP SEN 2/CIRC	—	1	×	A + B	<a href="#">DTC Description</a>
P2135	00	P2135	TP SENSOR-B1	—	1	×	A + B	<a href="#">DTC Description</a>
P2138	00	P2138	APP SENSOR	—	1	×	A + B	<a href="#">DTC Description</a>
P2159	00	P2159	VEHICLE SPEED SEN B	—	2	×	A + B	<a href="#">DTC Description</a>
P219A	00	P219A	AIR FUEL RATIO IMBALANCE B1	×	2	×	A	<a href="#">DTC Description</a>
P2227	00	P2227	Barometric pressure sensor A	—	2	×	A + B	<a href="#">DTC Description</a>
P2237	00	P2237	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">DTC Description</a>
P2238	00	P2238	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">DTC Description</a>
P2239	00	P2239	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">DTC Description</a>
P2251	00	P2251	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">DTC Description</a>
P2252	00	P2252	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">DTC Description</a>
P2253	00	P2253	O2 sensor bank 1 sensor 1	—	2	×	A + B	<a href="#">DTC Description</a>
P2270	00	P2270	O2 sensor signal bank 1 sensor 2	×	2	×	A + B	<a href="#">DTC Description</a>

P2080	00	P2080	EXHAUST GAS TEMP SENSOR 1 B1	-	2	×	B	Attached sheet 12(1/4)
-------	----	-------	------------------------------	---	---	---	---	------------------------

&lt;Added&gt;

ENGINE CONTROL SYSTEM

1049

	SYMPTOM													Reference page
	HA RD/ NO STA RT/ RES TAR T (EX CP. HA)	EN GIN E STA LL	HES ITAT ION/ SUR GIN G/ LAT SPO T	SPA RK KN OC K/ ETO NAT ION	LAC K OF PO WE R/ P OO R AC CEL ERA TION	HIG H IDL E/ LOW IDL E	RO UG H IDL E/ H UN TIN G	IDLI NG VIB RAT ION	SLO W/ NO RET URN TO IDL E	OVE RHE ATS/ WAT ER TEM PER ATU RE HIG H	EXC ESS IVE FUE L CO NSU MPT ION	EXC ESS IVE OIL CO NSU MPT ION	BAT TER Y DEAD (UN DER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Electric Intake valve timing control module circuit			3		3	3								Diagnosis Procedure <a href="#">DTC Description</a> , Diagnosis Procedure, DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a>
Electric intake valve timing control actuator circuit					3									DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a>
Exhaust valve timing intermediate lock control solenoid valve circuit														DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a> , DTC Description <a href="#">DTC Description</a>
Exhaust camshaft position sensor circuit	5	5	5	5	5		5	5			5			DTC Description <a href="#">DTC Description</a>
Exhaust gas temperature sensor											5			<del>DTC Description <a href="#">DTC Description</a>, DTC Description <a href="#">DTC Description</a>, DTC Description <a href="#">DTC Description</a>, DTC Description <a href="#">DTC Description</a></del>
PNP signal circuit			3		3		3	3			3			Inspection <a href="#">DTC Description</a> <Incorrect>
Refrigerant pressure sensor circuit		2					3		3		4			Inspection <a href="#">Component Function Check</a>
Electrical load signal circuit								3						<a href="#">Component Function Check</a>
Intake manifold runner control valve motor circuit					4	4								Inspection
Intake manifold runner control valve position sensor circuit					4	4								DTC Description <a href="#">DTC Description</a>
Intake manifold tuning valve circuit					1									Inspection <a href="#">DTC Description</a>
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	Work Flow, <a href="#">Work Flow</a>
ASCD steering switch circuit														<a href="#">DTC Diagnosis Procedure</a>
ABS actuator and electric unit (control unit)			4											Work Flow

1 - 6: The numbers refer to the order of inspection.

(continued on next table)

ENGINE CONTROL SYSTEM - PR25DD - DTC/CIRCUIT DIAGNOSIS - P0544 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P0545 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P0546 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P2080 EXHAUST GAS TEMPERATURE SENSOR - DTC Description, P2081 EXHAUST GAS TEMPERATURE SENSOR - DTC Description

<Correct>




HEADLIGHT ADJUSTMENT (LOW-BEAM)


CAUTION:

- Do not cover a headlight for more than three minutes to prevent the plastic headlight lens deformation.
- Be sure to adjust the aiming adjustment screw in the tightening direction.

1.The low-beam headlight should project on the screen upper edge of the beam (cut-off).




2.When adjusting the vertical direction side, insert the screwdriver from the service hole near the headlight assembly mounting bolts.



3.Turn the adjusting screws to achieve the specified low-beam cut-off location on the aiming screen.

<Entry type>  
<Added>



Standard value:

(Vertical direction) Horizontal line (H) ± 50.5 mm (± 2.0 in) (± 0.38 degrees angle)

(Horizontal direction): ± 133.0 mm (± 5.2 in) (± 1 degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)

EXTERIOR LIGHTING SYSTEM



NOTE:

High-beam pattern should be correct when the low-beams are adjusted properly.

Luminous Intensity Measurement

1. Set the headlights to high-beam.
2. Using a photometer, and following its manufacturer's instruction manual, measure the headlight center intensity and check to be sure that the limit value is satisfied.

Limit: 40,000 cd or more (When a screen is set 18.3m (60 ft) ahead of the vehicle)



NOTE:

When measuring the intensity, maintain an engine speed of 2,000 r/min, with the battery fully charged.

There may be special local regulations pertaining to headlight intensity. Be sure to make any adjustments necessary to satisfy such regulations.

If an illuminometer is used to make the measurements, convert its values to photometer values by using the following formula.

$I = E \times r^2$ :

- I = intensity (cd)
- E = illumination (lux)
- r = distance (m) from headlights to illuminometer


FRONT FOG LAMP AIMING ADJUSTMENT

service specifications

Item	Standard value	Limit
Fog light aiming (cutoff line direction) [at 7.62 m (25.0 ft)]	The horizontal line 277.0 mm (10.91 in) (2.08 degrees angle) below the horizontal line (H)	-
Fog light aiming (vertical direction) [at 7.62 m (25.0 ft)]	-	Area from 163.0 mm (6.42 in) (1.22 degrees angle) above the cutoff line to 163.0 mm (6.42 in) (1.22 degrees angle) below the cutoff line
Fog light aiming (horizontal direction) [at 7.62 m (25.0 ft)]	-	Vertical line (V) ± 599.7 mm (± 23.6 in) (± 4.5 degrees angle).

<Added>

<Premium type>



Standard value:

(Vertical direction) Horizontal line (H) + 50.5 mm, - 0 mm (+ 2.0 in, - 0 in) (+ 0.38 degrees angle, - 0 degrees angle)

(Horizontal direction): ± 133.0 mm (± 5.2 in) (± 1 degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)



NOTE:

High-beam pattern should be correct when the low-beams are adjusted properly.

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

Both side front fog lamps are not turned ON in any condition.

Diagnosis Procedure

1. COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [Symptom Table](#).

Is the inspection result normal?

YES >>

GO TO 2

NO >>

Repair or replace the malfunctioning part.

2. CHECK FRONT FOG LIGHT REQUEST SIGNAL

With M.U.T.-III SE

1. Select "FRONT FOG LIGHT REQ" in "Data List" mode of "IPDM E/R" using M.U.T.-III SE.
2. With operating the front fog light switch, check the monitor status.

Monitor item	Condition	Monitor status
FRONT FOG LIGHT REQ	Front fog light switch	On
	(With lighting switch 2ND)	Off

Is the item status normal?

YES >>

Replace IPDM E/R. Refer to [Removal and Installation](#).

NO >>

Replace BCM. Refer to [Removal and Installation](#).

PERIODIC MAINTENANCE

HEADLAMP AIMING ADJUSTMENT

Service Specifications

Item	Standard value	Limit
Headlight aiming [at 7.62 m (25.0 ft)]	Vertical direction	-
	Horizontal direction	-
Headlight intensity cd (at high-beam)	-	40,000 or more (when a screen is set 18.3 m (60 ft) ahead of the vehicle)

PRECAUTIONS ON HOW TO USE THE HEADLIGHT ASSEMBLY

Be careful with the following items as resin lenses are used in the headlight assembly.

- Don't illuminate the headlight for three minutes or more when the headlight is covered with scratch protector.
- Don't tape the outer lens.
- Don't scratch the outer lens surface with a sharp edged special tool.

Headlight aiming [at 7.62 m (25.0 ft)]	Low-beam	Vertical direction	Entry type	Standard value	Limit
			Standard type	Horizontal line (H) $\pm 50.5$ mm ( $\pm 2.0$ in) $\pm 0.38$ degrees angle	-
			Premium type	Vertical direction) Horizontal line (H) $+ 50.5$ mm - 0 mm (+2.0 in, - 0 in) $+ 0.38$ degrees angle, - 0 degrees angle	-
		Horizontal direction		$\pm 133.3$ mm ( $\pm 5.2$ in) ( $\pm 1$ degrees angle) from the axis, which is 266.1 mm (10.5 in) (2 degrees angle) rightward from the vertical line (V)	-