

Important Information for Maintaining, Diagnosing and Checking the (AGM) Battery (60/12)

Vehicle type and cause



Information

This Technical Information replaces the TI dated 30 July 2012.

Changes/additions compared to the previous Technical Information:

- Several chargers removed and added under “Recommended chargers” (range streamlined).
- Other test methods added to Step 7 under “Checks”.

Change Overview

Revision	Date	Change
0	03/12/2018	▪ First Publication
1	01/28/2026	▪ Update to Order Types

Model Line: **Cayenne (92A / 9YA / 9YB)**

Macan

Model Year: **As of 2011**

Concerns: **AGM starter battery (referred to below simply as “battery”)**

Cause: **Customer complaints concerning battery-related topics**

Recurring customer complaints concerning topics relating to battery capacity and quality.



Information

This "Technical Information" is intended as a **summary guide to assist you** with the following battery-related topics:

- Basic information on the battery, see ⇒ *Technical Information 'Basic information'*,
- **documentation required**, see ⇒ *Technical Information 'Documentation is essential in the event of a complaint'*,
- recommended **chargers and tools**, see ⇒ *Technical Information 'Recommended chargers and tools'*,
- possible **checks**, see ⇒ *Technical Information 'Checking the battery'*,
- **procedure** if the **battery has to be replaced/storing replacement batteries**, see ⇒ *Technical Information 'Procedure for replacing the battery'* and
- available **reference material**.

The critical points:

- Quality assurance for **battery life and battery performance** and
- **Trickle charging** in the **workshop and by customers themselves**

should also be generally improved as a result.

Basic information on the battery

Characteristics: The **AGM "starter battery"**:

- is absolutely essential for the **"Auto Start Stop" function and recuperation**,
- is totally **maintenance-free** ⇒ **no need** to add water or check the electrolyte,
- **is leak-proof and dry**,
- **is not sensitive to vibrations and shaking** and
- has a **high cold-start performance**.



Information

The battery has a limited service life.

The service life of the battery is affected by:

- the driving conditions for the vehicle and
- thus, by the care and maintenance of the battery (trickle charging, etc.).

⇒ If a charger is not connected in order to trickle-charge the battery when the vehicle is idle for extended periods,

the battery life will be reduced considerably, thereby resulting in **natural wear**.

Please pass this information on to your customers.



Information

When working on the vehicle:

- using the PIWIS Tester or
 - for work that takes longer than 15 minutes,
- a charger must be connected in order to trickle-charge the battery.

Special features:



Information

The **AGM battery**:

- is installed as standard in the vehicle and **must not be replaced by a conventional "starter battery"** and
- **must not be opened.**

If **the battery needs to be replaced**, the following data must be entered in the **gateway control unit** using PIWIS Tester II (under Maintenance/repairs - Change battery):

- Serial number,
- part number,
- manufacturer and
- battery size.

The **battery sensor**:

- is connected between the battery negative terminal and ground cable,
- is an important **part of the energy management system** and
- is used to **measure battery variables** (battery current, battery voltage and negative terminal temperature) for **vehicle electrical system diagnosis**.

NOTICE

A battery charger for providing an external power supply or for jump-lead starting is connected directly to the battery in the vehicle.

- **Damage to battery sensor.**
 - **Battery sensor sends incorrect battery values to the vehicle electrical system.**
- ⇒ **Always connect a battery charger for providing an external power supply or for jump-lead starting to the defined connections in the engine compartment. ⇒ Workshop Manual '2X00INC8 Battery trickle charging'**

The battery is based on **AGM technology (AbsorbedGlassMat)**:

- Special micro-glass-fibre mats lie between the lead plates of the battery and contain all the battery acid.
- The sealed system is equipped with a pressure relief valve for the safe discharge of any gases.

Chemical processes:

The gas produced during charging is transferred through the pores in the glass-fibre mat to the negative electrode, where it is converted back to water.

⇒ Water loss is impossible during normal operation.

Documentation is essential in the event of a complaint

Documentation:

**Information**

If a customer complaint is received concerning topics relating to battery capacity and quality, the following **written documentation** must be created **before carrying out any other work**:

1. **Create a VAL** (Vehicle Analysis Log) and attach it to the job ⇒ charger required to trickle-charge the battery.

2. Document the following points and attach them to the job.

- Precise description of the **fault types**
- Precise description of the **vehicle history**
- Precise description of the **activities performed**
- Precise description of the possible **charger used**
- **Battery production date** (see negative terminal)
- **Log of a battery tester**
- In addition, state whether the battery was discharged by an active load (e.g. overnight)
- Also state whether a charger was used by the customer to trickle-charge the battery
- Also state whether the vehicle has a seasonal licence plate or is used in seasonal operation

⇒ These battery documents will be **reviewed as required** as part of the PSA (Porsche Service Analysis).

⇒ Furthermore, we reserve the right to **reject warranty claims** if the instructions and information on **care, maintenance and documentation are not observed**.

Recommended chargers and tools**Recommended and suitable battery chargers and battery testers**

⇒ An **up-to-date list** of recommended and suitable battery testers and chargers can be found in the PIWIS information system, under **Workshop Equipment and Special Tools Manual** (WEST), chapter ⇒ *Workshop Equipment 'WE1393 1 - Battery testers/chargers'*

NOTICE

A battery charger for providing an external power supply or for jump-lead starting is connected directly to the battery in the vehicle.

- **Damage to battery sensor.**
 - **Battery sensor sends incorrect battery values to the vehicle electrical system.**
- ⇒ **Always connect a battery charger for providing an external power supply or for jump-lead starting to the defined connections in the engine compartment. ⇒ *Workshop Manual '2X00INC8 Battery trickle charging'***

- Chargers:
- **Battery Charger, 90 A**
 - **Battery Charger, 90 A**
 - **Battery Charger, 45 A**
 - **NEW: Battery Charger, 45 A**
 - **NEW: Battery Charger, 90 A**
 - **NEW: Battery Charger, 90 A**
 - **NEW: Battery Charger**

Specifically for customers (see Porsche Tequipment - Accessories and Maintenance):

- 955.044.900.56 ⇒ Charge-o-mat II
- 955.044.900.55 ⇒ Charge-o-mat II (GB version)
- 955.044.900.54 ⇒ Charge-o-mat II (USA version, 110 V)
- **Adapter** (required for vehicles without cigarette lighter): 000.043.202.55 ⇒ Adapter (for Charge-o-mat II and vehicles without cigarette lighter)

- Battery test: ⇒ **For measuring**
- Battery condition
 - Idle current, idle voltage and battery voltage:
- **Battery tester**
 - **Battery tester**



Information

Some of the **functions of a battery tester** (e.g. measuring battery voltage and closed-circuit current) can **also be carried out** using the

- **9900 - PIWIS Tester 3** or
- **charger** (see operating instructions for the relevant charger)

if necessary.

- Part No.: 999. ⇒ Battery (capacity: **70 Ah**)
 999. ⇒ Battery (capacity: **80 Ah**)
 999. ⇒ Battery (capacity: **95 Ah**)

References: ⇒ Workshop Manual '270689 Battery trickle charge'

Checking the battery



Ignition of the AGM battery during charging.

- **Danger of injury and risk of damage to materials coming into contact with battery acid when charging the AGM battery.**
- ⇒ **Never enter rooms in which batteries are being charged while holding a naked flame or smoking. Gases produced by the charging process in the batteries are highly flammable.**



Information

Document the following steps and the respective results carefully.

The battery temperature must be at least 10 °C (50 °F) when carrying out the checks.

Checks:

The following checks are carried out on the battery for diagnostic and error analysis purposes:

- 1 **General data** relating to the vehicle, battery (see below) and vehicle mileage per year.




Figure 1

⇒ The specifications on the battery (in the vehicle) may differ from the specifications shown in Figure 1

⇒ **Illustration (⇒ Figure 1) serves only as an example.**

- Battery type: Rating in Ah (⇒ Figure 1 -Item A-),
- Date of manufacture of the battery (stamped on negative terminal): ⇒ Figure 1 -Item B-),
- Battery I-No. (for 2D code: ⇒ Figure 1 -Item C-),
- Item number (⇒ Figure 1 -Item D-) and

- Battery manufacturer (⇒ *Figure 1 -Item E-*),
 - Safety instructions and warnings for handling the battery (⇒ *Figure 1 -Item F-*).
- 2 **Visual inspection** of the battery:
 - 2.1 for damage to the housing,
 - 2.2 corroded and/or loose terminals and
 - 3 Check the battery using a **battery tester** (see ⇒ *Technical Information '270689 Recommended chargers and tools'*):
 - ⇒ Battery **charge state before and after charging**.
 - 4 **Charge the battery** using a suitable **charger** (see chapter ⇒ *Technical Information '270689 Recommended chargers and tools'*, but with a current rating of at least 40 Ah ⇒ Observe minimum charging time and operating instructions for the charger).

If the **previous diagnostics**

- **clearly indicate a defective battery** and
- There are **no problems** between the problem and the customer statement,

⇒ **Replacing the battery** (see ⇒ *Workshop Manual '2706 1900 Removing and installing battery'*).

End of remedial action.



Information

In the event of technical **problems**, e.g.

- measurement and test results and/or diagnosis indicate that the battery is defective despite having handled the battery carefully and
- having trickle-charged the battery,

⇒ the following **fault finding/diagnostic** steps

must be performed in the entire vehicle electrical system **in addition to replacing the battery**:

- 5 Measure the battery voltage using a voltmeter/voltage tester ⇒ *Workshop Manual '270601 Checking battery with battery tester'*:
 - Battery idle voltage,
 - Battery voltage with engine running at idle speed and
 - Measurement at an engine speed of approx. 3,000 - 4,000 rpm **with active loads** (light, heating, air conditioning).

⇒ The PIWIS Tester can also be used for these measurements.

- 6 **Measure closed-circuit current**, see ⇒ *Workshop Manual '9X00IN Closed-circuit current measurement'* (if the measured value is greater than 30 mA ⇒ determine the cause).
- 7 Generator test - Measure **generator voltage** and **charging current**:
 - Generator voltage with engine running at idle speed and
 - Generator voltage at an engine speed of approx. 3,000 - 4,000 rpm **with active loads** (light, heating, air conditioning).
 - Charging current on the generator with engine running at idle speed (measurement using commercially available clamp-on ammeter) and
 - Charging current on the generator at an engine speed of approx. 3,000 - 4,000 rpm (measurement using commercially available clamp-on ammeter).

Other test methods:

 - 7.1 Using PIWIS Tester II ⇒ Go to **GFF** ("Guided Fault Finding") ⇒ **Generator test**: Document **"2722"** (power supply - control system - supply voltage - charging system) or
 - 7.2 With the PIWIS Tester II ⇒ In the **"control unit overview"** select the **DME control unit**. The **generator voltage** is displayed in the **"Nominal values"** overview, or
 - 7.3 Alternatively, the voltage can even be measured directly at terminal 30 on the generator in some cases, depending on the vehicle model.
- 8 **Voltage drop measurement** (max. 0.6 V per line):
 - Measured on positive side ⇒ between battery positive terminal and generator positive and
 - Measured on negative side ⇒ between battery negative terminal and generator housing.
- 9 The following **values** (see table) can be **read out using PIWIS Tester II 9818**:
 - 9.1 Connect PIWIS Tester to the vehicle.
 - 9.2 Switch on ignition.
 - 9.3 Select the relevant vehicle in the "Diagnostics" menu.
 - 9.4 Select the **"Gateway"** control unit in the "Control unit overview" menu and switch to the **"Actual values/input signals"** menu.
 - 9.5 Answer **YES** in response to the VAL (Vehicle Analysis Log) prompt.
 - 9.6 Read the campaign information instructions and confirm by pressing **F12** .
 - 9.7 In the "Actual values/input signals" overview, select **"Battery"** and **"Battery charge state history"** and press **F12** to confirm.
 - 9.8 In the "Actual values" overview, **select the following actual values**:

Battery ageing	charge-related ... % performance-related ... %
Battery internal resistance	Actual ... mOhm
Battery charge state	... %
Open-circuit voltage	... V
Battery temperature	(Acid) ... (Terminal) ...
Closed-circuit current	Below limit value (Duration) ... min. Limit value exceeded (Duration) ... min.
Battery charge state History	Battery charge state 0 ... 25% Battery charge state 26 ... 50% Battery charge state 51 ... 75% Battery charge state 76 ... 100%

9.9 Press **F12** to confirm your selection.

9.10 **Read off and document actual values.**

9.11 Press **F11** to exit the display.

9.12 Press **F11** to go back.

End of remedial action.

Additional references, summary

References: **Further technical information about the installed battery type can be found in the relevant Driver's Manual.**

Forms:

Battery trickle charge:

⇒ *Technical Information '0X0000 Recommendations and measures for vehicle storage (26/09)'*

Testing and checking the battery:

⇒ *Workshop Manual '2706IN General information on AGM vehicle battery'*

⇒ *Workshop Manual '9X00IN01 Measurement of idle current'*

Disconnecting and reconnecting the battery / removal and installation or replacing the battery:

⇒ *Workshop Manual '9X00IN Work instructions after disconnecting the battery'*

⇒ *Workshop Manual '27061900 Removing and installing battery'*

Labor time

Labor time:	27060100: Checking the battery	Labor time: 20 TU
	27068950: Charging the battery	Labor time: 20 TU
	27061900: Removing and installing battery	Labor time: 15 TU
	27065500: Replacing battery	Labor time: 50 TU

Important Notice: Technical Bulletins issued by Porsche Cars North America, Inc. are intended only for use by professional automotive technicians who have attended Porsche service training courses. They are written to inform those technicians of conditions that may occur on some Porsche vehicles, or to provide information that could assist in the proper servicing of a vehicle. Porsche special tools may be necessary in order to perform certain operations identified in these bulletins. Use of tools and procedures other than those Porsche recommends in these bulletins may be detrimental to the safe operation of your vehicle, and may endanger the people working on it. Properly trained Porsche technicians have the equipment, tools, safety instructions, and know-how to do the job properly and safely. Part numbers listed in these bulletins are for reference only. The work procedures updated electronically in the Porsche PIWIS diagnostic and testing device take precedence and, in the event of a discrepancy, the work procedures in the PIWIS Tester are the ones that must be followed.

© 2026 Porsche Cars North America, Inc.