REKON DCM3 RESET PROCEDURE

- DISCONNECT SHORE POWER, TURN OFF CHARGE LINE DISCONNECT KEY AND TURN OFF THE BATTERY DISCONNECT SWITCH.
- ACCESS THE BATTERIES COMPARTMENT INSIDE THE COACH AT THE REAR PASSENGER SIDE COMPARTMENT. THE SHIELD IS HELD ON BY SPRING LOADED BOLTS. TURN EACH BOLT ¼ TURN COUNTER CLOCKWISE AND IT WILL DISENGAGE.
- REMOVE THE 2 LARGE 2 OUGHT RED CABLES FROM THE BATTERIES (SEE PHOTO BELOW) FOR 5 MINUTES.



- THE NET LED LIGHT ON THE DCM3 SHOULD NOW BE OFF. AFTER 5 MINUTES HAS ELAPSED, RE-ATTACH CABLES AND TIGHTEN DOWN TO 100 FT LBS WITH A TORQUE WRENCH. CHECK STATUS LIGHT ON DCM3 IS DISPLAYING SOLID GREEN LIGHT. FULLY CHARGE BATTERIES TO REGAIN % SYMBOL ON TOUCH SCREEN.

