

July 24, 2006

TO: All Georgie Boy Dealers

RE: Safety Recall 06V-267

Dear Georgie Boy Dealer:

This notice is sent to you in accordance with the requirements of the National Traffic and Motor Vehicle Safety Act.

Georgie Boy has decided that a defect that relates to motor vehicle safety exists in 2006 and 2007 Landau, Cruise Master and Pursuit motorhomes manufactured between January 21, 2006 and July 6, 2006.

On affected units, the cabinet containing the television in the center of the cockpit overhead may be inadequately secured. Should the television cabinet become unsecured during travel, the cabinet and television assembly may become detached from the cockpit overhead and fall down, potentially contacting the windshield, driver or front seat passenger resulting in either a crash or personal injury.

Owners of suspect units will be notified in a letter instructing them to contact their Georgie Boy dealer to schedule an appointment to have their unit repaired. A copy of this letter is attached for your reference.

Please find attached repair instructions and information relating to the preparation and submission of claims for reimbursement.

Thank you for your prompt attention to this matter. If you have any questions or require assistance, please contact your Regional Service Manager at 1-888-516-3569.

Sincerely,

GEORGIE BOY MANUFACTURING

Attachments



**The following is a field program procedure to ensure the fastening of the Front Television and TV Cabinet for Georgie Boy Pursuit, Landau and Cruise Master Motorhomes. Please follow each step carefully to ensure the proper attachment method will be obtained when you are complete.**

**Order part kit number 1097447 (Birch) or 1097448 (Cherry)**

**Your Field Program Parts box should contain:**

- Screw ¼-20 x 3” Self Tap Flat - (8 pc.) - #338648
- Screw, #8-1” Round Washer Quad – (2 pc.) - #374342
- Screw, #8-1 ¾” Round Washer Quad – (10 pc.) - #505746
- Screw, #8-3” Round Washer Quad – (6pc.) - #387757
- Wedge, 1”x 3” x 27” Lumber– (1pc.) - #1097254 (AI-18085/AI-18171)
- Button, Wood (Brazilian Cherry) – (4pc) - #944404
- Button, Wood (Welbeck Birch) – (4pc.) - #969649
- Bracket, CRN Zinc Round (2pc) - #949466

**STEP 1:** Remove the existing Wood buttons and screws from each corner of the TV Trim Ring. The buttons should be easily removed by prying them off with a flat edge paint scraper or similar tool. Be cautious to not scratch the surface of the TV Trim Ring, as a replacement has NOT been provided with this program.



**STEP 2:** Remove the TV Wedge located between the top of the TV and the bottom side of the TV Box. Be CAUTIOUS that the TV doesn't slide from the cabinet, as this wedge is the primary force maintaining its securement.



**STEP 3:** To remove TV, disconnect Power Cord, AV Jacks and Cable Wires. Be CAUTIOUS!!! TV is VERY HEAVY. This may require two people due to the size and weight of the TV. Ensure that wires are out of way by securing them to the rear of the TV box.



**STEP 4:** Install #8-1 3/4 Rnd Wash Quad screws (10ea) into upper front edge and rear edge of OSB panel (3/4" inward from front and rear edge of OSB).



**STEP 5:** Pre-drill TV Box frame with 3/16" drill bit and install 1/4 -20 x 3" Self Tap Flat screws (6ea) equally spaced into upper front Aluminum tube.



**STEP 6:** Pre-drill TV Box frame and install ¼ - 20 x 3” Self Tap Flat screws (2ea) into Lower Rear Aluminum tube of the TV Box. These fasteners will be secured to the overhead cowl board, try to stay in the top 1/3 of the tube.



**STEP 7:** Ensure the side fasteners have been installed. If not, install #8- 1 ¾” Round Washer Quad screws (4 per side). You must measure the dimension from the bottom of the outside of the TV Box up to the bottom of the attached side/front cabinet and add 1”. This will locate the fasteners into the bottom of the side/front shelf.



**STEP 8:** Re-Install TV into overhead TV Box and reconnect required power cable and AV Jacks. Install Upper TV Wedge and secure with (4) #8-3” Round Washer Quad Screws ensuring that the screw are angled into the ceiling for proper retention.



**STEP 9:** Install Bottom Bracket, CRN Zinc Round (2pc) with #8 -3/4” Round Washer Quad Screws.



**STEP 10:** Re-Install TV Trim Ring and Buttons.



By following these steps you will be able to successfully complete this field program. If you have further questions, feel free to contact your Regional Service Manager at 1-888-516-3569.