

PROCEDURE - T660 Hood Strut Lock Tube Retrofit (Recall 10KWE)

1. Park the vehicle on a level surface, turn off the engine and engage the parking brake.
2. Open the hood and locate the hood safety latch on the chassis' right side.



3. Unbolt frame attachment of strut while holding hood at balance point.



4. Remove bolt and nut from frame-side ball joint on strut.
5. Remove roll pins (use vice grips or channel locks).



6. Slide the lock tube off of the strut.

7. Clamp the rod to lock it in place. Protect rod surface from damage.



8. Remove the Rod End fitting and Pivot Disk.

9. Install the new Pivot Disk with threaded holes and apply Loctite to threads.



10. Reinstall Rod End.



11. Reinstall lock tube with the (2) Socket Head Cap Screws supplied in the retrofit kit (torque to 7-11 lb-ft).

12. Reinstall strut onto truck.

