

## Webasto Safety Recall VIN Results for 30001391

CustomerID-Branch	MODEL YEAR / MAKE / MODEL	Total Quantity	H700/600 Installations	TVS900 Installations	Unidentified Installations
30001391	1990 / BUICK / LESABRE Count	1	1	0	0
30001391	1994 / CADILLAC / DEVILLE Count	1	1	0	0
30001391	1994 / CADILLAC / SDV Count	1	1	0	0
30001391	1994 / MERCURY / GRAND MARQUIS Count	1	1	0	0
30001391	1996 / CHEVROLET / TAHOE Count	1	1	0	0
30001391	1997 / CADILLAC / DEVILLE Count	3	3	0	0
30001391	1997 / CADILLAC / SEVILLE Count	1	1	0	0
30001391	1997 / DODGE / INTREPID Count	1	1	0	0
30001391	1998 / CADILLAC / DEVILLE Count	2	2	0	0
30001391	1998 / CHEVROLET / BLAZER Count	1	1	0	0
30001391	1998 / NISSAN / ALTIMA Count	1	1	0	0
30001391	1999 / LINCOLN / NAVIGATOR Count	1	1	0	0
30001391	1999 / LINCOLN / TOWNCAR Count	3	3	0	0
30001391	1999 / MERCURY / SABLE Count	1	1	0	0
30001391	2000 / CADILLAC / DEVILLE Count	4	4	0	0
30001391	2000 / DODGE / CARAVAN Count	1	1	0	0
30001391	2000 / HONDA / ACCORD Count	1	1	0	0
30001391	2000 / LINCOLN / LS Count	1	1	0	0
30001391	2000 / LINCOLN / TOWNCAR Count	1	1	0	0
30001391	2000 / MERCURY / SABLE Count	1	1	0	0
30001391	2001 / CADILLAC / DEVILLE Count	2	1	0	1
30001391	2001 / CADILLAC / ELDORADO Count	2	1	0	1
30001391	2001 / CADILLAC / SEVILLE Count	1	1	0	0
30001391	2001 / CHEVROLET / TRAIL BLAZER Count	1	1	0	0
30001391	2001 / LINCOLN / LS Count	1	1	0	0
30001391	2001 / LINCOLN / TOWNCAR Count	1	1	0	0
30001391	2002 / CADILLAC / DEVILLE Count	9	9	0	0
30001391	2002 / CADILLAC / ELDORADO Count	1	1	0	0
30001391	2002 / CHEVROLET / AVALANCHE Count	1	1	0	0
30001391	2002 / CHRYSLER / PT CRUISER Count	1	1	0	0
30001391	2002 / FORD / CROWN VICTORIA Count	1	1	0	0
30001391	2002 / FORD / ESCAPE Count	3	3	0	0
30001391	2002 / FORD / EXPEDITION Count	2	2	0	0
30001391	2002 / FORD / EXPLORER Count	2	2	0	0
30001391	2002 / LINCOLN / LS Count	1	1	0	0
30001391	2002 / LINCOLN / TOWNCAR Count	4	4	0	0
30001391	2002 / MERCURY / MOUNTAINEER Count	1	1	0	0
30001391	2002 / NISSAN / ALTIMA Count	1	1	0	0
30001391	2002 / TOYOTA / CAMRY SOLARA Count	1	1	0	0
30001391	2003 / CADILLAC / CTS Count	2	2	0	0
30001391	2003 / CADILLAC / DEVILLE Count	4	4	0	0
30001391	2003 / CADILLAC / ELDORADO Count	1	1	0	0
30001391	2003 / CHEVROLET / BLAZER Count	1	1	0	0
30001391	2003 / FORD / ESCAPE Count	1	1	0	0
30001391	2003 / FORD / EXPLORER Count	5	5	0	0
30001391	2003 / JEEP / LIBERTY Count	1	1	0	0
30001391	2003 / LINCOLN / AVIATOR Count	1	1	0	0
30001391	2003 / LINCOLN / LS Count	4	4	0	0
30001391	2003 / LINCOLN / NAVIGATOR Count	2	2	0	0
30001391	2003 / LINCOLN / TOWNCAR Count	4	4	0	0
30001391	2003 / MERCURY / GRAND MARQUIS Count	7	7	0	0
30001391	2003 / MERCURY / MOUNTAINEER Count	1	1	0	0
30001391	2003 / NISSAN / ALTIMA Count	3	3	0	0
30001391	2003 / NISSAN / MAXIMA Count	1	1	0	0

**Webasto Safety Recall VIN Results for 30001391**

CustomerID-Branch	MODEL YEAR / MAKE / MODEL	Total Quantity	H700/600 Installations	TVS900 Installations	Unidentified Installations
30001391	2003 / NISSAN / SENTRA Count	1	1	0	0
30001391	2003 / PONTIAC / AZTEK Count	1	1	0	0
30001391	2003 / TOYOTA / CAMRY Count	4	4	0	0
30001391	2003 / TOYOTA / CAMRY SOLARA Count	1	1	0	0
30001391	2003 / TOYOTA / RAV4 Count	2	2	0	0
30001391	2004 / BMW / x3 Count	1	1	0	0
30001391	2004 / CADILLAC / DEVILLE Count	1	1	0	0
30001391	2004 / CADILLAC / DTS Count	1	1	0	0
30001391	2004 / CADILLAC / ESCALADE Count	1	1	0	0
30001391	2004 / CHRYSLER / LTC Count	1	1	0	0
30001391	2004 / CHRYSLER / PACIFICA Count	1	1	0	0
30001391	2004 / FORD / F150 Count	4	4	0	0
30001391	2004 / FORD / MUSTANG Count	1	1	0	0
30001391	2004 / GMC / SIERRA Count	1	1	0	0
30001391	2004 / LINCOLN / AVIATOR Count	2	2	0	0
30001391	2004 / LINCOLN / LS Count	2	2	0	0
30001391	2004 / LINCOLN / NAVIGATOR Count	1	1	0	0
30001391	2004 / LINCOLN / TOWNCAR Count	8	8	0	0
30001391	2004 / MERCURY / GRAND MARQUIS Count	1	1	0	0
30001391	2004 / NISSAN / QUEST Count	1	1	0	0
30001391	2004 / NISSAN / SENTRA Count	1	1	0	0
30001391	2004 / TOYOTA / 4RUNNER Count	1	1	0	0
30001391	2005 / CADILLAC / CTS Count	2	2	0	0
30001391	2005 / CADILLAC / STS Count	1	1	0	0
30001391	2005 / CHEVROLET / COBALT Count	1	1	0	0
30001391	2005 / CHEVROLET / SUBURBAN Count	1	1	0	0
30001391	2005 / CHEVROLET / TAHOE Count	1	1	0	0
30001391	2005 / CHRYSLER / 300 Count	6	6	0	0
30001391	2005 / FORD / 500 Count	1	1	0	0
30001391	2005 / FORD / ESCAPE Count	1	0	0	1
30001391	2005 / FORD / EXPLORER Count	1	1	0	0
30001391	2005 / FORD / TAURUS Count	1	1	0	0
30001391	2005 / GMC / YUKON XL Count	1	1	0	0
30001391	2005 / LINCOLN / TOWNCAR Count	4	3	0	1
30001391	2005 / MERCURY / MONTEGO Count	1	1	0	0
30001391	2005 / NISSAN / ALTIMA Count	3	3	0	0
30001391	2006 / CADILLAC / DTS Count	2	2	0	0
30001391	2006 / CADILLAC / SRX Count	1	1	0	0
30001391	2006 / CHRYSLER / 300 Count	1	1	0	0
30001391	2006 / CHRYSLER / PACIFICA Count	1	1	0	0
30001391	2006 / DODGE / DURANGO Count	1	1	0	0
30001391	2006 / FORD / EXPLORER Count	2	2	0	0
30001391	2006 / FORD / FREESTYLE Count	1	1	0	0
30001391	2006 / GMC / ENVOY Count	1	1	0	0
30001391	2006 / GMC / SIERRA Count	2	2	0	0
30001391	2006 / HYUNDAI / SONATA Count	1	1	0	0
30001391	2006 / LINCOLN / MARK LT Count	1	1	0	0
30001391	2006 / LINCOLN / TOWN CAR Count	1	1	0	0
30001391	2006 / LINCOLN / TOWNCAR Count	5	5	0	0
30001391	2006 / LINCOLN / ZEPHYR Count	1	1	0	0
30001391	2006 / MERCURY / GRAND MARQUIS Count	1	1	0	0
30001391	2006 / MERCURY / MOUNTAINEER Count	1	1	0	0
30001391	2006 / NISSAN / FRONTIER Count	1	1	0	0
30001391	2007 / BUICK / RENDEZVOUS Count	1	1	0	0

## Webasto Safety Recall VIN Results for 30001391

CustomerID-Branch	MODEL YEAR / MAKE / MODEL	Total Quantity	H700/600 Installations	TVS900 Installations	Unidentified Installations
30001391	2007 / CADILLAC / CTS Count	2	2	0	0
30001391	2007 / CADILLAC / DTS Count	2	2	0	0
30001391	2007 / CADILLAC / ESCALADE Count	1	1	0	0
30001391	2007 / CHRYSLER / 300 Count	1	1	0	0
30001391	2007 / CHRYSLER / SEBRING Count	1	1	0	0
30001391	2007 / DODGE / CHARGER Count	1	1	0	0
30001391	2007 / DODGE / NITRO Count	1	1	0	0
30001391	2007 / FORD / EXPLORER Count	1	1	0	0
30001391	2007 / FORD / FUSION Count	1	1	0	0
30001391	2007 / HYUNDAI / ENTOURAGE Count	1	1	0	0
30001391	2007 / HYUNDAI / SANTA FE Count	1	1	0	0
30001391	2007 / HYUNDAI / TUCSON Count	1	1	0	0
30001391	2007 / LINCOLN / MKX Count	2	2	0	0
30001391	2007 / LINCOLN / NAVIGATOR Count	1	1	0	0
30001391	2007 / LINCOLN / TOWNCAR Count	3	3	0	0
30001391	2007 / MERCURY / MILAN Count	1	1	0	0
30001391	2007 / MERCURY / MOUNTAINEER Count	1	1	0	0
30001391	2007 / MITSUBISHI / ECLIPSE Count	1	0	0	1
30001391	2007 / NISSAN / ALTIMA Count	1	1	0	0
30001391	2007 / NISSAN / SENTRA Count	1	1	0	0
30001391	2007 / PONTIAC / GRANDPRIX Count	1	1	0	0
30001391	2007 / TOYOTA / CAMRY Count	1	1	0	0
30001391	2008 / CADILLAC / CTS Count	4	4	0	0
30001391	2008 / CADILLAC / DTS Count	2	2	0	0
30001391	2008 / CHEVROLET / SILVERADO Count	1	1	0	0
30001391	2008 / CHRYSLER / SEBRING Count	1	1	0	0
30001391	2008 / DODGE / AVENGER Count	1	1	0	0
30001391	2008 / FORD / EDGE Count	1	1	0	0
30001391	2008 / FORD / F350 Count	1	1	0	0
30001391	2008 / GMC / YUKON Count	1	1	0	0
30001391	2008 / HYUNDAI / ELANTRA Count	1	1	0	0
30001391	2008 / HYUNDAI / SANTA FE Count	1	1	0	0
30001391	2008 / HYUNDAI / VERACRUZ Count	1	1	0	0
30001391	2008 / LINCOLN / MKX Count	1	1	0	0
30001391	2008 / LINCOLN / TOWN CAR Count	1	1	0	0
30001391	2008 / LINCOLN / TOWNCAR Count	2	2	0	0
30001391	2008 / MAZDA / TRIBUTE Count	1	1	0	0
30001391	2008 / MERCURY / MILAN Count	1	1	0	0
30001391	2008 / MERCURY / MOUNTAINEER Count	1	0	0	1
30001391	2008 / RAM / RAM Count	2	2	0	0
30001391	2008 / TOYOTA / TACOMA Count	1	1	0	0
30001391	2008 / TOYOTA / TUNDRA Count	1	1	0	0
30001391	2009 / CADILLAC / CTS Count	1	1	0	0
30001391	2009 / CHEVROLET / SILVERADO Count	1	1	0	0
30001391	2009 / GMC / ACADIA Count	1	1	0	0
30001391	2009 / HYUNDAI / SANTA FE Count	1	1	0	0
30001391	2009 / HYUNDAI / SONATA Count	2	2	0	0
30001391	2009 / KIA / SORENTO Count	1	1	0	0
30001391	2009 / KIA / SPECTRA Count	1	1	0	0
30001391	2009 / PONTIAC / G6 Count	1	1	0	0
30001391	2009 / PONTIAC / VIBE Count	1	1	0	0
30001391	2009 / TOYOTA / CAMRY Count	1	1	0	0
30001391	2009 / TOYOTA / COROLLA Count	1	1	0	0
30001391	2009 / TOYOTA / HIGHLANDER Count	1	1	0	0

**Webasto Safety Recall VIN Results for 30001391**

CustomerID-Branch	MODEL YEAR / MAKE / MODEL	Total Quantity	H700/600 Installations	TVS900 Installations	Unidentified Installations
30001391	2009 / TOYOTA / TACOMA Count	1	1	0	0
30001391	2009 / VOLKSWAGEN / TIGUAN Count	1	1	0	0
30001391	2010 / CHEVROLET / EQUINOX Count	1	1	0	0
30001391	2010 / CHEVROLET / TAHOE Count	1	1	0	0
30001391	2010 / TOYOTA / HIGHLANDER Count	1	1	0	0
	<b>Grand Count</b>	<b>261</b>	<b>255</b>	<b>0</b>	<b>6</b>

2010 Toyota Scion	1
2010 GMC Terrain	1
2010 KIA Sonata	1
2010 Chrysler 300	1
2010 Ford Fusion	1
2010 Toyota Tundra	1
	<b>267</b>