

PROCEDURE

1. Raise the vehicle.
2. Remove the cotter pin from the bolt on the drag link. Reserve the cotter pin. See Figure 1
3. Torque the nuts at 133 ± 15 Lb ft (180 ± 20 N•m). See Figure 1.



Figure 1 - Steering drag link



WARNING:

After the application of the torque on the drag link nuts, position the nuts in such a way that the cotter pin holes are free. If necessary, rethigten the nuts to correctly position them and take care to torque within the torque limitation.

4. Install the retained cotter pin reserved on the drag link.
5. Lower the vehicle
6. Fill out the Campaign work table at the end of this document and return to your Nova Bus after-sales service representative.

REVISIONS

R1 : Client list modified in the French version only.

ISSUED BY:	LUC CARIGNAN	DATE:	2011MR01	PAGE 3 OF 4
APPROVED BY:				

