

NHTSA #: 11V-440 TC #: 2011-323 Job Code: 9901096
Flat Rate: 0.25

PARTS MUST BE ORDERED FROM STARCRAFT FOR EVERY RETAIL-SOLD UNIT. DEALER-STOCK UNITS WILL HAVE PARTS AUTOMATICALLY SENT TO THE DEALER.

ACTION REQUIRED: Add a bracket to the spare tire carrier

MODELS / UNITS:

2011 Autumn Ridge AR-ONE Travel Trailers

14RB - B28U5298-5423, 5425
15RB - B28W5208-5253, 5264-5387
16BH - B28V5202-5315

2012 Autumn Ridge AR-ONE Travel Trailers

14RB - C28U5051-5144, 5146-5176
15RB - C28W5051-5202, 5204-5207, 5209-5230, 5233-5239, 5241-5251
16BH - C28V5051-5073, 5075-5134, 5137-5140, 5143-5145, 5147-5149, 5151-5158, 5160-5165, 5167-5168
18FB - C28S5051-5072, 5074-5076, 5078-5080, 5082-5089, 5091-5093, 5096-5100, 5102, 5104-5107, 5109-5110

2012 Autumn Ridge Travel Trailers

197FBH - C28P5051-5063
235FB - C28E5051-5074
245DS - C28L5051-5068
256BHS - C28K5051-5068
278BH - C28B5051-5117
297BHS - C28D5051-5062
309BHL - C28M5052-5057
31RLSZ - C28H5052-5056, 5064-5067, 5069-5075
329BHU - C28G5051-5068
36RESA - C28T5051-5063, 5065-5075

KIT CONTENTS

11V-440S

Note: Kit can only be ordered using the order form included with this bulletin.

(1) bracket
(3) self tapping screws
Instruction sheet

TOOLS/MATERIAL REQ.:

Screw gun with square head bit
socket wrench

INSTRUCTIONS

1. Remove the spare tire from the carrier.
2. Place the bracket on the tire carrier and insert the bolts through the bracket and carrier (**Fig. 2a**). Mount the spare tire back on the carrier.
3. Install the (3) self tapping screws into the bracket using the pre-drilled holes. Make sure the bracket is securely (**Fig. 3a**) attached to the carrier tube.

