

"DOCUMENT UNCONTROLLED IF PRINTED"

DOC #	PROCESS NAME	PAGE	REVISION	STATION	BY	DATE
	Weatherizing Unused Electrical Connections	1 OF 1		SER	DBaker	12/17/2014

Read process before beginning. If you do not understand any part please contact: Chris Ward, Director of Parts and Warranty at 1-866-953-5555 or by E-mail @ cward@ARBOCSV.com.

Good Mechanics safety practice must be followed on any repairs.

Safety practices should include but not be limited to properly supporting the chassis, axles, blocking tires, and a work area free of clutter.

Repair shops safety rules must be followed and safety equipment used. O.E.M. Battery and Auxiliary Battery MUST be disconnected.

This Recall notice applies to all 2015 product built from July 1, 2014 to December 12, 2014.

Labor Operation Code: RCO56301 .

Labor Time Allowance: .4 hours.

Tools Required

- 1- Heat gun
- 2- Screw gun (depending on bus)

Parts List

- 1- (2) 4" pieces Heat shrink, 1/4"x4' 3M EPS 300 polyolefin adhesive lined
(purchase locally)

Repair Instructions:

Step 1- Remove bottom light.



Step 2- Locate the unused side marker light connection.



Step 3- Add a 2" piece of shrink wrap over the ends and shrink with heat gun.



Step 4- Reinstall the light and repeat with other side.

