

Inspection procedures:

This inspection procedure is only required on Hutchens part numbers 27020-01 and 27301-01 installed under the Fontaine Revolution flatbed trailers.

1. Locate the Z-rail slider(s) under the trailer. Depending on the trailer configuration this could be located at the front and rear trailer axle or the rear axle only.
2. Clean and visually inspect air ride hanger to hanger mounting plate attachment welds and the hanger corssmember attachment welds shown below. Inspection in these areas will be performed on both the Road side and Curb side.

