Vor	\Box	′olvo C	ar Customer Service	TJ :	31955
Title		Climate ur	it drain hose	Page	1 (11)
Action		Inspection		Operation number:	98635-2
Issue	Date		Reason		
1	l 2016-09		First issue		

Affected vehicles

Model year	Model
2017	S90 (17-)
2016, 2017	XC90 (16-)

Equipment

Designation	Part No.
Interior trim remover	

Orientation view



Color symbols



Note! This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.

- 1. Used for focused component, the component with which you will do something.
- 2. Used as extra colors when you need to show or differentiate additional parts.
- 3 . Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
- 4 . Used when the component is not fully removed from the vehicle but only hung to the side.
- 5 . Used for standard tools and special tools.
- 6 . Used as background color for vehicle components.

Applies to the passenger side

Removal



Remove the part carefully Remove the panel.



Remove passenger side sill moulding front,
refer to:
Removal, replacement and installation
8 - Body and interior
84 - Exterior trim, glass, weatherstrips
845 - sealing and protect. molding for
door, lid, and side window





Caution! Make sure that the component is positioned correctly.

Fold the carpet to the side. Remove the part carefully Remove the marked part.

Check







Caution! The grommet seal must rest on the metal surface, not on the carpet.

Note! Make sure that the seal is correctly located.



The graphic is just to show the back of the component and the location of the tabs. The component does not need to be removed if it is already correctly installed.



Check that the rubber grommet is not loose: 1 -First grab the hose connection and press inwards. 2 -Then pull outwards. 3 -Again push inwards.

If no faults are detected, to install, reverse the removal procedure.

If the result of the checking procedure is not OK, the component must be replaced with a new component.



Applies to the driver's side



■ 2-2-3-3-8-CR R0R

Remove driver side front sill trim panel, refer
to:
Removal, replacement and installation
8 - Body and interior
84 - Exterior trim, glass, weatherstrips
845 - sealing and protect. molding for
door, lid, and side window



Remove accelerator pedal, refer to: Removal, replacement and installation 2 - Engine with mountings and equipment 27 - Engine control 271 - gas pedal control





Caution! Make sure that the component is positioned correctly.

Fold the carpet to the side. Remove the part carefully Remove the marked part.

Check







Caution! The grommet seal must rest on the metal surface, not on the carpet.

Note! Make sure that the seal is correctly located.

The graphic is just to show the back of the component and the location of the tabs. The component does not need to be removed if it is already correctly installed.





Check that the rubber grommet is not loose: 1 -First grab the hose connection and press inwards. 2 -Then pull outwards. 3 -Again push inwards.

If no faults are detected, to install, reverse the removal procedure.

Page 11 (11)

If the result of the checking procedure is not OK, the component must be replaced with a new component.

