



# Recall Campaign

NHTSA # 16V-568

TC # 2016-386

draft

Job Code: 9903318

Flat Rate: .3 hr

## PARTS KIT REQUIRED

### Action Required

Replace pvc shower curtain

### Affected Units

2013-2017 Redhawk Class C motor homes

Year	Model	Part #	Parts Kit #
2013	D1	XK0050-0100	16V568A
		XL0051-0192	16V568B
		XS0051-0144	16V568A
2014	E1	XK0051-0137	16V568A
		XL0051-0163	16V568B
		XM0051-0094	16V568B
		XS0051-0122	16V568A
2015	F1	X10051-0055	16V568A
		X20051-0055	16V568B
		XD0050-0209	16V568A
		XK0051-0222	16V568A
		XL0051-0237	16V568B
		XM0051-0160	16V568B
		XS0051-0072	16V568A
2016	G1	X10051-0089	16V568A
		X20051-0063	16V568B
		XD0051-0307	16V568A
2016		XK0051-0338	16V568A
		XL0051-0318	16V568B
		XM0051-0158	16V568B
2017	H1	X10051-0081	16V568A
		X20051-0061	16V568B
		XD0051-0136	16V568A
		XK0051-0149	16V568C
		XL0051-0156	16V568B
	XM0051-0085	16V568B	

### Parts Kit 16V568 A B C

- 1 Shower Curtain
- 8 Quarter turn fasteners

### Repair Instructions

Please refer to instructions provided by manufacture of shower curtain Shower Enclosures of America, Inc.



# CURTAIN REPLACEMENT INSTRUCTIONS

## IDENTIFY "FASTENERS"



Identify 4ea. 'quarter-turn' fasteners on the top  
Identify 4ea. 'quarter-turn' fasteners on the bottom

## STEP 1



Rotate each fastener 1/4 turn to the left  
to disengage curtain from 'guide clips' in the track

## STEP 2



Remove the curtain by easily sliding 'upward'

## IDENTIFY "CURTAIN BOTTOM"



The 'bottom' of the curtain contains a 2" sewn stiffener to the 'INSIDE' of the curtain

## STEP 3



- Slide new curtain into the channels; left and right (starting with the 'bottom'- as shown)
- Replace the 8ea. 'quarter-turn' fasteners (included if needed)