

U24 CB/FX

200mm

141-0149 screws

Pre-drill holes in plastic backing with a 7/64" drill bit and seal screws with silicone

- turn off water pressure.
- unscrew faucet head
- mark guide ring screw hole locations
- drill one 7/64" hole for each screw
- Put one dab of SCS 1000 silicone in each hole
- fasten each ring to the shower wall with a #6 Robertson screw driver
- unscrew shower head
- feed hose through each guide ring as shown
- reinstall shower head.

