

Recall 17V-271/TC 2017-225

Retention Clip Installation Instructions

Step 1: Run the slide in halfway so you can access the column and the wall to install the retention clip

Step 2: You must remove the plastic guard, which is located on the side of the slide out closest to the door. Note: Not all models utilize this guard.

-Remove the screws that are used to secure the plastic guard (Generally 4-5 Screws are used during install)

Step 3: Locate the stainless rivet at the top and measure 6" down to install the first retention clip. Must be 6" below to avoid damaging the Schwintek motor

-Once you have the correct measurement screw in the self-tapping screw into the column.

-After the column screw is secured install the #10 x 1 screw into the wall.

Step 4: Locate the stainless rivet at the bottom and measure 6" up to install the second retention clip. Must be 6" above to avoid damaging the Schwintek motor

-Once you have the correct measurement screw in the self-tapping screw into the column.

-After the column screw is secured install the #10 x 1 screw into the wall.

(Repeat Steps 3 and 4 for installation of opposite side of the slide out)

Step 5: Install the plastic guard that was taken off in **Step 2** (if applicable) with the same screws and using the same screw holes.

Step 6: Run the slide in and out to make sure that everything is in proper working order after the installation

#8 1" self-tapping screw

Self-tapping screw goes into this hole which is screwed into the column



Coarse non self-tapping screw goes into this hole



**Plastic guard must
be removed
before installing
the Z clips**

**(If the plastic
guard is present
on model)**





**Take the screws out
of the plastic
guard before removing
it.**

A close-up photograph showing a hand holding a long, black, textured metal Z-clip against a light-colored wooden panel. To the right, a black metal frame is visible, with a white rectangular component (possibly a light fixture or vent) attached to it. The Z-clip is being positioned to be installed into the frame. The background is a wooden surface.

Once the guard is removed the Z clips can be installed.

6" below
the rivet



6" above
the rivet
during
install of
bottom
z clip



**Screw must be 6"
above the rivet
when installing**

6"

