

2018-06

Sportsmen 333BH \bar{K} LP Recall

1. Put pinch gimp around 3 sides of the 11 1/2" x 13" L bracket that do not have a bend.
2. Place L bracket at a 45 degree angle starting at the top corner behind the rear slide out arm (making sure the L bracket is underneath the LP lines) and put 3 – self-tapping lags through the pre drilled holes into the frame.
3. Put a washer and self-tapping lag one end of the spring and screw it to the frame just in front of the outrigger behind the slide out.
4. Place a zip tie around the unused end of the spring and the LP lines just below where they go into the floor.
5. Run the slide out in and out making sure the LP lines lay on top of the L bracket when in the in position

Parts: 4 lags (146307) 1 washer (800074) 1 Zip tie (123357) 2' pinch gimp (140906) 1 11 1/2" x 13" L bracket (800112) 1 spring (150995)

