

18V-681

Sonic 190VRB Gas Manifold Instructions

1. Locate the Manifold above the off door side axle. Remove the self-tapping lags holding the P clamps for the gas line and the manifold.
2. Move the manifold up and relag it to the lip of the frame, make any necessary adjustments to get the gas lines up with the manifold and relag the P clamps.

