

SAFETY ADVISORY

MORryde Rubber Pin Box

It has been determined that vehicles in this recall population may have pin box mounting hardware that was insufficiently tightened. This could lead to an increased risk of personal injury. In order to prevent injury or damage to the vehicle, the mounting hardware must be properly torqued.

Models Included:

2019 Forest River Columbus

Serial Number Ranges:

2019 Forest River

Tools Required: 15/16" deep well socket
Torque wrench capable of 135ft-lbs
15/16" wrench
Paint marker

Allotted Time: 0.5 hour

Instructions:

Step 1: Disconnect truck from trailer.

Step 2:

Set the torque wrench to 135ft-lbs, use the 15/16" deep well socket and torque all 10 bolts that mount the pin box to the trailer frame. Keep the nuts from moving by using a 15/16" wrench.



Step 3:

Use a paint marker and torque mark all bolts.

