

Recall Inspection and Repair Instructions

NHTSA Recall #: 21V-610

Tiffin Motorhomes Recall #: WAY-101

Models Involved: 2017, 2018, 2019, 2020, 2021 & 2022 Wayfarer Motorhomes, all floorplans.

Tools Needed:

¾" OR 19MM BOX END WRENCH
¾" OR 19MM DEEP WELL SOCKET
RATCHET
PNEUMATIC OR ELECTRIC IMPACT GUN
HAMMER/MALLET
PRY BAR
FLOOR JACK
JACK STANDS
HYDRAULIC LIFT IF AVAILABLE

Parts Needed:

24FW, 24QW, 24TW, 25QW, 25RW, 25SW, 25TW floorplans require the following parts:
2 of 5125064, liner gussets
1 of 5125485, gusseted hitch
8, 2" grade 8 hex bolts and nuts

FLAT RATE CODES AND TIMES

When filing the warranty claim for payment please use the following flat rate codes and times.

For 24FW, 24QW, 24TW, 25QW, 25RW, 25SW, 25TW floorplans, use code **WF8803RC01**, for 1.00 hour

For units with damage to existing frame rail extensions please contact Winfield Service for authorization numbers and time allowed.

Inspection Instructions/Procedure:

1. Inspect the condition of the existing frame rail extensions for signs of damage. If there is damage, please contact Wayfarer at 205-487-4710 for instructions and authorization.
2. If no damage is found, please proceed with the repair.

Repair Instructions/Procedure:

1. Remove the receiver hitch by removing the (6) grade 8 hex bolts (3 per side) from the unit's receiver hitch using a $\frac{3}{4}$ " or 19 MM socket and box end wrench. Lower the receiver hitch from chassis using a floor jack.



2. On some units, placement of the water tank pan favors one side of the unit. Loosening the tank pan bolts (8) $\frac{3}{8}$ " hex bolts will allow you to shift the tank and pan slightly aiding in installation of the gusset liners.



3. Install the gusseted extension liners part # 5125064. Start by feeding the liner gusset inside the gap between the chassis extension and tank pan. Once started, use a mallet or sledge hammer to aid in installing the liner. Using a 2" Grade 8 hex bolt, attach the truss to the liner and extension by feeding the bolt in from the top side and tighten the bolts to 75 ft. lbs. once installed.



4. Once the liners are installed, lift the new hitch, part # 5125065, into place and fasten the hitch to frame rail extensions using (6) 2" grade 8 hex bolts. Feed bolts from top to bottom of rail and tighten to 85 ft. lbs.

