


RECALL 23V638 / 2023-513 REMEDY INSTRUCTIONS

	Make(s): HARDSIDE, SOFTSIDE & REAL-LITE Model(s): MANY, SEE BELOW Model Year(s): 2024	Repair Code: RC-003-09-00-004409 Allotted Time: .25 HRS. Inspection Code: N/A Allotted Time: N/A
	Concern: The incoming charge line from the vehicle may not have a battery management system ("BMS") prior to being connected to the lithium battery.	Photo(s) Required: YES, POST REMEDY Prior Authorization Required: YES Part(s) Kit Number: N/A Part(s) Return: N/A

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

CERTAIN 2024 HARDSIDE: HRHS-690, HRHS-750, HRHS-8801, HRHS-2901, HRHS-2910 & HRHS-2912
 CERTAIN 2024 SOFTSIDE: SZSS-500, SZSS-550, SZSS-1240 & SZSS-1251
 CERTAIN 2024 REAL-LITE: RCSS-1600, RCSS-1604, RCHS-1805, RCSS-1609

STEP 1: ACCESS THE 7-WAY BARGMEN PLUG WIRING;

- THIS WILL BE LOCATED ON THE DRIVERS SIDE FRONT WALL ON ALL TRUCK CAMPER MODELS;
- ACCESS WILL NEED TO BE GAINED THROUGH USE OF REMOVING AN ACCESS PANEL(S)/DOOR/FALSE PANEL;

STEP 2: LOCATE THE BLACK 7-WAY BARGMEN WIRE THAT IS CONNECTED TO A RED WIRE WITH A WAGO CONNECTOR

STEP 3: REMOVE THE WAGO CONNECTOR AND DISCARD;

- INSTALL AND CRIMP A BELL CAP ONTO THE RED WIRE
- INSTALL AND CRIMP A BELL CAP ONTO THE BLACK WIRE
- ENSURE BOTH BELL CAPS ARE INSTALLED SECURELY

STEP 4: CLEAN AREA(S);

STEP 5: REINSTALL THE ACCESS PANEL(S)/DOOR/FALSE PANEL – IF ANY REMOVED;

STEP 6: CLAIM REPAIR CODE.