

## RECALL 23V658 REMEDY INSTRUCTIONS



Make(s): SALEM & WILDWOOD  
Model(s): SBF378FL, WBF378FL & WBT310BHI  
Model Year(s): 2024

Concern:  
There may not a secondary means of egress installed in the vehicle as required.

Repair Code: RC-047-03-00-004417  
Allotted Time: 0.00 – P.A.R. FOR TIME  
Inspection Code: N/A  
Allotted Time: N/A  
Photo(s) Required: NO  
Prior Authorization Required: YES  
Part(s) Kit Number: SEE BELOW  
Part(s) Return: N/A

**Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.**

### **FOR MODELS SBF378FL & WBF378FL ORDER KIT NUMBERS:**

30I93094A - EXIT STICKER

F100218266 - EXIT RED HANDLE with SET SCREW

STEP 1: INSTALL EGRESS WINDOW KIT ON REAR WALL BEDROOM WINDOW. INSTALL EGRESS STICKER TO GLASS.

STEP 2: CLAIM REPAIR CODE.

### **FOR MODELS WBT310BHI ORDER KIT NUMBER:**

F100462355 – 29" x 48" EGRESS WINDOW (INCLUDES FOAM TAPE SEALANT)

STEP 1: CAREFULLY REMOVE WOODEN TRIM FROM AROUND WINDOW;

STEP 2: CUT OFF PIN NAILS ON THE BACK SIDE OF TRIM WITH SIDE CUTTERS, DO NOT PULL THROUGH;

- **PULLING THROUGH/EXCESSIVE DAMAGE TO TRIM MAY NOT COVERED UNDER THE SCOPE OF THIS RECALL!**

STEP 3: OUTSIDE OF THE VEHICLE, APPLY DUCT TAPE TO THE VEHICLE AND WINDOW;

- ABOUT 20" DOWN FROM THE TOP OF THE WINDOW, STARTING AT LEAST 12" HORIZONTALLY FROM THE LEFT OF THE WINDOW, CROSSING THE WINDOW AND 12" PAST THE WINDOW TO THE RIGHT SIDE;
- ABOUT 12" UP FROM THE BOTTOM OF THE WINDOW, STARTING AT LEAST 12" HORIZONTALLY FROM THE LEFT OF THE WINDOW, CROSSING THE WINDOW AND 12" PAST THE WINDOW TO THE RIGHT SIDE;

STEP 4: GO INSIDE AND CAREFULLY UNFASTEN THE RETAINING RING AND SET ASIDE FOR REUSE;

- SAVE THE SCREWS FOR REUSE;

STEP 5: GO BACK OUTSIDE AND PEEL THE TAPE AND CAREFULLY LOWER THE WINDOW AND DISCARD;

STEP 6: PREP THE 29" x 48" EGRESS WINDOW WITH THE FOAM TAPE AROUND THE FOUR FLAT EDGES THAT MATE AGAINST THE REAR WALL.

STEP 7: INSTALL THE 29" x 48" EGRESS WINDOW INTO THE OPENING AND SECURE USING THE SAME METHODS FROM STEP 3;

STEP 8: REINSTALL THE RETAINING RING USING THE SCREWS FROM THE OLD WINDOW;

STEP 9: REINSTALL THE TRIM WITH PIN NAILS;

STEP 10: CAP SEAL THE EXTERIOR SIDES AND TOP OF THE WINDOW;

STEP 11: CLEAN THE AREA INSIDE THE VEHICLE;

STEP 12: CLAIM THE REPAIR CODE.