

RECALL 24V137 / 2024-117 REMEDY INSTRUCTIONS



Make(s): IBEX & NOBO
Model(s): BXTRVS1, BXTRVS2 & NBTRVS1
Model Year(s): 2024

Concern:
The Cadet Heater(s) may have been installed to close to the ceiling, which may damage the ceiling panel(s).

Repair Code: RC-003-13-00-004509

Allotted Time: 3.00 HRS.

Inspection Code: N/A

Allotted Time: N/A

Photo(s) Required: YES, POST REMEDY

Prior Authorization Required: YES

Part(s) Kit Number: F100538905

Part(s) Return: N/A

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

BATHROOM CABINET REMEDY:

STEP 1: DISCONNECT POWER TO THE CADET HEATER;

STEP 2: REMOVE 14 ½" BY 45" CABINET DOOR;

STEP 3: REMOVE THE CADET HEATER;

STEP 4: REMOVE THE 4" X 10" STYLE;

STEP 5: LOOSEN THE SHELF BY TAKING OUT SCREWS ALONG THE FRONT WALL AND THE SIDEWALL;

- CONTINUE TO CUT OFF THE SHELF BY REMAINING 2 SIDES USE A BUZZ SAW OR OSCILLATING TOOL TO AIDE IN CUTTING THE STAPLES/FASTENERS;
- THE SHELF SHOULD NOW DROP TO THE NEXT SHELF WITHIN THE CABINET;

STEP 6: MOVE THE EXISTING 2" X 12" STYLE DOWN TO 22" FROM THE CEILING TO THE TOP SIDE OF THE STYLE AND REATTACH;

- IT MAY BE NECESSARY TO EXTEND THE 120V WIRING USING A JUNCTION BOX AND THE APPROPRIATE GAUGE WIRE;

STEP 7: SECURE THE PROVIDED FACE FRONT OVER THE TOP OF THE EXISTING FACE FRONT USING SCREWS COMING IN THROUGH THE BACK SIDE;

STEP 8: REINSTALL CADET HEATER IN THE NOW LOWER OPENING;

STEP 9: SLIDE SHELF UP AND RESECURE TO ALL SIDES;

STEP 10: REINSTALL THE NEW PROVIDED CAB DOOR 14 1/2" BY 37 1/2"

BEDROOM CABINET REMEDY:

STEP 1: DISCONNECT POWER TO CADET HEATER

STEP 2: REMOVE THE CADET HEATER ;

STEP 3: REMOVE THE 4" X 10" STYLE;

STEP 4: REMOVE BOTH RECEPTACLES AND USB IN THE MIDDLE OF THE CABINET;

- REMOVE THE PANEL THAT HAD THE RECEPTACLES AND USB

STEP 5: REATTACH THE NOW REMOVED RECEPTACLES USING PROVIDED BLANK RECEPTACLES;

STEP 6: SECURE BLANK RECEPTACLES BACK AND TOWARDS THE RIGHT SIDE IN THE OPENING;

STEP 7: EXTEND WIRE FROM CEILING TO THE MIDDLE OF THE CABINET USING PROVIDED BLANK RECEPTACLES AND WIRING;

STEP 8: ADD PROVIDED BACKING FOR THE SURFACE MOUNT BOX WITHIN THE OPENING;

STEP 9: ADD 1 3/8" STYLE TO THE RIGHT SIDE OF THE NEWLY MADE OPENING;

STEP 10: INSTALL THE SURFACE MOUNT CAN;

STEP 11: REINSTALL THE CADET HEATER;

STEP 12: INSTALL PROVIDED FACE FRAME ACCESS STYLE TO THE OLD HEATER LOCATION AT THE TOP OF THE FACE FRAME;

STEP 13: TEST FUNCTIONALITY OF CADET HEATERS;

STEP 14: CLAIM REPAIR CODE.