


## RECALL 25V230 / 2025-189 REMEDY INSTRUCTIONS

 <b>FOREST RIVER</b>	Make(s): CATALINA Model(s): BCAT154RBX Model Year(s): 2025	Repair Code: RC-632-09-00-004703 Allotted Time: 6.00 HRS. Inspection Code: N/A Allotted Time: N/A
	Concern: The waste water holding tank(s) ventilation pipe may not be terminated exterior of the vehicle.	Photo(s) Required: NO Prior Authorization Required: YES Part(s) Kit Number: F100731741 Part(s) Return: NO

**Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.**

PARTS KIT (F100731741):

ROOF VENT CAP & BASE

1 1/2" "T"

1 1/2" – 79" VENT PIPE

STEP 1: REMOVE SHOWER PAN, SHOWER BASE, AND LOOSEN THE SHOWER WALL;

STEP 2: LOCATE SHOWER DRAIN PIPE. USE 1 1/2" TEE TO MARK WHERE YOU NEED TO CUT;

STEP 3: INSTALL TEE WITH VENT PIPE HOLE FACING UP TOWARDS THE ROOF;

STEP 4: ON THE ROOF, USING A 2" HOLE SAW, DRILL A HOLE AT 37.5 FROM THE BACK OF THE UNIT TOWARDS THE FRONT;

STEP 5: 18" FROM THE SIDE OF THE UNIT (OFF DOOR SIDE);

STEP 6: INSERT 79" PIPE THROUGH THE HOLE, THEN GLUE TO THE TEE FROM THE INSIDE;

STEP 7: RE INSTALL WALL BATH PANEL, SHOWER WALL, AND TUB BASE WITH SHOWER DRAIN;

STEP 8: RE SEAL TUB SURROUND AS NECESSARY;

STEP 9: INSTALL ROOF VENT OVER THE VENT PIPE ON THE ROOF AND SEAL WITH WHITE ALPHA SEAL;

STEP 10: TEST FOR PROPER OPERATION;

STEP 11: CLAIM REPAIR CODE.