


RECALL 25V245 / 2025-203 REMEDY INSTRUCTIONS

 FOREST RIVER	Make(s): MANY, SEE BELOW Model(s): MANY, SEE BELOW Model Year(s): MANY, SEE BELOW	Repair Code: RC-037-09-00-004706 Allotted Time: .50 HRS. Inspection Code: RC-037-05-00-004705 Allotted Time: .10 HRS.
	Concern: The thimble which the steps latch to may not have thread lock.	Photo(s) Required: NO Prior Authorization Required: YES Part(s) Kit Number: SEE BELOW Part(s) Return: NO, FIELD DESTROY

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

CERTAIN: 2024 & 2025:

AURORA - AART18RD & ART28EPIC

CAMPSITE RESERVE - CRT16SW, CRT20JW, CRT39GB & CRT39JD

CASCADE - CST16MLC, CST20OGC, CST39DLC, CST39SRC & CST39TNC

CATALINA - ACAT18RDL, ACAT35FME & CAT283EPIC

CEDAR CREEK - CRT40CCK, CRT40CDL & CRT40CFD

CHEROKEE - CKT16ML, CKT16MLBL, CKT20OG, CKT20OGBL, CKT39AL, CKT39ALBL, CKT39DL, CKT39DLBL, CKT39HBA, CKT39HBABL, CKT39JM, CKT39JMBL, CKT39LB, CKT39NA, CKT39NABL, CKT39SR, CKT39SRBL & CKT39TN

IMPRESSION - MPF44STAY

PAUSE - PETRE17.4-AR & PETXC22.4

PUMA - PUT37PFL & PUT403LFT

SABRE - SRF36ML

SALEM - SBFROOST43

SANDPIPER - SAT399LOFT, SAT402FK, SAT403RD & SAT420FL

SIERRA - SET399LOFT, SET403RD & SET420FL

VENGEANCE - VGF341GS11, VGF351G2, VGF383G2, VGF391T145, VGF4007VG2, VGT26L140 & VGT32L132

WILDWOOD - WBFROOST43

INSPECTION:

STEP 1: INSPECT THE VEHICLE FOR DETACHABLE MORRYDE STEPS;

- IF THE VEHICLE DOES NOT HAVE DETACHABLE STEPS ANYWHERE ON THE VEHICLE, CLAIM THE INSPECTION CODE;
- IF THE VEHICLE DOES HAVE DETACHABLE STEPS ON THE VEHICLE, USE THE APPROPRIATE REMEDY ATTACHED;

REMEDY:

STEP 1: IDENTIFY WHICH VEHICLE BRAND NAME & MODEL AND LOCATE THE APPROPRIATE REMEDY STEPS ATTACHED;

- THE VARIOUS REMEDY DOCUMENTS ATTACHED ARE BY DOCUMENT/PART NUMBER;
- **PARTS KIT:** ORDER THE DOCUMENT/PART NUMBER FROM THE DIVISION FOR REPAIR;

REMEDY LISTINGS BY VEHICLE:

TOY HAULER RAMP DOOR & RAMP DOOR PATIO DETACHABLE STEPS:

USE DOCUMENT "CLIP ON BRACKET REPLACEMENT INSTRUCTIONS - STP56-015 - STP54-080" (ATTACHED)

- KIT NUMBER IS "STP54-080" FROM THE DIVISION – 1 PER DETACHABLE STEP

IMPRESSION: MPF44STAY:

USE DOCUMENT "CLIP ON BRACKET REPLACEMENT INSTRUCTIONS - STP57-641 - STP54-077 - 44STAY" (ATTACHED)

- KIT NUMBER IS "STP54-077" FROM THE DIVISION – 1 PER DETACHABLE STEP

SALEM & WILDWOOD: SBFROOST43 & WBFROOST43:

USE DOCUMENT "CLIP ON BRACKET REPLACEMENT INSTRUCTIONS - STP57-641 - STP54-077 - ROOST43" (ATTACHED)

- KIT NUMBER IS "STP54-077" FROM THE DIVISION – 1 PER DETACHABLE STEP

ALL OTHER MODELS - INCLUDING REAR PATIO DECK:

USE DOCUMENT "CLIP ON BRACKET REPLACEMENT INSTRUCTIONS - STP57-515 - STP54-078" (ATTACHED)

- KIT NUMBER IS "STP54-078" FROM THE DIVISION(S) – 1 PER DETACHABLE STEP