


RECALL 25V263 / 2025-218 REMEDY INSTRUCTIONS

	Make(s): BRAVADO Model(s): BRC33DSF Model Year(s): 2025	Repair Code: RC-041-09-00-004708 Allotted Time: 2.00 HRS. Inspection Code: N/A Allotted Time: N/A
	Concern: The dinette/sofa slideroom floor may detach from the slideroom walls.	Photo(s) Required: NO Prior Authorization Required: YES Part(s) Kit Number: F100736761 Part(s) Return: N/A

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

STEP 1: REMOVED BOTTOM RAIL FROM EXTERIOR OF LARGE SLIDE-OUT;

STEP 2: PRE-DRILL HOLES USING A 3/16" DRILL BIT FOR THE SELF-TAPPING SCREWS IN THE NEXT STEP.

- THE FIRST 3 SHOULD BE SPACED 2" APART TOWARD THE INSIDE OF THE ROOM;
- THE SECOND 3 SHOULD BE EVENLY SPACED FOR THE REMAINING AREA;

STEP 3: ADD 6 OF THE 5" SELF-TAPPING #14 SCREWS TO THE BOTTOM GOING UP PER SIDE OF THE SLIDE OUT;

- THE FIRST 3 SHOULD BE SPACED 2" APART TOWARD THE INSIDE OF THE ROOM;
- THE SECOND 3 SHOULD BE EVENLY SPACED FOR THE REMAINING AREA;

STEP 4: REPLACE RAIL AND RE-SEAL

STEP 5: ON THE INTERIOR NEXT TO THE THEATER SEAT, FASTEN 30" BLACK METAL CORNER MOLD 1" X 1 1/2" TO THE FLOOR AND TO THE WALL TO SECURE THEM TOGETHER.

- USE 1" SELF-TAPPING SCREWS WITH BLACK HEAD, 4 PER SIDE EVENLY SPACED;

STEP 6: LIFT THE DINETTE BENCH LID AGAINST THE WALL TO EXPOSE THE BOTTOM OF THE SLIDE WALL AND FLOOR LINE;

- ADD 4 - 1 1/2" SELF-TAPPING SCREWS THROUGH THE CLEAT INTO THE SIDE WALL;
- ADD 4 - 1 1/2" SELF-TAPPING SCREWS THROUGH THE SAME CLEAT INTO THE FLOOR EVENLY SPACED APART;

STEP 7: CLAIM REPAIR CODE.