


RECALL 25V277 / 2025-228 REMEDY INSTRUCTIONS

 FOREST RIVER	Make(s): STEALTH & XLR Model(s): MANY, SEE BELOW Model Year(s): 2025	Repair Code: RC-003-09-00-004712 Allotted Time: .30 HRS. Inspection Code: RC-003-05-00-004711 Allotted Time: .10 HRS.
	Concern: The front exterior accent lamp wire may lack the proper over current protection.	Photo(s) Required: NO Prior Authorization Required: YES Part(s) Kit Number: N/A Part(s) Return: N/A

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

CERTAIN 2025 - STEALTH & XLR TOY HAULER FIFTH-WHEELS: SFF3216GX, XLF286B, XLF363BX, XLF36G15, XLF40BAR13 & XLF41G14

INSPECTION:

STEP 1: LOCATE THE FRONT ACCENT LAMP GREEN/WHIE STRIPED 14AWG. WIRE IN THE FRONT COMPARTMENT;

- IF THE GREEN/WHITE STRIPE WIRE IS TERMINATED INTO A WAGO WITH A BLUE WIRE AND A RED WIRE WITH 15AMP OVER CURRENT PROTECTION, CLAIM INSPECTION ONLY;
- IF THE GREEN/WHITE STRIPE WIRE IS TERMINATED TO 30AMP MINI-BREAKER, MOVE TO REMEDY;

REMEDY:

STEP 1: REMOVE THE GREEN/WHITE WIRE FROM THE 30AMP MINI-BREAKER BY REMOVING THE 3/8" NUT;

- ONCE THE GREEN/WHITE STRIPE WIRE IS REMOVED, RE-INSTALL THE 3/8" NUT TIGHTLY AS TO ALLOW NO MOVEMENT;

STEP 2: CUT OFF THE RING TERMINAL FROM THE GREEN/WHITE STRIPE WIRE;

STEP 3: STRIP THE APPROPRIATE AMOUNT OF WIRE SHEATHING TO FIT INTO THE WAGO;

- DO NOT OVER STRIP THE WIRE AND HAVE EXPOSED COPPER STRANDS;

STEP 4: INSTALL THE GREEN/WHITE STRIPE WIRE INOT THE WAGO;

- LOCATE THE WAGO WITH THE SOLID BLUE WIRE WITH A 15AMP FUSE AND A SOLID RED WIRE IMMEDIATELY TO THE RIGHT OF THE MINI-BREAKER STRIP;
- THE WAGO MAY NEED TO BE CHANGED FROM A 2 POSITION WAGO TO A 3 POSITION WAGO (*SOURCE LOCALLY*)

STEP 5: ENSURE THE WAGO HAS ALL THREE WIRES INTO THEIR OWN INSERTS ON A 3 POSITION WAGO;

- GREEN/WHITE STRIPE WIRE
- BLUE SOLID WIRE (15AMP OVER CURRENT PROTECTION WIRE)
- RED SOLID WIRE

STEP 6: TEST FRONT ACCENT LAMP(S) FOR PROPER FUNCTIONALITY;

STEP 7: CLAIM REPAIR CODE.