


RECALL 26V039 / 2026-027 REMEDY INSTRUCTIONS

 FOREST RIVER	Make(s): MANY, SEE BELOW Model(s): MANY, SEE BELOW Model Year(s): 2026	Repair Code: RC-003-09-00-004796 Allotted Time: .50 HRS. Inspection Code: RC-003-05-00-004795 Allotted Time: .25 HRS.
	Concern: If the charge line for the 7-way becomes short circuited, it could cause a fire.	Photo(s) Required: NO Prior Authorization Required: YES Part(s) Kit Number: NO Part(s) Return: N/A

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

CERTAIN 2026: CHEROKEE ICE HOUSE RECREATIONAL VEHICLES
CERTAIN 2026: CAMPSITE RESERVE ICE HOUSE RECREATIONAL VEHICLES
CERTAIN 2026: CASCADE ICE HOUSE RECREATIONAL VEHICLES

PARTS:

SOURCE LOCALLY

INSPECTION:

STEP 1: LOCATE MINI BREAKER IN THE BATTERY COMPARTMENT.

- IDENTIFY THE 10AWG BLACK CHARGE LINE COMING FROM THE 7 WAY PLUG.
- IF CONNECTED TO THE PROTECTED SIDE OF THE MINI-BREAKER, CLAIM INSPECTION REPAIR CODE ONLY;
 - IF CONNECTED TO THE PROTECTED SIDE SKIP TO STEP 3 OF THE REMEDY AND COMPLETE STEPS 3 THROUGH 9;

REMEDY:

STEP 1: REMOVE THE BLACK 10AWG CHARGE WIRE FROM THE MINI-BREAKER AND REINSTALL THE NUT.

- TIGHTEN TO 25 IN-LBS.;

STEP 2: REMOVE THE NUT FROM THE PROTECTED SIDE OF THE BREAKER. INSTALL THE BLACK 10 AWG WIRE AND REINSTALL THE NUT.

- TIGHTEN TO 25 IN-LBS.;

STEP 3: LOCATE THE 4X4 JUNCTION BOX ON THE FRONT CROSS MEMBER OF THE TRAILER;

STEP 4: LOCATE THE 10 AWG BLACK WIRE COMING FROM THE 7 WAY CONNECTOR AND EXITS THE BOX TO THE BATTERY COMPARTMENT;

STEP 5: INSTALL A 30AMP MINI-BREAKER TO THE CROSS MEMBER, NEXT TO THE 4X4 JUNCTION BOX;

STEP 6: CONNECT THE 10AWG. BLACK CHARGE LINE TO THE COPPER "BATT" POST OF THE MINI-BREAKER;

- USE THE CORRECT SIZE RING TERMINAL;
- TIGHTEN TO 25 IN-LBS.

STEP 7: CONNECT THE 10AWG. BLACK WIRE THAT RUNS INTO THE VEHICLE TO THE SILVER SIDE OF THE MINI-BREAKER;

- USE THE CORRECT SIZE RING TERMINAL;
- TIGHTEN TO 25 ON-LBS.;

STEP 8: TEST FUNCTIONALITY;

STEP 9: CLAIM REPAIR CODE.