

RECALL 26V352 / 2026-263 REMEDY INSTRUCTIONS

 FOREST RIVER	Make(s): SALEM & WILDWOOD Model(s): MANY, SEE BELOW Model Year(s): 2023 - 2024	Repair Code: RC-003-01-00-004832 Allotted Time: .50 HRS. Inspection Code: RC-003-05-00-004831 Allotted Time: .25 HRS.
	Concern: Incorrect wiring was used on a fireplace outlet in certain model trailers	Photo(s) Required: NO Prior Authorization Required: YES Part(s) Kit Number: SOURCE LOCALLY Part(s) Return: NO, FIELD DESTROY

Turn off LP Gas at LPG Tank(s). Disconnect the vehicles' battery Positive and Negative, disconnect any House battery(s) Positive and Negative, if equipped with a generator ensure it is off and lastly, ensure the vehicle is disconnected from shore power. Block any tires/wheels to prevent the vehicle from rolling. Failure to do so may result in electrocution, fire or other personal injury, property damage and/or death.

CERTAIN 2024 – 2025 – SALEM: SMT24VIEWX, SMT24VIEWX, SMT25ICE, SMT26ICE & SMT26ICE
 CERTAIN 2024 – 2025 – WILDWOOD: WDT24VIEWX, WDT24VIEWX, WDT25ICE, WDT26ICE & WDT26ICE

SOURCE LOCAL PARTS (AS NEEDED):

1 – LISTED AND APPROVED NEW 110V 15AMP RECEPT
 12” – 14GA. ROMEX WIRE
 1 – 4” X4” JUNCTION BOX
 1 – 4” X4” JUNCTION BOX LID
 6 – WAGO CONNECTORS
 OR OTHER NEC APPROVED JUNCTION/CONNECTORS

INSPECTION:

STEP 1: REMOVE FIRE PLACE;

STEP 2: INSPECT 110V WIRE WHICH THE RECEPT IS WIRED WITH FROM THE CIRCUIT;

- IF THE RECEPT HAS A BLACK 14GA. “SJ” 110V WIRE FROM THE CIRCUIT, MOVE ON TO REMEDY;
- IF THE RECEPT HAS A WHITE OR OTHER COLOR 14GA. ROMEX WIRE FROM THE CIRCUIT, CLAIM INSPECTION AND REINSTALL FIRE PLACE;

REMEDY:

STEP 1: REMOVE MOUNTING SCREWS FOR RECEPT, SET ASIDE;

STEP 2: CUT THE BLACK 14GA. “SJ” 110V WIRE CLOSE TO THE RECEPT;

- DISCARD RECEPT – DO NOT REUSE IN ANY OTHER APPLICATION;

STEP 3: INSTALL APPROVED JUNCTION BOX/CONNECTION CLOSE TO WHERE THE “OLD” RECEPT WAS LOCATED;

- ENSURE TO USE NEC APPROVED JUNCTION(S) IF USING DIFFERENT;

STEP 4: INSTALL 14GA. ROMEX AND SECURE TO THE BLACK 14GA. “SJ” WIRE WITH WAGO CONNECTORS;

- ENSURE TO USE NEC APPROVED METHODS IF USING DIFFERENT CONNECTORS;

STEP 5: INSTALL OTHER END OF 14GA. ROMEX INTO THE REPLACEMENT RECEPT;

- ENSURE TO FOLLOW THE RECEPTS’ MANUFACTURERS INSTALLATION INSTRUCTIONS;

STEP 6: SECURE THE RECEPT

- USING THE SCREWS FROM THE DISCARDED RECEPT;
- REATTACH IN THE SAME VICINITY OF THE DISCARDED RECEPT;

STEP 7: PLUG THE FIRE PLACE INTO REINSTALLED RECEPT;

- TEST FIRE PLACE FUNCTIONALITY;
- ENSURE APPROVED JUNCTION(S) ARE SECURED;

STEP 8: REINSTALL FIRE PLACE;

- CLEAN AREA OF DEBRIS;

STEP 9: CLAIM REPAIR CODE.