

SP13-15 Floor covering becoming unglued in the coach

Inspect flooring, if you find a bubble that has a diameter size bigger than 2 inches you need to fix it.

Make a cut of 1cm long in flooring directly on the bubble.

Apply **Glue 684654 CONTACT GLUE 3M 1357-N (it is a 18 gallon, find equivalent glue locally)** and make a cross or "X" shape bead under floor covering and wooden floor.

Apply pressure on the glued surface to spread glue evenly under the flooring.

Let the glue evaporate for 30 minutes (do not close the hole)

Apply weight on entire glued surface for 2 hours

