

Tech Tips

TT 91-11-16

Date: August 5, 2011

2009-2013 Vehicles Equipped with Bluetooth Hands-Free
Phone – Pairing of Android Phones

March 29, 2013: Update to Include Additional Model Years.

When pairing an Android phone to the Bluetooth system, a few extra steps may be necessary. Follow the instructions below to pair the phone:

Device pairing instructions: Android 2.2 (Froyo)	
1	Let's begin at the home screen. Tap the arrow at the bottom left corner to access all your apps.
2	Tap "Wireless & networks."
3	Tap "Bluetooth@." You'll know that Bluetooth is on because there will be a green checkmark next to it.
4	Start your VW. Your Model's Bluetooth system will be in "discovery" mode for three minutes.
5	Tap "Bluetooth settings."
6	Tap "discoverable." A green checkmark should appear.
7	Tap "Scan for devices."
8	Once your phone has located "VW PHONE", tap it.
9	When the Bluetooth menu comes back up, it should say "Connected to phone & media audio" under the VW PHONE name on your phone. Be sure to watch the "Notifications bar" at the top of your phone's screen for an alert about Phonebook access. If you get this alert, you should approve it for your phonebook to operate properly.
10	If your Volkswagen has a multi-function display, follow the instructions there to finish connecting.

 **Note:**

The phonebook option is only available only on certain model configurations. Please see appropriate Technical Bulletin dependent on PR code of the installed Bluetooth system (i.e. 9W2, 9W3, 9W7).