

SB-10043373-3486



Countries:	BRAZIL, CANADA, UNITED STATES, MEXICO, SOUTH AFRICA	Document ID:	IK1600149
Availability:	ISIS, FleetISIS	Revision:	7
Major System:	CAB / SLEEPER / HOOD	Created:	2/27/2012
Current Language:	English	Last Modified:	10/30/2013
Other Languages:	Français , Portuguese , Español ,	Author:	Patrick Gotschall
Viewed:	1602		

[Less Info](#)

[Hide Details](#)

Coding Information

Copy Link 	Copy Relative Link 	Bookmark View My Bookmarks	Add to Favorites 	Print 	Provide Feedback 	Helpful 39	Not Helpful 12
----------------------	-------------------------------	--	-----------------------------	------------------	-----------------------------	--------------------------	------------------------------

Title: One piece sunshade mounting bracket becomes loose or comes off the cab

Applies To: HPV style (DuraStar, TerraStar, WorkStar, TranStar, ProStar, LoneStar) day cabs, extended cabs, and travel crews built in Garland or Springfield between June 2010 and February 2012. This does not affect Escobedo built vehicles.

DESCRIPTION

The one piece sunshade mounting bracket used on all model day cabs have been seeing instances where the adhesive patches fail and the sunshade mounting bracket becomes loose and/or comes completely off the vehicle.



The sunshade mounting bracket has completely detached from the vehicle.



The sunshade mounting bracket is starting to come loose from the vehicle - the adhesive patch at the center mount is pulling apart.

RESOLUTION

- If the bracket has not come off yet but is loose or in the process of detaching, follow the instructions in [Safety Recall 13505](#).
- If the bracket has come off, install a new mounting bracket. Remove any remaining adhesive from cab roof, prime/paint the attachment area, and reinstall the new mounting bracket using Lord Fusor 120, T20, or T21 SMC Repair Adhesive. Then seal the perimeter with an all weather adhesive/sealant. Use 2512126c91 - 3M 740 Hybrid Sealant - White (for white trucks) or 2611726c1 - SuperTrans® Sealant - Clear (for all trucks except white).
- For removal and installation of the sunshade to the bracket refer to the [Master Service Manual](#).

 Hide Details

Feedback Information

Viewed: 1601

Helpful: 39

Not Helpful: 12

No Feedback Found