

SB-10043373-7142**iKNow**

Select Country UNITED STATES
Availability: Internal
Major System: CAB / SLEEPER / HOOD
Other Language availability: English
Average Rating:
Number of Ratings:0

Doc ID: IK1600149
Language: English
Revision: 1.00
Created: 2/27/2012
Last Modified: 2/27/2012
Used: 0
Author: Adam Lesho

[Copy Link](#)

Rate this Article:

[Provide article feedback](#)

Was this document helpful?

[Yes](#)[No](#)[Bookmark](#)[Print](#)**Do not redistribute. For Internal Use Only.****Title:**

One piece sunshade mounting bracket coming loose or off the cab

Applies To:

All model day cabs

DESCRIPTION

The one piece sunshade mounting bracket used on all model day cabs have been seeing instances where the adhesive patch fails and the sunshade and the sunshade mounting bracket come off the vehicle.





RESOLUTION

- For installation of the mounting bracket, remove any remaining adhesive from cab roof, prime/paint the attachment area, and reinstall the new mounting bracket using Lord Fusor 120, T20, or T21 SMC Repair Adhesive. Then seal the perimeter with an all weather adhesive/sealant such as SikaFlex 221.
- For removal and installation of the sunshade to the bracket [CLICK HERE](#)

Feedback on this Article		(Hide Details)
<p>Viewed: 25 (this is the # of times that an article was opened)</p> <p>Used: 0 (this is the # of times that someone answered "Yes" the article did help them or it was attached to a case file)</p> <p>No's: 0 (this is the # of times that someone answered "No" the article did not help them)</p> <p>Average Rating:</p> <p>Number of Ratings: 0</p>		
<p>Feedback Comments</p> <p style="border: 1px solid black; padding: 2px; display: inline-block;">There are no feedback comments on this article yet.</p>		